


Lift Plate and Holding Fixture Installation




 **Callout** **Component Name**

1	<p>DT-47811-A Transmission Lift Plate</p> <p>Warning: Handle with care, the transmission assembly weighs over 83 Kg (183 lbs). Bodily injury could occur if not handled properly.</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tip After installation of lift plate, raise the transmission with an overhead hoist.</p> <p>Tighten 12 N·m (106 lb in)</p>
2	<p>J-46625 Transmission Holding Fixture</p> <p>J-46625-10 Holding Fixture Adapter</p> <p>Tip Adjust mounting block on fixture to match bosses on case.</p> <p>Tighten</p>

	13 N·m (10 lb ft).	
--	--------------------	--

Torque Converter Removal



Callout	Component Name
1	<p>Lock Pin</p> <p>Warning: Lock pin must be secured into the bench fixture to hold the transmission and prevent bodily injury.</p> <p>Tip Ensure the <i>J-3289-20</i> holding fixture is mounted to a bench that is properly supported and will support the weight of the transmission assembly without tipping. <i>J-39890</i> holding fixture adapter and an engine stand can be used as an alternative method for supporting the transmission assembly during repairs.</p> <p>Special Tools</p> <ul style="list-style-type: none">• <i>J-3289-20</i> Holding Fixture• <i>J-39890</i> Transmission Holding Fixture Adapter
2	<p><i>J-21366</i> Torque Converter Holding Strap</p>
	<p>Torque Converter Assembly</p> <p>Caution: Only install the lift assist handles until it stops. Do not tighten. Over</p>

tightening the lift assist handles can cause damage to the torque converter.

3 **Tip**
Failure to raise the torque converter straight up could damage the torque converter clutch lip seal inside the torque converter clutch assembly.

Special Tools

J-46409 Torque Converter Lifting Handles


Control Valve Body Assembly Removal

Table 1: [Control Valve Body Cover Removal](#)

Table 2: [Control Solenoid \(With Body and TCM\) Valve Assembly Removal](#)

Table 3: [Control Valve Body Assembly Removal](#)

Control Valve Body Cover Removal




Control Valve Body Cover Removal

Callout	Component Name
1	Control Valve Body Cover Bolts M6 x 30 (Qty: 13)
2	Control Valve Body Cover
3	Control Valve Body Gasket Tip Discard the seal. It is not reusable.
4	Control Valve Body Cover Wiring Connector Hole Seal Caution: Support the control solenoid valve assembly around the connector when removing the seal. Excessive pulling force can damage the internal electrical connections.

© 2010 General Motors Corporation. All rights reserved.

	Tip Discard the seal. It is not reusable.
5	Shift Position Switch Connector
6	Output Speed Sensor Connector
7	Input Speed Sensor Connector

Control Solenoid (With Body and TCM) Valve Assembly Removal




Control Solenoid (With Body and TCM) Valve Assembly Removal

Callout	Component Name
1	Control Valve Body M5 x 40.5 (Qty: 3)
2	Control Valve Body Bolt M6 x 30 (Qty: 12)
3	Control Solenoid (with Body and TCM) Valve Assembly
4	Control Solenoid Valve Assembly Filter Plate Caution: Use care when removing or installing the filter plate assembly. A broken or missing retaining tab may not adequately secure the filter plate to the control solenoid valve assembly, resulting in possible damage or contamination.
	Tip <ul style="list-style-type: none"> Discard the filter plate. It is not reusable. Inspect the pressure switch seals for damage or contamination. Replace the

control solenoid valve assembly as necessary.


Control Valve Body Assembly Removal



Control Valve Body Assembly Removal


Callout	Component Name
1	Fluid Level Control Valve
2	Fluid Level Control Valve Gasket
3	Control Valve Body Bolt M6 x 60 (Qty: 9)
4	Control Valve Body Bolt M6 x 53 (Qty: 2)
5	Control Valve Body Assembly
6	Control Valve Body Spacer Plate Assembly
7	Manual Shaft Detent Spring Bolt M6 x 16 (Qty: 1)
8	Manual Shaft Detent Lever Spring Assembly
9	1-2-3-4 Clutch Fluid Passage Seal Tip Discard the seal. It is not reusable.
10	Low/Reverse Clutch Fluid Passage Seal Tip Discard the seal. It is not reusable.

Input and Output Speed Sensor Removal




Callout	Component Name
1	A/Trans Output Speed Sensor Bolt M6 x 18 (Qty: 1)
2	A/Trans Output Speed Sensor Assembly
3	Input Speed Sensor Bolt M6 x 23 (Qty: 1)
4	Input Speed Sensor Assembly Tip Compress the locking tabs on the plug to release it from the case and to avoid damaging the retainers.
5	Input Speed Sensor Assembly Seals (Qty: 3) Tip Discard the seals. They are not reusable.

Torque Converter Housing with Fluid Pump Assembly Removal




Callout	Component Name
1	Torque Converter and Differential Housing Bolts M8 x 30 (Qty: 15)
2	Torque Converter with Fluid Pump Housing Assembly
3	Torque Converter Housing Gasket Tip Discard the seal. It is not reusable.
4	Fluid Pump Seal Assembly Tip Discard the seal. It is not reusable.

Front Differential Carrier Assembly Removal



Callout	Component Name
1	Front Differential Carrier Bearing Assembly
2	Differential Carrier Assembly
3	Final Drive Sun Gear

Drive and Driven Sprocket, Drive Link, and Park Pawl Removal




Callout	Component Name
1	Drive Link Lube Scoop
2	Drive Link Lube Scoop Seals
3	Drive Link Lube Fluid Seal
4	Driven Sprocket Assembly, Drive Sprocket and Park Gear Assembly and Drive Link Tip 1. The drive link, drive and driven sprocket assemblies must be removed at the same time. 2. The driven sprocket ball bearing inner race has a slight interference fit with the case. Pull straight up to ease removal.
5	Driven Sprocket Bearing Assembly Tip The driven sprocket bearing may be stuck to the driven sprocket.
6	Front Differential Carrier Baffle Bolts M6 x 16 (Qty: 2)
7	Front Differential Carrier Baffle

© 2010 General Motors Corporation. All rights reserved.

8	Park Pawl Shaft
9	Park Pawl Spring
10	Park Pawl


Internal Components Removal



Callout	Component Name
1	<p>1-2-3-4 Clutch Backing Plate Retainer Ring</p> <p>Warning: The retainer is under tension. Use care when removing or installing the retainer. Personal injury could result.</p> <p>Caution: Use caution during removal or installation of the retainer ring to avoid damage to the case machined surface in the park pawl area. Burrs or raised edges on the case machined surface can cause the park pawl to bind and prohibit it from engaging the park gear.</p> <p>Tip Remove one end of the retainer using <i>J-28585</i> remover or equivalent and work the retainer out of the case groove.</p> <p>Special Tools</p> <p><i>J-28585</i> Snap Ring Remover or equivalent</p>
2	3-5 Reverse and 4-5-6 Clutch Housing Assembly, Gearset, Low-Reverse Clutch Assembly and Low-Reverse and 1-2-3-4 Clutch Housing

	Tip This unit is heavy - weighs 40 lbs. (18 Kg).
3	2-6 Clutch Plate (Qty: 1)
4	2-6 Clutch Apply Plate (Waved)
5	35R and 456 Clutch Housing Thrust Bearing Assembly

2-6 Clutch Piston Removal




Callout	Component Name
1	2-6 Clutch Spring Retainer Special Tool <i>J28585 Snap Ring Remover or equivalent</i>
2	2-6 Clutch Spring
3	2-6 Clutch Piston Assembly Tip <ul style="list-style-type: none">• Use pliers to remove the piston.• Inspect the piston seals for damage and/or wear. The piston is reusable.

Manual Shift Detent Lever with Shaft Position Switch Assembly and Park Pawl Actuator Removal

Table 1: [Manual Shaft Detent \(w/Shift Position Switch\) Lever Assembly Removal](#)

Table 2: [Park Pawl and Actuator Guide Removal](#)

[Manual Shaft Detent \(w/Shift Position Switch\) Lever Assembly Removal](#)




[Manual Shaft Detent \(w/Shift Position Switch\) Lever Assembly Removal](#)

Callout	Component Name
1	<p>Manual Shaft Detent Lever Hub Pin</p> <p>Special Tool</p> <p><i>DT-48550 Detent Lever Pin Remover</i></p>
	<p>Manual Shift Shaft Pin</p> <p>Tip</p> <p>Discard the pin. It is not reusable.</p>

Special Tools

2	<ul style="list-style-type: none"> J23129 Universal Seal Remover J6125-B Slide Hammer
3	Manual Shaft
4	Manual Shaft Detent (w/Shift Position Switch) Lever Assembly
5	Park Pawl Actuator Assembly

Park Pawl Actuator Guide Removal




Park Pawl and Actuator Guide Removal


Callout	Component Name
1	Park Pawl Actuator Guide Pin
2	Park Pawl Actuator Guide Assembly
3	Park Pawl Actuator Guide Assembly Seal

Tip
Discard the seal. It is not reusable.

Manual Shift Shaft Seal Removal




Input Shaft Support Replacement



Callout	Component Name
1	<p>3-5 Reverse and 4-5-6 Clutch Fluid Seals (Qty: 4)</p> <p>Tip</p> <ul style="list-style-type: none">Discard the fluid seals. They are not reusable.Refer to 3-5-Reverse and 4-5-6 Clutch Fluid Seal Ring Replacement.
2	<p>Input Shaft Support Bolts M6 x 50 (Qty: 3)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 12 N·m (106 lb in)</p>
3	<p>Input Shaft Support</p> <p>Tip</p> <p>Inspect the support for wear, damage or porosity.</p>


3-5-Reverse and 4-5-6 Clutch Fluid Seal Ring Replacement



Callout	Component Name
1	<p>3-5 Reverse and 4-5-6 Clutch Fluid Seals (Qty: 4)</p> <p>Tip</p> <ol style="list-style-type: none">1. Place J-46620-3 which is part of J-46620 installer over the case hub and adjust it so that only the bottom seal ring is exposed.2. Place a NEW fluid seal ring onto J-46620-3 which is part of J-46620 installer .3. Use J-46620-2 which is part of J-46620 installer to push the fluid seal ring down over J-46620-3 which is part of J-46620 installer into the hub ring groove.4. Repeat the above steps to install all 4 seal rings, adjusting J-46620-3 which is part of J-46620 installer to the appropriate ring groove. <p>Special Tools</p> <p>J-46620 Seal Installer</p>
	Small Chamfer Up © 2010 General Motors Corporation. All rights reserved.

	<p>Caution: Do not force J-46620-1 down over the seals as this will roll and damage the seals. The large chamfer is designed to fit over the over stretched seal. Use a hand to help shrink the seal if J-46620-1 is difficult to install over the seal rings.</p>
2	<p>Tip Install J-46620-1 which is part of <i>J-46620</i> installer with the large chamfer end down over the fluid seal rings and leave J-46620-1 which is part of <i>J-46620</i> installer on the seals for at least 60 seconds.</p>
	<p>Special Tools</p>
	<p><i>J-46620</i> Seal Installer</p>
3	<p>Large Chamfer Up</p> <p>Tip</p> <ol style="list-style-type: none">1. Install J-46620-1 which is part of <i>J-46620</i> installer with the small chamfer end facing down for at least 60 seconds. This will properly size the bottom seal ring.2. Leaving J-46620-1 which is part of <i>J-46620</i> installer on the fluid seal rings for an extended period of time could cause a fluid leak on the initial clutch piston circuit until the seal rings warm up and expand to the proper dimension. <p>Special Tools</p>
	<p><i>J-46620</i> Seal Installer</p>


Front Wheel Drive Shaft Seal Replacement - Case Side



 **Callout** **Component Name**

Callout	Component Name
1	Front Wheel Drive Shaft Oil Seal Special Tools <ul style="list-style-type: none">• <i>DT-47790</i> Seal Installer• <i>J 6125-B</i> Slide Hammer• <i>J 8092</i> Driver Handle• <i>J 23129</i> Universal Seal Remover

Transmission Case Cleaning and Inspection



Callout	Component Name
Caution: Do not use abrasive pads or bristle devices to clean the sealing surfaces. Abrasive pads produce a fine grit that can effect transmission function. Abrasive pads can also remove enough metal to create oil leaks.	
Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.	
Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.	
Preliminary Procedures	
1.	Thoroughly clean the transmission case assembly, including case threads, with clean solvent.
2.	Clean gasket sealing surfaces. Remove all residual gasket material.
3.	Inspect all threaded holes. If necessary, repair any thread damage.
	Torque Converter Housing Locating Pin
Procedure	©2010 General Motors Corporation. All rights reserved.


1	Inspect the torque converter housing locating pins. Specification The locating pins installed height is 7.4 mm (0.29 in).
2	Fluid Trough Check Ball Specification The check ball installed depth is 11.5 mm (0.45 in).
3	Converter Housing Sealing Surface
4	Control Valve Body Cover Sealing Surface
5	Fill Cap Seal
6	Transmission Fluid Cooler Pipe Sealing Surface
7	Fluid Pressure Test Plug Caution: Refer to Fastener Caution in the Preface section. Tighten 12 N·m (106 lb in)
8	Manual Shift Shaft Seal Surface
9	Fluid Fill Cap Sealing Surface
10	Fluid Level Plug Tighten 12 N·m (106 lb in)
11	Valve Body Locating Pin Procedure Inspect the valve body locating pins. Specification The locating pins installed height is 5.8 mm (0.22 in).
12	Drain Plug Tighten 12 N·m (106 lb in)

Manual Shift Detent Lever with Shaft Position Switch Assembly and Park Pawl Actuator Installation

Table 1: [Park Pawl and Actuator Guide Installation](#)

Table 2: [Installation](#)


Park Pawl Actuator Guide Installation



Park Pawl and Actuator Guide Installation

Callout	Component Name
1	Park Pawl Actuator Guide Assembly Seal
2	Park Pawl Actuator Guide Assembly
3	Procedure Install the park pawl actuator guide pin. Specification The park pawl actuator guide pin installed height is 9.7 mm (0.38 in).

Installation




Installation

Callout	Component Name
1	Park Pawl Actuator Assembly
2	Manual Shift Detent (with Shaft Position Switch) Lever Assembly
3	<p>Manual Shaft</p> <p>Tip Lubricate the shaft with ATF to prevent damage to the manual shift shaft seal during installation.</p>
4	<p>Manual Shaft Detent Lever Hub Pin</p> <p>Tip Use a NEW pin to ensure proper engagement with the shaft. <i>DT-48550</i> remover can also be used to install the pin.</p> <p>Procedure</p> <p>Install the manual shaft detent lever hub pin.</p> <p>Specification: The manual shaft detent lever hub pin installed height is (b) 7.9 mm (0.38 in).</p>


Special Tools	
<i>DT-48550 Detent Lever Pin Remover</i>	
5	<p>Manual Shift Shaft Pin</p> <p>Caution: Use J 41229 to install the manual shaft pin at the correct height in order to properly secure the manual shaft. If you install the pin too deep, the case bore may crack.</p> <p>Tip Use a NEW pin to ensure proper engagement with the case.</p> <p>Procedure</p> <p>Inspect pin height.</p> <p>Specification: The manual shift shaft pin installed height is within (a) 7.2-8.2 mm (0.28-0.32 in).</p> <p>Special Tools</p> <p><i>J-41229 Manual Shaft Pin Installer</i></p>

Manual Shift Shaft Seal Installation



Callout	Component Name
1	Manual Shift Shaft Seal Special Tool <i>DT-49101 Seal Installer</i>

2-6 Clutch Piston Installation



Callout	Component Name
1	<p>2-6 Clutch Piston Assembly</p> <p>Tip</p> <ul style="list-style-type: none"> Position the 2-6 piston air bleed and large slot toward the top of the case. <i>DT-47796</i> seal protector prevents the piston seal lip from damage during installation. Apply a thin coat of ATF to the I.D. of the <i>DT-47796</i> seal protector to ease installation of the piston. <p>Special Tool</p> <p><i>DT-47796</i> Seal Protector</p>
2	<p>2-6 Clutch Spring</p> <p>2-6 Clutch Spring Retainer</p> <p>Caution: Regulate the air pressure to 40 psi maximum. High pressure could cause the piston to over travel and damage the piston seals.</p> <p>Tip</p> <ul style="list-style-type: none"> Place the retainer on the 2-6 clutch spring and align the retainer opening with

3


the largest gap in the case splines toward the bottom of the case. The retainer opening should be supported by a spline tooth of the case.

- Apply shop air to the clutch fluid feed hole in the case to verify proper piston operation.

Special Tools

- *DT-47797* Spring Installer
- *DT-48056* Spring Compressor Bridge

Low and Reverse and 1-2-3-4 Clutch Housing, Low and Reverse Clutch Assembly, Output Sun Gear, and 2-6 Clutch Plate Disassemble




Callout	Component Name
1	1-2-3-4 Clutch Backing Plate
2	1-2-3-4 Clutch Plate Assembly (Qty: 2)
3	1-2-3-4 Clutch Plate (Qty: 2)
4	1-2-3-4 Clutch Waved Plate
5	<p>Tip The sun gear thrust bearing may be stuck to the driven sprocket hub.</p>
6	Output Sun Gear Assembly
7	Low-Reverse and 1-2-3-4 Clutch Housing Assembly
8	Low and Reverse Clutch Apply Plate
9	Low and Reverse Clutch Plate (Qty: 3)
10	Low and Reverse Clutch Plate Assembly (Qty: 3)
11	Low and Reverse Clutch Backing Plate

© 2010 General Motors Corporation. All rights reserved.

12	Low and Reverse Clutch Assembly (OWC)
13	2-6 Clutch Plate Assembly (Qty: 2)
14	2-6 Clutch Plate (Qty: 1)

Input, Reaction, and Output Carrier Disassemble



Callout	Component Name
1	Output Carrier Assembly
2	Output Carrier Thrust Bearing Assembly
3	Input Sun Gear Thrust Bearing Assembly
4	Input Carrier Assembly
5	Input Sun Gear
6	Input Sun Gear Thrust Bearing Assembly
7	Input Carrier Thrust Bearing Assembly
8	Reaction Carrier Assembly
9	Reaction Carrier Sun Gear Assembly
10	Reaction Carrier Sun Gear Thrust Bearing Tip The sun gear thrust bearing may be stuck to the sun gear.
11	3-5 Reverse and 4-5-6 Clutch Housing Assembly

3-5-Reverse and 4-5-6 Clutch Housing Disassemble

Table 1: [Turbine Shaft, Reluctor Wheel and Piston Removal](#)


Table 2: [4-5-6 Clutch Plate Removal](#)

Table 3: [4-5-6 Clutch Piston Removal](#)

Table 4: [Reluctor Wheel and Piston Removal](#)

Table 5: [3-5 Reverse Clutch Plate Removal](#)

Turbine Shaft, Reluctor Wheel and Piston Removal




Turbine Shaft, Reluctor Wheel and Piston Removal

Callout	Component Name
1	<p>Turbine Shaft Retainer Ring</p> <p>Tip Discard the retainer ring. It is not re-usable.</p>
2	<p>Special Tools</p> <p>J-5586-A Snap Ring Pliers or equivalent</p>
	Turbine Shaft

© 2010 General Motors Corporation. All rights reserved.

3	Reaction Carrier Hub Assembly
4	Reaction Carrier Hub Thrust Bearing Assembly


4-5-6 Clutch Plate Removal



4-5-6 Clutch Plate Removal

Callout	Component Name
1	4-5-6 Clutch Backing Plate Retaining Ring
2	4-5-6 Clutch Backing Plate
3	4-5-6 Clutch Plate Assembly (Qty: 4)
4	4-5-6 Clutch Plate (Qty: 3)
5	4-5-6 Clutch Apply Plate
6	4-5-6 Clutch Wave Plate

4-5-6 Clutch Piston Removal




4-5-6 Clutch Piston Removal

Callout	Component Name
1	<p>4-5-6 Clutch Dam Retaining Ring</p> <p>Special Tools</p> <ul style="list-style-type: none"> • DT-47951-2 Spring Compressor • J-5586-A Snap Ring Pliers or equivalent
2	<p>4-5-6 Clutch Piston Fluid Dam Assembly</p> <p>Tip</p> <ol style="list-style-type: none"> 1. Place the 3-5 reverse and 4-5-6 clutch housing onto the support hub in the case. 2. Apply shop air to the 4-5-6 clutch feed hole using a rubber tipped air gun to dislodge the dam piston and the 4-5-6 clutch piston from the clutch housing.
3	4-5-6 Clutch Piston Return Spring Assembly
4	<p>4-5-6 Clutch Piston</p> <p>Tip</p> <p>Apply shop air to the 4-5-6 clutch feed hole using a rubber tipped air gun to dislodge the clutch piston.</p>
5	4-5-6 Clutch Piston Inner Seal
6	4-5-6 Clutch Piston Outer Seal (DK Blue) (Stepped)

7 4-5-6 Clutch Piston Outer Seal (Large) (Rounded)


Reluctor Wheel and Piston Removal



Reluctor Wheel and Piston Removal

Callout	Component Name
1	Input Shaft Speed Sensor Reluctor Ring Retainer Ring Caution: Compress the reluctor wheel just enough to clear the retainer. Over compressing the reluctor wheel will break the alignment tab and the clutch housing.
	Special Tools
	DT-47694 Piston Spring Compressor
2	Input Shaft Speed Sensor Reluctor Wheel
3	3-5 Reverse Clutch Piston
4	3-5 Reverse Clutch Piston Return Spring Assembly
5	3-5 Reverse Clutch Piston Inner (Reluctor) Seal (Orange)
6	3-5 Reverse Clutch Piston Inner Seal
7	3-5 Reverse Clutch Piston Dam Seal (Black)

3-5 Reverse Clutch Plate Removal




3-5 Reverse Clutch Plate Removal

Callout	Component Name
1	3-5 Reverse Clutch Backing Plate Ring Retainer Ring Tip Gently push down on the backing plate to get enough clearance between the backing plate and retainer.
2	3-5 Reverse Clutch Backing Plate
3	3-5 Reverse Clutch Plate Assembly (Qty: 3)
4	3-5 Reverse Clutch Plate (Qty: 3)
5	3-5 Reverse Clutch Apply Plate (Waved)

3-5-Reverse and 4-5-6 Clutch Housing Assemble

- Table 1: [3-5 Reverse Clutch Plates Installation](#)
- Table 2: [Reluctor Wheel and Piston Installation](#)
- Table 3: [4-5-6 Clutch Piston Installation](#)
- Table 4: [4-5-6 Clutch Fluid Dam Installation](#)
- Table 5: [4-5-6 Clutch Plates Installation](#)
- Table 6: [Turbine Shaft Installation](#)

3-5 Reverse Clutch Plates Installation




3-5 Reverse Clutch Plates Installation

Callout	Component Name
1	3-5 Reverse Clutch Apply Plate (Waved)
2	3-5 Reverse Clutch Plate (Qty: 3)
3	3-5 Reverse Clutch Plate Assembly (Qty: 3)
4	3-5 Reverse Clutch Backing Plate
5	3-5 Reverse Clutch Backing Plate Ring Retainer Ring

Reluctor Wheel and Piston Installation


© 2010 General Motors Corporation. All rights reserved.



Reluctor Wheel and Piston Installation

Callout	Component Name
1	3-5 Reverse Clutch Piston Dam Seal (Black)
2	3-5 Reverse Clutch Piston Inner Seal
3	3-5 Reverse Clutch Piston Inner (Reluctor) Seal (Orange)
4	3-5 Reverse Clutch Piston Return Spring Assembly
5	3-5 Reverse Clutch Piston
6	Input Shaft Speed Sensor Reluctor Wheel
7	<p>Input Shaft Speed Sensor Reluctor Ring Retainer Ring</p> <p>Caution: Compress the reluctor wheel just enough to clear the retainer. Over compressing the reluctor wheel will break the alignment tab and the clutch housing.</p> <p>Caution: Regulate the air pressure to 40 psi maximum. High pressure could cause the piston to over travel and damage the piston seals.</p> <p>Tip Place the housing assembly onto the input shaft support inside the case. Apply shop air to the clutch fluid feed hole in the case to verify proper piston operation.</p> <p>Special Tools</p> <p>DT-47694 Piston Spring Compressor</p>


4-5-6 Clutch Piston Installation



4-5-6 Clutch Piston Installation

Callout	Component Name
1	4-5-6 Clutch Piston Inner Seal
2	4-5-6 Clutch Piston Outer Seal (Large) (Rounded)
3	4-5-6 Clutch Piston Outer Seal (DK Blue) (Stepped)
4	<p>4-5-6 Clutch Piston</p> <p>Tip</p> <ul style="list-style-type: none"> • <i>DT-47805</i> seal protector prevents the dam seal lip from damage during installation. Apply a thin coat of ATF to the I.D. of <i>DT-47805</i> protector to ease the installation of the piston. • <i>DT-47951-2</i> spring compressor can be used as a pusher if necessary. <p>Special Tools</p> <ul style="list-style-type: none"> • <i>DT-47805</i> Seal Protector • <i>DT-47951-2</i> Spring Compressor

4-5-6 Clutch Fluid Dam Installation




4-5-6 Clutch Fluid Dam Installation

Callout	Component Name
1	4-5-6 Clutch Piston Return Spring Assembly
2	<p>4-5-6 Clutch Piston Fluid Dam Assembly</p> <p>Tip <i>DT-47951-1</i> seal protector prevents the dam seal lip from damage during installation. Apply a thin coat of ATF to the I.D. of <i>DT-47951-1</i> protector to ease the installation of the dam.</p>
	<p>Special Tools</p> <p><i>DT-47951-1</i> Seal Protector</p>
3	<p>4-5-6 Clutch Dam Retaining Ring</p> <p>Caution: Regulate the air pressure to 40 psi maximum. High pressure could cause the piston to over travel and damage the piston seals.</p> <p>Tip</p> <ul style="list-style-type: none"> Leave <i>DT-47951-1</i> protector in place while installing the retaining ring. Place the housing assembly onto the input shaft support inside the case. Apply shop air to the clutch fluid feed hole in the case to verify proper piston operation. <p>Special Tools</p>

DT-47951-2 Spring Compressor


4-5-6 Clutch Plates Installation



4-5-6 Clutch Plates Installation

Callout	Component Name
1	Reaction Carrier Hub Thrust Bearing Assembly
2	Reaction Carrier Hub Assembly
3	4-5-6 Clutch Wave Plate
4	4-5-6 Clutch Apply Plate
5	4-5-6 Clutch Plate Assembly (Qty: 4)
6	4-5-6 Clutch Plate (Qty: 3)
7	4-5-6 Clutch Backing Plate
8	4-5-6 Clutch Backing Plate Retaining Ring


Turbine Shaft Installation



Turbine Shaft Installation

Callout	Component Name
1	Turbine Shaft
2	Turbine Shaft Retainer Ring Tip Do not re-use the turbine shaft retainer ring. Special Tools <i>J-5586-A Snap Ring Pliers or equivalent</i>

Input, Reaction, and Output Carrier Assemble




Callout	Component Name
1	3-5 Reverse and 4-5-6 Clutch Housing Assembly
2	Reaction Carrier Sun Gear Thrust Bearing
3	Reaction Carrier Sun Gear Assembly
4	Reaction Carrier Assembly
5	Input Carrier Thrust Bearing Assembly
6	Input Sun Gear Thrust Bearing Assembly
7	Input Carrier Assembly
8	Input Sun Gear
9	Input Sun Gear Thrust Bearing Assembly
10	Output Carrier Thrust Bearing Assembly
11	Output Carrier Assembly
12	<p>2-6 Clutch Plate Assembly (Qty: 2)</p> <p>Tip Begin with the clutch plate assembly and alternate with the clutch plate.</p>
	2-6 Clutch Plate (Qty: 1)

13

Tip


Only install one 2-6 Clutch Plate at this time. The remaining clutch plate is installed into the case.

3-5-Reverse and 4-5-6 Clutch Housing, and Input, Reaction, and Output Carrier Installation



Callout	Component Name
1	3-5 Reverse and 4-5-6 Clutch Housing Thrust Bearing
2	2-6 Clutch Apply Plate (Waved)
3	2-6 Clutch Plate (Qty: 1) <p>Tip</p> <ul style="list-style-type: none"> Only install one 2-6 Clutch Plate. The remaining clutch plate is installed with the gearset assembly. Align the large flat areas with the valve body end of the case and the 2 tabs on the clutch plate that are close to each other with the slots at the bottom right corner of the case.
4	3-5 Reverse and 4-5-6 Clutch Housing Assembly and Gearset <p>Tip</p> <p>Align the large flat areas of the 2-6 Clutch Plate with the valve body end of the case and the 2 tabs on the clutch plate that are close to each other with the slots at the bottom right corner of the case.</p>

Low and Reverse Clutch Assembly and Low and Reverse Clutch Plate Installation



Callout	Component Name
1	<p>Low and Reverse Clutch Assembly (OWC)</p> <p>Tip</p> <ul style="list-style-type: none"> The Low and Reverse Clutch Assembly should rotate freely in one direction and lock in the opposite direction. Align the large flat areas of the Low and Reverse Clutch Assembly with the valve body end of the case.
2	Low and Reverse Clutch Backing Plate
3	Low and Reverse Clutch Plate Assembly (Qty: 3)
4	<p>Low and Reverse Clutch Plate (Qty: 3)</p> <p>Tip</p> <p>Align the large flat areas of the Low and Reverse Clutch Plate with the valve body end of the case.</p>
5	<p>Low and Reverse Clutch Apply (Waved) Plate</p> <p>Tip</p>

© 2010 General Motors Corporation. All rights reserved.


Align the large flat areas of the Low and Reverse Clutch Apply Plate with the valve body end of the case.

Low and Reverse and 1-2-3-4 Clutch Housing Disassemble

Table 1: [Low and Reverse Clutch Piston Removal](#)

Table 2: [1-2-3-4 Clutch Piston Removal](#)


Low and Reverse Clutch Piston Removal



Low and Reverse Clutch Piston Removal

Callout	Component Name
1	Low and Reverse Clutch Spring Retainer Special Tools <i>J-8059 Snap Ring Pliers - Parallel Jaw</i>
2	Low and Reverse Clutch Spring
3	Low and Reverse Clutch Piston


1-2-3-4 Clutch Piston Removal



1-2-3-4 Clutch Piston Removal

Callout	Component Name
1	1-2-3-4 Clutch Spring Retainer Special Tools <i>J-8059 Snap Ring Pliers - Parallel Jaw</i>
2	1-2-3-4 Clutch Spring
3	1-2-3-4 Clutch Piston

Low and Reverse and 1-2-3-4 Clutch Housing Cleaning and Inspection




Callout	Component Name												
<p>Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.</p> <p>Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.</p>													
<h3>Preliminary Procedures</h3> <ol style="list-style-type: none">1. Thoroughly clean the housing with clean solvent.2. Inspect the piston bores and retainer ring grooves for wear, damage or porosity. <table border="1"><tbody><tr><td>1</td><td>1-2-3-4 Clutch Spring Retainer Groove</td></tr><tr><td>2</td><td>1-2-3-4 Clutch Piston Bore</td></tr><tr><td>3</td><td>Low and Reverse Clutch Spring Retainer Groove</td></tr><tr><td>4</td><td>Low and Reverse Clutch Piston Bore</td></tr><tr><td>5</td><td>Clutch Oil Passages</td></tr><tr><td>6</td><td>Air Bleed Passages</td></tr></tbody></table>		1	1-2-3-4 Clutch Spring Retainer Groove	2	1-2-3-4 Clutch Piston Bore	3	Low and Reverse Clutch Spring Retainer Groove	4	Low and Reverse Clutch Piston Bore	5	Clutch Oil Passages	6	Air Bleed Passages
1	1-2-3-4 Clutch Spring Retainer Groove												
2	1-2-3-4 Clutch Piston Bore												
3	Low and Reverse Clutch Spring Retainer Groove												
4	Low and Reverse Clutch Piston Bore												
5	Clutch Oil Passages												
6	Air Bleed Passages												

Low and Reverse and 1-2-3-4 Clutch Housing Assemble

Table 1: [1-2-3-4 Clutch Piston Installation](#)

Table 2: [Low and Reverse Clutch Piston Installation](#)

1-2-3-4 Clutch Piston Installation



1-2-3-4 Clutch Piston Installation

Callout	Component Name
1	<p>1-2-3-4 Clutch Piston</p> <p>Tip <i>DT-47798</i> protector prevents the piston seal lip from damage during installation. Apply a thin coat of ATF to the ID of <i>DT-47798</i> protector to ease the installation of the piston.</p> <p>Special Tools</p> <p><i>DT-47798</i> Seal Protector</p>
2	1-2-3-4 Clutch Spring
	1-2-3-4 Clutch Spring Retainer

© 2010 General Motors Corporation. All rights reserved.

Caution: Regulate the air pressure to 40 psi maximum. High pressure could cause the piston to over travel and damage the piston seals.

Tip


3

1. Place the retainer onto DT-47799-1 which is part of *DT-47799* compressor . Compressing the spring using DT-47799-2 which is part of *DT-47799* compressor , will install the retainer into the retainer groove.
2. Apply shop air to the clutch fluid feed hole in the clutch housing to verify proper piston operation.

Special Tools

DT-47799 Clutch Piston Spring Compressor

Low and Reverse Clutch Piston Installation




Low and Reverse Clutch Piston Installation

Callout	Component Name
	Low and Reverse Clutch Piston
1	<p>Tip</p> <p><i>DT-47807</i> protector prevents the piston seal lip from damage during installation. Apply a thin coat of ATF to the ID of <i>DT-47807</i> protector to ease the installation of the piston.</p>

Special Tools	
	<i>DT-47807</i> Clutch Piston Seal Protector
2	Low and Reverse Clutch Spring
	Low and Reverse Clutch Spring Retainer
	Caution: Regulate the air pressure to 40 psi maximum. High pressure could cause the piston to over travel and damage the piston seals.
	Tip
3	<ol style="list-style-type: none">1. Place the retainer onto <i>DT-47794-1</i> which is part of <i>DT-47794</i> compressor . Compressing the spring using <i>DT-47794-2</i> which is part of <i>DT-47794</i> compressor , will install the retainer into the retainer groove.2. Apply shop air to the clutch fluid feed hole in the clutch housing to verify proper piston operation.
Special Tools	
	<i>DT-47794</i> Spring Compressor

Low and Reverse and 1-2-3-4 Clutch Housing, and 1-2-3-4 Clutch Plate Installation



 **Callout** **Component Name**

Callout	Component Name
1	Low and Reverse and 1-2-3-4 Clutch Housing Tip The longer legs face the bottom of the case and the oil passages face the valve body end of the case.
2	Output Sun Gear Assembly
3	1-2-3-4 Clutch Waved Plate Tip Align the single pair of tabs with the bottom valve body end of the case.
4	1-2-3-4 Clutch Plate (Qty: 2)
5	1-2-3-4 Clutch Plate Assembly (Qty: 2)
6	1-2-3-4 Clutch Backing Plate Tip Align the single skinny tab with the case spline facing the top of the case.
	1-2-3-4 Clutch Backing Plate Retainer Ring

© 2010 General Motors Corporation. All rights reserved.

Warning: The retainer is under tension. Use care when removing or installing the retainer. Personal injury could result.

Caution: Use caution during removal or installation of the retainer ring to avoid damage to the case machined surface in the park pawl area. Burrs or raised edges on the case machined surface can cause the park pawl to bind and prohibit it from engaging the park gear.

Tip


7

- Install the retainer with the taper facing away from the backing plate.
- Align the retainer opening with the largest gap in the case splines toward the bottom of the case.
- Install one end of the retainer into the retainer ring groove. Use *J28585* snap ring remover and work the retainer into the case groove. Use a screwdriver to hold the retainer away from the case while pushing down on the retainer with *J28585* snap ring remover .

Special Tool


J28585 Snap Ring Remover or equivalent

Drive Sprocket, Driven Sprocket, and Drive Link Cleaning and Inspection



Callout	Component Name
1	Drive Sprocket Thrust Washer
2	Drive Sprocket Retainer Ring
3	Drive Sprocket
4	Drive Sprocket Bearing Assembly
5	Park Gear
6	Driven Sprocket
7	Drive Link Assembly


Drive and Driven Sprocket, Drive Link, and Park Pawl Installation



Callout	Component Name
1	Front Differential Carrier Baffle
2	Front Differential Carrier Baffle Bolt M6 x 16 (Qty: 2) Caution: Refer to Fastener Caution in the Preface section. Tighten 12 N·m (106 lb in)
3	Drive Link Lube Scoop Seal
4	Drive Link Lube Fluid Seal
5	Drive Link Lube Scoop
6	Driven Sprocket Bearing Assembly
7	Drive Sprocket Bearing Assembly
	Driven Sprocket Assembly, Drive Sprocket Assembly and Drive Link Tip <ul style="list-style-type: none"> • Install the drive link with the colored links and/or part number facing up.

		<ul style="list-style-type: none">• The drive link, drive, and driven sprocket assemblies must be installed at the same time.• The ball bearing should spin freely and smoothly.• The driven sprocket ball bearing inner race has a slight interference fit with the case. Tap gently with the palm of a hand or a soft tip hammer to install.
8		Park Pawl
10		Park Pawl Spring
11	Park Pawl Shaft	<p>Tip</p> <p>Check to ensure that the park pawl operates freely and is not binding.</p>


Front Differential Carrier Cleaning and Inspection



Callout	Component Name
<p>Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.</p>	
<p>Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.</p>	
<p>Caution: Keep thrust washers with the gear it was matched to. The thrust washers are selective sizes and it is difficult to identify the proper washer thickness. Improper assembly can cause premature failure of the differential assembly.</p>	
1	Front Differential Pinion Gear Shaft Retainer
2	Front Differential Pinion Gear Pin
3	Sun Gear to Differential Housing Bearing Assembly


4	Front Differential Pinion Gear Washer
5	Front Differential Pinion Gear
6	Front Differential Planetary Pinion Gear Bearing Roller

Front Differential Carrier Installation




Callout	Component Name
1	Final Drive Sun Gear
2	Differential Carrier Assembly
3	Front Differential Carrier Bearing Asembly

Transmission Fluid Pump, Front Differential Carrier Baffle, and Front Differential Ring Gear Removal




Callout	Component Name
1	Front Differential Carrier Baffle Bolts M6 x 25 (Qty: 2)
2	Front Differential Carrier Baffle
3	Front Differential Ring Gear Retainer Tip Note the direction of the taper to ensure proper installation.
4	Front Differential Ring Gear
5	Fluid Pump Bolts M8 x 33 (Qty: 8)
6	Fluid Pump Assembly
7	Torque Converter and Differential Housing Seal

Front Wheel Drive Shaft Seal Replacement - Torque Converter Housing Side



Callout	Component Name
1	<p>Front Wheel Drive Shaft Oil Seal Assembly</p> <p>Special Tools</p> <ul style="list-style-type: none">• <i>DT-47790</i> Seal Installer• <i>J 6125-B</i> Slide Hammer• <i>J 8092</i> Driver Handle• <i>J 23129</i> Universal Seal Remover

Torque Converter Housing Cleaning and Inspection




Callout	Component Name
Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.	
Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.	
Caution: Do not use abrasive pads or bristle devices to clean the sealing surfaces. Abrasive pads produce a fine grit that can effect transmission function. Abrasive pads can also remove enough metal to create oil leaks.	
<h3>Preliminary Procedure</h3> <p>Thoroughly clean the torque converter housing, including case threads with clean solvent.</p>	
1	Threaded Hole
2	Gasket Sealing Surface

Transmission Fluid Pump Disassemble

Table 1: [Fluid Filter Assembly and Torque Converter Fluid Seal Disassemble](#)

Table 2: [Fluid Pump Disassemble](#)

Fluid Filter Assembly and Torque Converter Fluid Seal Disassemble




Fluid Filter Assembly and Torque Converter Fluid Seal Disassemble

Callout	Component Name
1	<p>Fluid Filter Assembly</p> <p>Tip Rotate filter 90 degrees to disengage locking tangs.</p>
2	Torque Converter Fluid Seal Retainer
3	<p>Torque Converter Fluid Seal</p> <p>Special Tools</p> <ul style="list-style-type: none"> • J6125-B Slide Hammer

© 2010 General Motors Corporation. All rights reserved.

	<ul style="list-style-type: none"> J23129 Universal Seal Remover
4	Torque Converter Fluid Seal Assembly
	Special Tools <ul style="list-style-type: none"> J6125-B Slide Hammer J23129 Universal Seal Remover

Fluid Pump Disassemble




Fluid Pump Disassemble

Callout	Component Name
Warning: Valve springs can be tightly compressed. Use care when removing retainers and plugs. Personal injury could result.	
Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.	
Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.	
Preliminary Procedure	

Clean and inspect all valve components and the pump body for wear and/or damage.	
1	Fluid Pump Cover Bolts M6 x 25 (Qty: 23) Tip There are 3 bolts on the pump cover side and 20 bolts on the pump body side.
2	Fluid Pump Cover
3	Fluid Pump Driven Gear
4	Fluid Pump Drive Gear
5	TCC Control Valve Train
6	Fluid Pump Blow Off Ball Valve Train
7	Pressure Regulator Valve Train
8	TCC Blow Off Ball Valve Train

Fluid Pump Selective Measurement



 **Callout** **Component Name**


Callout	Component Name
1	<p>A/Trans Fluid Pump Body</p> <p>Tip Measure the distance from the bottom of the gage bar to the bottom of the pump rotor cavity. Refer to Fluid Pump Selective Specifications.</p> <p>Special Tool</p> <p>J 34673 Flat Gage Bar or equivalent</p>
2	<p>A/Trans Fluid Pump Driven Gear</p> <p>Tip Refer to Fluid Pump Selective Specifications to select the correct gear.</p>
3	<p>A/Trans Fluid Pump Drive Gear</p> <p>Tip Refer to Fluid Pump Selective Specifications to select the correct gear.</p>

Transmission Fluid Pump Assemble

Table 1: [Fluid Pump with Valve Trains Assemble](#)

Table 2: [Torque Converter Fluid Seal and Fluid Filter Assembly Assemble](#)

Fluid Pump with Valve Trains Assemble




Fluid Pump with Valve Trains Assemble

Callout	Component Name
1	TCC Blow Off Ball Valve Train
2	Pressure Regulator Valve Train
3	Fluid Pump Blow Off Ball Valve Train
4	TCC Control Valve Train
5	Fluid Pump Drive Gear Tip The chamfer on the drive gear teeth face towards the pump body.
6	Fluid Pump Driven Gear Tip The chamfer on the driven gear OD faces the pump body.

© 2010 General Motors Corporation. All rights reserved.

7	Fluid Pump Cover
	Fluid Pump Cover Bolt M6 x 25 (Qty: 23)
8	<p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 12 N·m (106 lb in)</p>

Torque Converter Fluid Seal and Fluid Filter Assembly Assemble




Torque Converter Fluid Seal and Fluid Filter Assembly Assemble

Callout	Component Name
1	<p>Torque Converter Fluid Seal Assembly</p> <p>Tip The fluid seal assembly must be staked in place using <i>DT-49131</i> tool to ensure proper seal retention.</p> <p>Special Tools</p> <ul style="list-style-type: none"> • <i>DT-47792</i> Seal Installer • <i>DT-49131</i> Seal Staking Tool
	Torque Converter Fluid Seal

Special Tools	
2	<i>DT-47791 Seal Installer</i>
3	Torque Converter Fluid Seal Retainer
4	Fluid Filter Assembly Tip Rotate filter 90 degrees to engage locking tangs.

Transmission Fluid Pump, Front Differential Carrier Baffle, and Front Differential Ring Gear Installation




Callout	Component Name
1	Torque Converter and Differential Housing Seal
2	Fluid Pump Assembly
3	Fluid Pump Bolt M8 x 33 (Qty: 8) Caution: Refer to Fastener Caution in the Preface section. Tighten 10 N·m (89 lb in) then rotate the bolt an additional 45 degrees.
4	Front Differential Ring Gear
5	Front Differential Ring Gear Retainer Tip Install the retainer with the taper facing away from the ring gear.

© 2010 General Motors Corporation. All rights reserved.

6	Front Differential Carrier Baffle
	Front Differential Carrier Baffle Bolt M6 x 25 (Qty: 2)
7	Tighten 12 N·m (106.21 lb in)

Torque Converter Housing with Fluid Pump Assembly Installation




Callout	Component Name
1	Fluid Pump Seal Assembly
2	Torque Converter Housing Gasket
3	Torque Converter (with Fluid Pump) Housing Assembly Tip Rotate the differential slightly in each direction using <i>DT-47793</i> tool to align the differential pinion gears with the differential ring gear in the torque converter housing.
	Special Tools <i>DT-47793</i> Differential Rotating Tool
	Torque Converter and Differential Housing Bolt M8 x 30 (Qty: 15) Caution: Refer to Fastener Caution in the Preface section.
	Procedure

© 2010 General Motors Corporation. All rights reserved.


	Tighten the bolts in sequence.
4	Tighten 10 N·m (89 lb in) then rotate bolt an additional 50 degrees.
	Special Tools
	<i>J-45059</i> Angle Meter or equivalent

Input and Output Speed Sensor Installation




Callout	Component Name
1	Input Speed Sensor Assembly Seals
2	Input Speed Sensor Assembly
3	Input Speed Sensor Bolt M6 x 23 (Qty: 1) Caution: Refer to Fastener Caution in the Preface section. Tighten 12 N·m (106 lb in)
4	A/Trans Output Speed Sensor Assembly
5	A/Trans Output Speed Sensor Bolt Tighten 12 N·m (106 lb in)

Control Valve Body Assembly Disassemble



Callout	Component Name
1	Control Solenoid Valve Support
2	Control Valve Body Bolt M5 x 40.5 (Qty: 1)
3	Valve Channel Plate Tip Inspect the channel plate bolt pass through holes for damage or burnelling. Any damage could cause leaking. Replace as necessary.
4	Control Valve Channel Plate Spacer Plate Assembly
5	Valve Body Ball Check Valves (Qty: 6)

Control Valve Body Cleaning and Inspection




Callout	Component Name
Warning: Valve springs can be tightly compressed. Use care when removing retainers and plugs. Personal injury could result.	
Caution: After cleaning the transmission components, allow to air dry. Do not use cloth or paper towels in order to dry any transmission components. Lint from the towels can cause component failure.	
Caution: Do not reuse cleaning solvents. Previously used solvents may deposit sediment which may damage the component.	
<h3>Preliminary Procedure</h3> <p>Clean and inspect all valve components and the valve body. The control valve body assembly is only replaceable as an assembly.</p>	
1	First-Reverse and 4-5-6 Clutch Regulator Valve Train
2	1-2-3-4 Clutch Boost Valve Train
3	1-2-3-4 Clutch Regulator Valve Train
4	2-6 Clutch Regulator ValveTrain
5	3-5 Reverse Clutch Regulator Valve Train

© 2010 General Motors Corporation. All rights reserved.


6	Clutch Piston Dam Feed Regulator Valve Train
7	TCC Regulator Apply Valve Train
8	Clutch Select Valve Train
9	Actuator Feed Limit Valve Train
10	Manual Valve

Control Valve Channel Plate Cleaning and Inspection




Callout	Component Name
1	Channel Plate to Valve Body Spacer Plate Assembly
2	Valve Channel Plate
3	Control Valve Body Guide Pins

Control Valve Body Assembly Assemble



Callout	Component Name
1	Valve Body Ball Check Valve (Qty: 6)
2	Control Valve Channel Plate Spacer Plate Assembly
3	Valve Channel Plate Tip Inspect the channel plate bolt pass through holes for damage or burnelling. Any damage could cause leaking. Replace as necessary.
4	Control Valve Body Bolt M5 x 40.5 (Qty: 1) Caution: Refer to Fastener Caution in the Preface section. Tighten 8 N·m (71 lb in)
5	Control Solenoid Valve Support

Control Valve Body Assembly Installation




Callout	Component Name
1	Low and Reverse Clutch Fluid Passage Seal
2	1-2-3-4 Clutch Fluid Passage Seal
3	Control Valve Body Spacer Plate Assembly
4	Control Valve Body Assembly
5	Control Valve Body Bolt M6 x 60 (Qty: 9) Caution: Refer to Fastener Caution in the Preface section. Tighten 12 N·m (106 lb in)
6	Control Valve Body Bolt M6 x 53 (Qty: 2) Tighten 12 N·m (106 lb in)
7	Manual Shaft Detent Lever Spring Assembly
8	Manual Shaft Detent Spring Bolt M6 x 16 (Qty: 1) Tighten

© 2010 General Motors Corporation. All rights reserved.

	12 N·m (106 lb in)
9	Fluid Level Control Valve Gasket
10	Fluid Level Control Valve


Control Solenoid Valve and Transmission Control Module Assembly Installation



Callout	Component Name
1	<p>Control Solenoid Valve Assembly Filter Plate</p> <p>Caution: Use care when removing or installing the filter plate assembly. A broken or missing retaining tab may not adequately secure the filter plate to the control solenoid valve assembly, resulting in possible damage or contamination.</p> <p>Tip Install a NEW filter plate to prevent fluid leaks past the fluid seals.</p>
2	Control Solenoid (w/Body and TCM) Valve Assembly
3	<p>Control Valve Body Bolt M5 x 40.5 (Qty: 3)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 8 N·m (71 lb in)</p>
4	<p>Control Valve Body Bolt M6 x 97 (Qty: 12)</p> <p>Tighten</p>


	12 N·m (106 lb in)	
--	--------------------	--

Control Valve Body Cover Installation




Callout	Component Name
1	Input Speed Sensor Connector
2	Output Speed Sensor Connector
3	Shift Position Switch Connector
4	Control Valve Body Cover Wiring Connector Hole Seal
5	Tip Do not re-use the valve body cover wiring connector hole seal.
	Control Valve Body Cover Gasket
6	Tip Do not re-use the valve body cover gasket.
	Control Valve Body Cover
7	Control Valve Body Cover Bolts M6 x 30 (Qty: 13)
	Caution: Refer to Fastener Caution in the Preface section. Tighten 12 N·m (106 lb in)

Torque Converter Installation



Callout	Component Name
1	<p>Torque Converter Assembly</p> <p>Tip Failure to lower the torque converter straight down could damage the torque converter clutch lip seal inside the torque converter clutch assembly.</p> <p>Special Tools</p> <p><i>J-46409</i> Torque Converter Lifting Handles</p>
2	<p><i>J-21366</i> Converter Holding Strap</p> <p>Warning: The torque converter must be held to the torque converter housing by a retaining device such as shipping brackets. Without the retaining device, the torque converter may slide forward, disengaging the oil pump, or may fall completely out of the transmission causing personal injury and/or property damage.</p>

Lift Plate and Holding Fixture Removal



Callout	Component Name
1	<p><i>J-46625 Transmission Holding Fixture</i></p> <p>Tip Raise the transmission in order to remove the holding fixture.</p>
2	<p><i>DT-47811-A Transmission Lift Plate</i></p> <p>Tip Lower the transmission assembly onto the transmission jack in order to remove the lift plate.</p>