

## Wheel and Tire

Base Part Number: 1007

### Special Tool(s) / General Equipment

Wooden Block

### DISASSEMBLY

**NOTICE:** Failure to follow the instructions below may result in damage to the TPMS.

**NOTICE:** The TPMS sensor is mounted to the valve stem. Removal of the valve stem requires dismounting the tire from the wheel and removal of the TPMS sensor.

**NOTE:** Use only the Digital Tire Pressure Gauge any time tire pressures are measured to be sure that accurate values are obtained.

1. Remove the wheel and tire.  
Refer to: [Wheel and Tire](#) (204-04A Wheels and Tires, Removal and Installation).
2. **NOTICE:** The valve stem is connected to the TPMS sensor. Do not pull the valve stem from the wheel, or damage to the sensor will occur.

**NOTE:** If a new TPMS sensor is being installed, remove and discard the valve stem-to-sensor screw and the sensor.

Remove the valve stem core and fully deflate all air from the tire.


3. **NOTICE:** Do not allow the tire beads to move beyond the wheel mid-plane (middle of the wheel) when separating the beads from the wheels, damage to the TPMS sensor may occur.

**NOTICE:** Tire and valve stem position is critical to prevent damage to the TPMS sensor when using a paddle-type bead separator.

**NOTE:** Some machines may have a nylon roller bead separator at the 12 o'clock position instead of the paddle-type bead separator at the 3 o'clock position.

- For a paddle-type tire machine, position the valve stem at the 12 o'clock or 6 o'clock position and the paddle at the 3 o'clock position.
- For a roller-type tire machine, align the valve stem with the roller at any position.


**NOTE:** Paddle type shown, roller type similar.




4. **NOTE:** Index-mark the valve stem and wheel weight positions on the tire.

Place the wheel and tire assembly on the turntable of the tire machine with the valve stem at the 11:30 position and the machine arm at the 12 o'clock position and dismount the outer bead from the wheel.






5. Reset the wheel and tire assembly on the turntable of the tire machine with the valve stem at the 11:30 position and the machine arm at the 12 o'clock position and dismount the inner bead from the wheel.
6. **NOTE:** *A new valve stem must be installed whenever a new tire or wheel is installed.*
  1. Remove and discard the TPMS sensor-to-valve stem screw.
  2. Separate the TPMS sensor from the valve stem.



**7. NOTICE: Use care not to damage the wheel surface when removing the valve stem.**

Using a suitable valve stem remover/installer, remove and discard the valve stem.  
Use the General Equipment: Wooden Block




**NOTE:** When installing a new wheel, always install a new valve stem and sensor screw. Reuse the TPMS sensor from the previous wheel if possible. The TPMS will not have to be trained if the sensor is reused.

**NOTE:** If the TPMS sensor is being reused, inspect the TPMS sensor for damage and install a new sensor as necessary.

8. **NOTICE:** To prevent TPMS sensor and valve stem damage, the valve stem must be installed onto the TPMS sensor and then installed into the wheel as an assembly.

Position the new valve stem onto the TPMS sensor and install the new screw.  
*Torque: 13 lb.in (1.5 Nm)*



## ASSEMBLY


**NOTICE:** Damage to the TPMS sensor may result if the tire mounting is not carried out as instructed.

1. **NOTICE:** It is important to pull the valve stem and TPMS sensor assembly through the wheel rim hole in a direction parallel to the valve stem hole axis. If the assembly is pulled through at an angle, damage to the valve stem and sensor assembly may occur.

**NOTICE:** Use care not to damage the wheel surface when installing the valve stem and TPMS sensor assembly.

**NOTE:** Lubricate the valve stem with soapy water and install the valve stem and TPMS sensor assembly into the wheel using a block of wood and a suitable valve stem installer.

Using a suitable valve stem installer, install the new valve stem and TPMS sensor assembly.  
Use the General Equipment: Wooden Block




2. **NOTE:** Lubricate the tire beads using a suitable fast-drying, corrosion-inhibiting tire bead lubricant.

**NOTE:** Do not mount the tire at this time.

Position the wheel on the turntable of the tire machine, then lubricate and position the bottom bead of the tire on the wheel.

3. Position the wheel to align the valve stem with the machine arm, at the 6 o'clock position, and mount the bottom bead of the tire.



4. Reposition the wheel to align the valve stem with the machine arm at the 6 o'clock position, and mount the top bead of the tire.

5. **NOTE:** Use only the Digital Tire Pressure Gauge any time tire pressures are measured to be sure that accurate values are obtained.

Inflate the tire to the pressure specified on the VC label located on the driver door or door pillar.

**NOTE:** Proceed to the next step if the tire beads do not seat at the specified inflation pressure.

6.  **WARNING: If there is a need to exceed the maximum pressure indicated on the sidewall of the tire in order to seat the beads, follow all steps listed below. Failure to follow these steps may result in serious personal injury.**

**NOTICE: The following steps should only be carried out if the tire beads cannot be seated by inflating the tire up to the maximum inflation pressure listed on the tire sidewall.**

1. Relubricate the tire bead and wheel bead seat area.
2. Install a remote valve and pressure gauge.
3. Wear eye and ear protection and stand at a minimum of 3.65 m (12 ft) away from the wheel and tire assembly.
4. Inflate the tire using the remote valve and tire gauge until the beads have seated or until the pressure gauge is 138 kPa (20 psi) more than maximum inflation pressure on tire sidewall. If beads have not seated, deflate the tire and proceed to the next step.
5. Place the wheel and tire assembly in an OSHA-approved tire safety cage.
6. Inflate the tire using the remote valve and pressure gauge until the beads have seated or until the pressure gauge is 276 kPa (40 psi) more than maximum inflation pressure on the tire sidewall. **Do not exceed 276 kPa (40 psi) above the maximum pressure on tire sidewall. Install a new tire if the beads do not seat at this pressure.**

7. Install the wheel and tire.

Refer to: [Wheel and Tire](#) (204-04A Wheels and Tires, Removal and Installation).

Copyright © 2019 Ford Motor Company

---