

**Communications Network****DTC Chart: Gateway Module (GWM)**

Diagnostics in this manual assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: [Diagnostic Methods](#) (100-00 General Information, Description and Operation).

| DTC      | Description   | Action  |
|----------|---|---|
| U2100:00 | Initial Configuration Not Complete: No Sub Type Information | CHECK the vehicle service history for recent service actions related to this module. This <u>DTC</u> sets due to incomplete or incorrect <u>PMI</u> procedures. INSTALL As-Built data from Professional Technician Society (PTS) following diagnostic scan tool instructions under Module Programming>As-Built. |
| U3000:44 | Control Module: Data Memory Failure                         | <a href="#">GO to Pinpoint Test AD</a>  |
| U3000:45 | Control Module: Program Memory Failure                      | <a href="#">GO to Pinpoint Test AD</a>  |
| U3000:46 | Control Module: Calibration/Parameter Memory Failure        | <a href="#">GO to Pinpoint Test AD</a>  |
| U3000:47 | Control Module: Watchdog/Safety µC Failure                  | <a href="#">GO to Pinpoint Test AD</a>  |
| U3000:49 | Control Module: Internal Electronic Failure                 | <a href="#">GO to Pinpoint Test AD</a>  |

**Symptom Chart(s)****Symptom Chart: Communication Network**

Diagnostics in this manual assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: [Diagnostic Methods](#) (100-00 General Information, Description and Operation).

**Symptom Chart**

| Condition  | Possible Sources           | Actions                                |
|--|----------------------------|--|
| The vehicle does not start with the diagnostic scan tool connected to the <u>DLC</u> and/or multiple malfunction indicators are only on when the diagnostic scan tool is connected to the <u>DLC</u> | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test AC</a> |

|   |                            |  |
|---|----------------------------|--|
| No <u>HS-CAN1</u> communication, all modules are not responding                               | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test X</a>  |
| No <u>HS-CAN2</u> communication, all modules are not responding                               | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test Y</a>  |
| No <u>HS-CAN3</u> communication, all modules are not responding                               | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test Z</a>  |
| No <u>HS-CAN4</u> communication, all modules are not responding                               | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test AA</a> |
| No <u>MS-CAN</u> communication, all modules are not responding                                | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test AB</a> |
| The <u>PCM</u> does not respond to the diagnostic scan tool                                   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test A</a>  |
| The <u>ABS</u> module does not respond to the diagnostic scan tool                            | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test B</a>  |
| The <u>RCM</u> does not respond to the diagnostic scan tool                                   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test C</a>  |
| The <u>BECMB</u> does not respond to the diagnostic scan tool                                 | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test D</a>  |
| The <u>OCSM</u> does not respond to the diagnostic scan tool                                  | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test E</a>  |
| The <u>SCCM</u> does not respond to the diagnostic scan tool                                  | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test F</a>  |
| The <u>IPC</u> does not respond to the diagnostic scan tool                                   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test G</a>  |
| The <u>BCM</u> does not respond to the diagnostic scan tool                                   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test H</a>  |
| The <u>PAM</u> does not respond to the diagnostic scan tool (integrated with the <u>BCM</u> ) | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test H</a>  |
| The <u>FCIM</u> module does not respond to the diagnostic scan tool                           | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test I</a>  |
| The <u>ACM</u> does not respond to the diagnostic scan tool                                   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test J</a>  |
| The <u>IPMA</u> does not respond to the diagnostic scan tool                                  | Refer to the               | <a href="#">GO to</a>                  |

|  |                            |  |
|--|----------------------------|--|
|  | Pinpoint Test              | <a href="#">Pinpoint Test K</a>        |
| The <u>APIM</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test L</a>  |
| The <u>DSP</u> does not respond to the diagnostic scan tool        | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test M</a>  |
| The <u>TCU</u> does not respond to the diagnostic scan tool        | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test N</a>  |
| The <u>RTM</u> does not respond to the diagnostic scan tool        | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test O</a>  |
| The <u>PSCM</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test P</a>  |
| The <u>SODL</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test Q</a>  |
| The <u>SODR</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test R</a>  |
| The <u>HUD</u> module does not respond to the diagnostic scan tool | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test S</a>  |
| The <u>TRM</u> does not respond to the diagnostic scan tool        | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test T</a>  |
| The <u>ATCM</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test U</a>  |
| The <u>DCDC</u> does not respond to the diagnostic scan tool       | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test V</a>  |
| The <u>GWM</u> does not respond to the diagnostic scan tool        | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test W</a>  |
| No power to the <u>DLC</u>   | Refer to the Pinpoint Test | <a href="#">GO to Pinpoint Test AC</a> |

## Pinpoint Tests

### ► [PINPOINT TEST A : THE POWERTRAIN CONTROL MODULE \(PCM\) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL](#)

- ▶ PINPOINT TEST B : THE ANTI-LOCK BRAKE SYSTEM (ABS) MODULE DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST C : THE RESTRAINTS CONTROL MODULE (RCM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST D : THE BECMB (EXTENDED POWER MODULE) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST E : THE OCCUPANT CLASSIFICATION SYSTEM MODULE (OCSM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST F : THE STEERING COLUMN CONTROL MODULE (SCCM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST G : THE INSTRUMENT PANEL CLUSTER (IPC) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST H : THE BODY CONTROL MODULE (BCM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST I : THE FRONT CONTROLS INTERFACE MODULE (FCIM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST J : THE AUDIO CONTROL MODULE (ACM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST K : THE IMAGE PROCESSING MODULE A (IPMA) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST L : THE ACCESSORY PROTOCOL INTERFACE MODULE (APIM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST M : THE AUDIO DIGITAL SIGNAL PROCESSING (DSP) MODULE DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST N : THE TELEMATIC CONTROL UNIT MODULE (TCU) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST O : THE RADIO TRANSCEIVER MODULE (RTM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST P : THE POWER STEERING CONTROL MODULE (PSCM) DOES NOT RESPOND

## TO THE DIAGNOSTIC SCAN TOOL

- ▶ PINPOINT TEST Q : THE SIDE OBSTACLE DETECTION CONTROL MODULE LH (SOD-L) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST R : THE SIDE OBSTACLE DETECTION CONTROL MODULE RH (SOD-R) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST S : THE HEAD UP DISPLAY (HUD) MODULE DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST T : THE TRM (TRAILER MODULE) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST U : THE ALL TERRAIN CONTROL MODULE (ATCM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST V : THE DIRECT CURRENT/DIRECT CURRENT (DC/DC) CONVERTER CONTROL MODULE (VOLTAGE QUALITY MODULE) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST W : THE GATEWAY MODULE (GWM) DOES NOT RESPOND TO THE DIAGNOSTIC SCAN TOOL
- ▶ PINPOINT TEST X : NO HIGH SPEED CONTROLLER AREA NETWORK 1 (HS-CAN1) COMMUNICATION, ALL MODULES ARE NOT RESPONDING
- ▶ PINPOINT TEST Y : NO HIGH SPEED CONTROLLER AREA NETWORK 2 (HS-CAN2) COMMUNICATION, ALL MODULES ARE NOT RESPONDING
- ▶ PINPOINT TEST Z : NO HIGH SPEED CONTROLLER AREA NETWORK 3 (HS-CAN3) COMMUNICATION, ALL MODULES ARE NOT RESPONDING
- ▶ PINPOINT TEST AA : NO HIGH SPEED CONTROLLER AREA NETWORK 4 (HS-CAN4) COMMUNICATION, ALL MODULES ARE NOT RESPONDING
- ▶ PINPOINT TEST AB : NO MEDIUM SPEED CONTROLLER AREA NETWORK (MS-CAN) COMMUNICATION, ALL MODULES ARE NOT RESPONDING
- ▶ PINPOINT TEST AC : NO POWER TO THE DATA LINK CONNECTOR (DLC)
- ▶ PINPOINT TEST AD : U3000:44 ,U3000:45, U3000:46, U3000:47 OR U3000:49

