

ELECTRICAL SYSTEM

SECTION EL

CONTENTS

PRECAUTIONS	5	Schematic	54	MT
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	Wiring Diagram - DTRL -	55	
Precautions for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service	5	CONSULT-II Inspection Procedure	60	
Precautions for Trouble Diagnosis	5	CONSULT-II Application Items	60	AT
Precautions for Harness Repair	6	Trouble Diagnoses	60	
Wiring Diagrams and Trouble Diagnosis	6	Bulb Replacement	65	
HARNESS CONNECTOR	7	Aiming Adjustment	65	TF
Description	7	PARKING, LICENSE AND TAIL LAMPS	66	
STANDARDIZED RELAY	9	System Description	66	PD
Description	9	Schematic	68	
POWER SUPPLY ROUTING	11	Wiring Diagram - TAIL/L -	69	
Schematic	11	CONSULT-II Inspection Procedure	73	AX
Wiring Diagram - POWER -	12	CONSULT-II Application Items	74	
Inspection	18	Trouble Diagnoses	74	
GROUND	19	STOP LAMP	76	SU
Ground Distribution	19	Wiring Diagram - STOP/L -	76	
COMBINATION SWITCH	32	BACK-UP LAMP	78	BR
Check	32	Wiring Diagram - BACK/L -	78	
Replacement	33	FRONT FOG LAMP	79	
STEERING SWITCH	34	System Description	79	ST
Check	34	Wiring Diagram - F/FOG -	80	
HEADLAMP (FOR USA)	35	Aiming Adjustment	82	
Component Parts and Harness Connector		TURN SIGNAL AND HAZARD WARNING LAMPS	83	RS
Location	35	System Description	83	
System Description	35	Wiring Diagram - TURN -	85	BT
Schematic	38	Trouble Diagnoses	87	
Wiring Diagram - H/LAMP -	39	Electrical Components Inspection	87	
CONSULT-II Inspection Procedure	43	ILLUMINATION	88	HA
CONSULT-II Application Items	44	System Description	88	
Trouble Diagnoses	44	Schematic	90	
Bulb Replacement	47	Wiring Diagram - ILL -	91	SC
Aiming Adjustment	47	INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS	98	
HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -	50	System Description	98	EL
Component Parts and Harness Connector		Schematic	100	
Location	50	Wiring Diagram - INT/L -	101	
System Description	50	CONSULT-II Inspection Procedure	106	IDX
		CONSULT-II Application Items	107	
		Trouble Diagnoses for Interior Lamp Timer	109	

CONTENTS (Cont'd)

METERS AND GAUGES	124	Wiring Diagram - CLOCK -	191
Component Parts and Harness Connector		REAR WINDOW DEFOGGER	192
Location	124	Component Parts and Harness Connector	
System Description.....	124	Location	192
Combination Meter/With Normal Meter.....	126	System Description.....	192
Combination Meter/With Fine Vision Meter.....	128	Wiring Diagram - DEF -	194
Schematic/With Normal Meter.....	130	CONSULT-II Inspection Procedure.....	198
Schematic/With Fine Vision Meter	131	CONSULT-II Application Items	199
Wiring Diagram - METER -	132	Trouble Diagnoses.....	200
Meter/Gauge Operation and Odo/Trip Meter		Electrical Components Inspection	203
Segment Check in Diagnosis Mode.....	133	Filament Check.....	204
Trouble Diagnoses.....	134	Filament Repair	205
Electrical Components Inspection	140	AUDIO	206
COMPASS AND THERMOMETER	141	System Description.....	206
System Description.....	141	Wiring Diagram - AUDIO -/Base System	207
Wiring Diagram - COMPAS -	142	Schematic/BOSE System.....	209
Trouble Diagnoses.....	143	Wiring Diagram - AUDIO -/BOSE System.....	210
Calibration Procedure for Compass	144	Trouble Diagnoses.....	215
WARNING LAMPS	145	Inspection.....	216
Schematic/With Normal Meter.....	145	Audio Unit Removal and Installation	216
Wiring Diagram - WARN -/With Normal Meter.....	146	Wiring Diagram - REMOTE -	217
Schematic/With Fine Vision Meter	154	AUDIO ANTENNA	218
Wiring Diagram - WARN -/With Fine Vision Meter	155	System Description.....	218
Fuel Warning Lamp Sensor Check	163	Wiring Diagram - P/ANT -	219
Electrical Components Inspection	163	Trouble Diagnoses.....	220
WARNING CHIME	164	Location of Antenna.....	220
Component Parts and Harness Connector		Antenna Rod Replacement	220
Location	164	POWER SUNROOF	222
System Description.....	164	System Description.....	222
Wiring Diagram - CHIME -	166	Wiring Diagram - SROOF -	223
CONSULT-II Inspection Procedure.....	168	CONSULT-II Inspection Procedure.....	225
CONSULT-II Application Items	169	CONSULT-II Application Items	226
Trouble Diagnoses.....	170	Trouble Diagnoses.....	226
FRONT WIPER AND WASHER	178	DOOR MIRROR	228
System Description.....	178	Wiring Diagram - MIRROR -	228
Wiring Diagram - WIPER -	180	GLASS HATCH OPENER	229
Removal and Installation	181	Wiring Diagram - T&FLID -	229
Washer Nozzle Adjustment	182	POWER SEAT	230
Washer Tube Layout	182	Wiring Diagram - SEAT -	230
REAR WIPER AND WASHER	183	HEATED SEAT	232
System Description.....	183	Wiring Diagram - HSEAT -	232
Wiring Diagram - WIP/R -	185	Seatback Heating Unit.....	235
Trouble Diagnoses.....	187	AUTOMATIC DRIVE POSITIONER	236
Removal and Installation	187	Component Parts and Harness Connector	
Washer Nozzle Adjustment	188	Location	236
Washer Tube Layout	188	System Description.....	237
Check Valve.....	188	Schematic	240
HORN	189	Wiring Diagram - AUT/DP -	241
Wiring Diagram - HORN -	189	On Board Diagnosis	246
CIGARETTE LIGHTER	190	Trouble Diagnoses.....	248
Wiring Diagram - CIGAR -	190	AUTOMATIC SPEED CONTROL DEVICE (ASCD) ...	271
CLOCK	191	System Description.....	271

CONTENTS (Cont'd)

POWER WINDOW	272	CONSULT-II	392	GI
System Description	272	Trouble Diagnoses	395	MA
Schematic	275	How to Replace NVIS (NATS) IMMU	408	
Wiring Diagram - WINDOW -	276	CAN COMMUNICATION	409	EM
CONSULT-II Inspection Procedure	281	System Description	409	
CONSULT-II Application Items	282	CAN Communication Unit	409	LC
Trouble Diagnoses	282	CAN SYSTEM (TYPE 1)	414	
POWER DOOR LOCK	291	Component Parts and Harness Connector		EC
Component Parts and Harness Connector		Location	414	
Location	291	System Description	414	FE
System Description	291	Wiring Diagram - CAN -	415	
Schematic	292	Trouble Diagnoses	417	FE
Wiring Diagram - D/LOCK -	293	Component Inspection	437	
CONSULT-II Inspection Procedure	299	CAN SYSTEM (TYPE 2)	438	CL
CONSULT-II Application Items	300	Component Parts and Harness Connector		
Trouble Diagnoses	301	Location	438	CL
REMOTE KEYLESS ENTRY SYSTEM	314	System Description	438	MT
Component Parts and Harness Connector		Wiring Diagram - CAN -	439	
Location	314	Trouble Diagnoses	441	AT
System Description	314	Component Inspection	459	
Schematic	318	CAN SYSTEM (TYPE 3)	460	AT
Wiring Diagram - KEYLESS -	319	Component Parts and Harness Connector		
CONSULT-II Inspection Procedure	323	Location	460	TF
CONSULT-II Application Items	324	System Description	460	
Trouble Diagnoses	325	Wiring Diagram - CAN -	461	PD
ID Code Entry Procedure	338	Trouble Diagnoses	462	
Keyfob Battery Replacement	342	Component Inspection	472	PD
VEHICLE SECURITY (THEFT WARNING)		CAN SYSTEM (TYPE 4)	473	AX
SYSTEM	343	Component Parts and Harness Connector		
Component Parts and Harness Connector		Location	473	AX
Location	343	System Description	473	SU
System Description	344	Wiring Diagram - CAN -	474	
Schematic	348	Trouble Diagnoses	475	BR
Wiring Diagram - VEHSEC -	350	Component Inspection	478	
CONSULT-II Inspection Procedure	356	ELECTRICAL UNITS LOCATION	479	ST
CONSULT-II Application Item	357	Engine Compartment	479	
Trouble Diagnoses	358	Passenger Compartment	480	ST
SMART ENTRANCE CONTROL UNIT	376	HARNES LAYOUT	482	RS
Description	376	How to Read Harness Layout	482	
CONSULT-II	378	Outline	483	RS
Schematic	380	Main Harness	484	BT
Smart Entrance Control Unit Inspection Table	382	Engine Room Harness	486	
HOMELINK UNIVERSAL TRANSCEIVER	385	Engine Control Harness	488	BT
Wiring Diagram - TRNSCV -	385	Body Harness LH	490	HA
Trouble Diagnoses	386	Body Harness RH	491	
NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM		Back Door Harness	492	HA
- NATS)	389	Engine and Transmission Harness	493	SC
Component Parts and Harness Connector		Room Lamp Harness	494	
Location	389	Air Bag Harness	495	SC
System Description	390	Front Door Harness	496	EL
System Composition	390	Rear Door Harness	497	
Wiring Diagram - NATS -	391	BULB SPECIFICATIONS	498	EL

CONTENTS (Cont'd)

Headlamp.....	498	Interior Lamp.....	498
Exterior Lamp	498	WIRING DIAGRAM CODES (CELL CODES).....	499

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NAEL0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS composition which is available to NISSAN MODEL R50 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of side air bag module (located in the outer side of front seat), side curtain air bag module (located in the headliner side of front and rear seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connector (and by yellow harness protector or yellow insulation tape before the harness connectors).

Precautions for SRS "AIR BAG" and "SEAT BELT PRE-TENSIONER" Service

NAEL0485

- Do not use electrical test equipment to check SRS circuits unless instructed to in this Service Manual.
- Before servicing the SRS, turn ignition switch "OFF", disconnect battery ground cable and wait at least 3 minutes.
For approximately 3 minutes after the cables are removed, it is still possible for the air bag and seat belt pre-tensioner to deploy. Therefore, do not work on any SRS connectors or wires until at least 3 minutes have passed.
- Diagnosis sensor unit must always be installed with their arrow marks "⇐" pointing towards the front of the vehicle for proper operation. Also check diagnosis sensor unit for cracks, deformities or rust before installation and replace as required.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place driver and passenger air bag modules with the pad side facing upward and side air bag module standing with the stud bolt side setting bottom.
- Conduct self-diagnosis to check entire SRS for proper function after replacing any components.
- After air bag inflates, the front instrument panel assembly should be replaced if damaged.

Precautions for Trouble Diagnosis CAN SYSTEM

NAEL0458

NAEL0458S01

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

PRECAUTIONS

Precautions for Harness Repair



Precautions for Harness Repair

NAEL0459

CAN SYSTEM

NAEL0459S01

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]
- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)

Wiring Diagrams and Trouble Diagnosis

NAEL0002

When you read wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS"
- EL-11, "POWER SUPPLY ROUTING" for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- GI-35, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"
- GI-24, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

Check for any Service bulletins before servicing the vehicle.

HARNESS CONNECTOR

Description

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

GI

NAEL0003

NAEL0003S01

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HARNESS CONNECTOR

Description (Cont'd)

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


=NAEL0003S02

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



SEL769V

STANDARDIZED RELAY

Description


Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NAEL0004

NAEL0004S01




SEL881H

TYPE OF STANDARDIZED RELAYS

NAEL0004S02

1M	1 Make	2M	2 Make
1T	1 Transfer	1M·1B	1 Make 1 Break



SEL882H

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connector	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GEL264

POWER SUPPLY ROUTING




Wiring Diagram — POWER —

Wiring Diagram — POWER —

BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

NAEL0248

NAEL0248S01




MEL086S


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC



REFER TO THE FOLLOWING.
(E1) -SUPER MULTIPLE JUNCTION (SMJ)



EL
IDX

MEL128S


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-03



REFER TO THE FOLLOWING.



MEL087S



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

NAEL0248S02

EL-POWER-04



REFER TO THE FOLLOWING.



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"



NAEL0248S03

EL-POWER-05



- (A) : With A/T
- (M) : With M/T
- (VD) : With VDC
- (OV) : Without VDC
- *1 OR : (OV)
- G/R : (VD)



- FUSE BLOCK (J/B)
- (M10)
 - (M91)
 - (E2)
 - (E3)
 - (E4)




POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06




REFER TO THE FOLLOWING.



POWER SUPPLY ROUTING

Inspection




Inspection

NAEL0249

FUSE

NAEL0249S01

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for “ELECTRICAL PARTS (BAT)” if vehicle is not used for a long period of time.




FUSIBLE LINK

NAEL0249S02

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



CIRCUIT BREAKER (PTC THERMISTOR TYPE)

NAEL0249S03

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current.

Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.

Ground Distribution

NAEL0250

NAEL0250S01

MAIN HARNESS

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX





Next page




GROUND

Ground Distribution (Cont'd)

A Preceding page



CON-NECTOR NUMBER	CONNECT TO
M15	Combination flasher unit
M23	Power window relay
M36	Rear window defogger switch (Terminal No. 1) (With auto A/C and normal meter, with manual A/C)
M36	Rear window defogger switch (Terminal No. 4) (With auto A/C and normal meter, with manual A/C)
M38	Mode door motor (With auto A/C)
M55	Air mix door motor (With auto A/C)
M42	Recirculation switch (Without auto A/C)
M69	Power antenna
M140	Door mirror remote control switch
M144	Power socket relay
M148	Rear TV switch (Without woody instrument finisher, with rear TV)
D31	Door mirror RH (Door mirror defogger)
Z5	Air bag diagnosis sensor unit



B Next page

MEL092S

GROUND

Ground Distribution (Cont'd)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX


B Preceding page



MEL093S

GROUND


Ground Distribution (Cont'd)



MEL094S

ENGINE ROOM HARNESS

NAEL0250S02



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

MEL129S

IDX

GROUND

Ground Distribution (Cont'd)



MEL095S

GROUND

Ground Distribution (Cont'd)

ENGINE CONTROL HARNESS

NAEL0250S03

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



CON-NECTOR NUMBER	CONNECT TO
F29	Condenser
F30	Ignition coil No. 1
F31	Ignition coil No. 3
F32	Ignition coil No. 5
F118	Ignition coil No. 2
F119	Ignition coil No. 4
F120	Ignition coil No. 6


MEL080Q

GROUND

Ground Distribution (Cont'd)

BODY HARNESS RH


NAEL0250S04



MEL096S

GROUND

Ground Distribution (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

MEL097S

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

GROUND

Ground Distribution (Cont'd)

BODY HARNESS LH

NAEL0250S05




* : This sub-harness is not shown in "Harness Layout", EL section.

MEL098S

GROUND


Ground Distribution (Cont'd)

△ C △ D Preceding page




Back door harness
Back door sub-harness

CON-NECTOR NUMBER	CONNECT TO
D103	Luggage room lamp
D302	High-mounted stop lamp



D201	Back door key cylinder switch
D202	License plate lamp (Without spare tire carrier)
D203	License plate lamp (With spare tire carrier)
D208	Back door switch
D209	Glass hatch switch
D212	Rear wiper motor



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC


EL

MEL911N

IDX

GROUND

Ground Distribution (Cont'd)



CON-NECTOR NUMBER	CONNECT TO
B107	Shield wire (Satellite sensor LH) (With side air bag)


MEL099S

GROUND

Ground Distribution (Cont'd)

BODY HARNESS

=NAEL0250S06



CON-NECTOR NUMBER	CONNECT TO
D304	Rear window defogger

MEL152M

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

COMBINATION SWITCH

Check

Check

NAEL0251



LIGHTING SWITCH

	OFF	AUTO	1ST	2ND
5			<input type="checkbox"/>	<input type="checkbox"/>
11			<input type="checkbox"/>	<input type="checkbox"/>
8				<input type="checkbox"/>
12				<input type="checkbox"/>
42		<input type="checkbox"/>		
(8)		<input type="checkbox"/>		


	A	B	C
(5)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
(8)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
(2)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

FRONT WIPER AND WASHER SWITCH

	LO	AUTO STOP	AMP	WASH	HI	EARTH
OFF	<input type="checkbox"/>					
INT	<input type="checkbox"/>					
LO	<input type="checkbox"/>					
HI	<input type="checkbox"/>					
WASH	<input type="checkbox"/>					

WIPER AMP. terminals: 14, 15, 13, 16, 17, 18

VARIABLE INTERMITTENT WIPER VOLUME



FOG LAMP SWITCH

	OFF	ON
31	<input type="checkbox"/>	<input type="checkbox"/>
32	<input type="checkbox"/>	<input type="checkbox"/>




TURN SIGNAL LAMP SWITCH

	L	N	R
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

REAR WIPER AND WASHER SWITCH

	WASH	OFF	INT	ON	WASH
21	<input type="checkbox"/>				
22	<input type="checkbox"/>				
23	<input type="checkbox"/>				
24	<input type="checkbox"/>				

MEL070Q



Replacement

For removal and installation of spiral cable, refer to RS-19, "Installation — Air Bag Module and Spiral Cable".

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HEADLAMP (FOR USA)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0254



SEL668Y

System Description

NAEL0255

The headlamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. And the headlamp battery saver system is controlled by the smart entrance control unit.

OUTLINE

NAEL0255S01

Power is supplied at all times

- to headlamp LH relay terminals 1 and 3
- through 15A fuse (No. 60, located in the fuse and fusible link box), and
- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When the ignition switch is in the ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)]

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

POWER SUPPLY TO LOW BEAM AND HIGH BEAM

When lighting switch is in 2ND or PASS position, ground is supplied

- to headlamp relay (LH and RH) terminal 2 from smart entrance control unit terminals 21 and 59

NAEL0255S02

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR USA)

System Description (Cont'd)

- through smart entrance control unit terminals 22 and 60,
- from lighting switch terminal 12

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW (“B”) position, power is supplied NAEL0255S03

- from terminal 5 of each headlamp relay
- to terminal 3 of each headlamp

Ground is supplied

- to headlamp LH terminal 2
- through lighting switch terminals 7 and 5
- through body grounds E13 and E41, and
- to headlamp RH terminal 2
- through lighting switch terminal 10 and 8
- through body grounds E13 and E41.

With power and ground supplied, the headlamp(s) will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH (“A”) position or PASS (“C”) position, power is supplied NAEL0255S04

- from terminal 5 of each headlamp relay
- to terminal 3 of each headlamp, and
- to combination meter terminal 26 for the HIGH BEAM indicator.

Ground is supplied

- to headlamp LH terminal 1, and
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 6 and 5
- through body grounds E13 and E41, and
- to headlamp RH terminal 1
- through lighting switch terminals 9 and 8
- through body grounds E13 and E41.

With power and ground supplied, the high beams and the high beam indicator illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

Except for Auto Light Control Operation

Headlamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. NAEL0255S05

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off. NAEL0255S0501

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

Auto light control operation

While the headlamps are turned ON by “AUTO” operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened. NAEL0255S0502

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, and restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.

HEADLAMP (FOR USA)

System Description (Cont'd)

- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps will be turned off. GI
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the saver is discontinued and restarts and lasts for 45 seconds, then the headlamps will be turned off. MA

Exterior lamp battery saver control time can be changed using “WORK SUPPORT” mode in “HEAD-LAMP”. EM

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then, LC
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59, EC
- through smart entrance control unit terminals 22 and 60 and FE
- through lighting switch terminal 12.

Then headlamps illuminate again.

AUTO LIGHT OPERATION

The auto light control system has an auto light sensor inside instrument mask that detects outside brightness. CL

- to smart entrance control unit terminal 23 MT
- from lighting switch terminal 42.

When ignition switch is turned to “ON” or “START” position and

- Outside brightness is darker than prescribed level. AT

After 3 seconds delay, outside brightness becomes darker than prescribed level.

Ground is supplied

- to headlamp relay LH and RH terminals 2 TF
- through smart entrance control unit terminals 21, 59 and 43, 64.

Then both headlamp relays and tail lamp relay are energized, headlamps (low or high) and tail lamps are illuminated according to switch position. PD

Auto light operation allows headlamps and tail lamps to go off when

- Outside brightness is brighter than prescribed level, or AX
- After 5 seconds delay, outside brightness is brighter than prescribed level.
- Ignition switch is turned to “OFF” position. (Headlamp will be turned OFF by exterior lamp battery saver control system. Refer to EL-36.) SU

NOTE:

The delay time changes (maximum of 20 seconds) as the outside brightness changes.

For parking license and tail lamp auto operation, refer to “PARKING, LICENSE AND TAIL LAMPS” (EL-66). BR

VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to “VEHICLE SECURITY (THEFT WARNING) SYSTEM” (EL-346). ST


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR USA)

Schematic

Schematic

NAEL0256







HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP —

Wiring Diagram — H/LAMP —

NAEL0257

EL-H/LAMP-01



REFER TO THE FOLLOWING.

(M10) -FUSE BLOCK-
JUNCTION BOX (J/B)





GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL947P

HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-02



REFER TO THE FOLLOWING.






(E1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL930R

HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-03



REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE JUNCTION (SMJ)







MEL931R

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR USA)


Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-04



REFER TO THE FOLLOWING.
 (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

MEL950P




CONSULT-II Inspection Procedure

NAEL0258


NAEL0258S01

“HEADLAMP”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “HEADLAMP”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR USA)

CONSULT-II Application Items

CONSULT-II Application Items

NAEL0453

NAEL0453S01

NAEL0453S0101

“HEAD LAMP” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
AUTO LIGT SW	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
AUTO LIGT SENS	Displays “Illumination outside of the vehicle (close to 5V when light/close to 0V when dark)” as judged from the auto light sensor signal.
LIGHT SW 1ST	Displays status of the lighting switch as judged from the lighting switch signal. (1ST or 2ND position: ON/Other than 1ST and 2ND position: OFF)
LIGHT SW 2ND	Displays status of the lighting switch as judged from the lighting switch signal. (2ND position: ON/Other than 2ND position: OFF)
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.

Active Test

NAEL0453S0102

Test Item	Description
TAIL LAMP	Tail lamp relay can be operated by on-off operation of the tail lamp.
HEAD LAMP	Headlamp relay can be operated by on-off operation of the headlamp.
AUTO LIGHT	Night time dimming signal can be operated by on-off operation.

Work Support

NAEL0453S0103

Work Item	Description
AUTO LIGHT SET	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● NORMAL/MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two modes. ● MODE 1 (ON)/MODE 2 (OFF)
ILL DELAY SET	Exterior lamp battery saver control time can be changed in this mode. Selects exterior lamp battery saver control time among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/ MODE 5 (90 sec.)/ MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

Trouble Diagnoses

NAEL0260

Symptom	Possible cause	Repair order
Neither headlamp operates.	<ol style="list-style-type: none"> 7.5A fuse Headlamp relay circuit Lighting switch Smart entrance control unit 	<ol style="list-style-type: none"> Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit. Check between smart entrance control unit and headlamp relays (LH and RH). Check Lighting switch. Check smart entrance control unit. (EL-382)

HEADLAMP (FOR USA)

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
Headlamp LH (low and high beam) does not operate, but headlamp RH (low and high beam) does operate.	<ol style="list-style-type: none"> 15A fuse Headlamp LH relay Headlamp LH relay circuit Lighting switch ground circuit 	<ol style="list-style-type: none"> Check 15A fuse (No. 60, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp LH relay. Check headlamp LH relay. Check the following. <ul style="list-style-type: none"> ● Harness between headlamp LH relay and headlamp LH ● Harness between headlamp LH relay and smart entrance control unit Check harness between lighting switch and ground. 	GI MA EM LC
Headlamp RH (low and high beam) does not operate, but headlamp LH (low and high beam) does operate.	<ol style="list-style-type: none"> 15A fuse Headlamp RH relay Headlamp RH relay circuit 	<ol style="list-style-type: none"> Check 15A fuse (No. 59, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp RH relay. Check headlamp RH relay. Check the following. <ul style="list-style-type: none"> ● Harness between headlamp RH relay and headlamp RH ● Harness between headlamp RH relay and smart entrance control unit Check harness between lighting switch and ground. 	EC FE CL
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> Bulb Open in the LH high beam circuit Lighting switch 	<ol style="list-style-type: none"> Check bulb. Check harness between headlamp LH and lighting switch for open circuit. Check lighting switch. 	MT
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> Bulb Open in LH low beam circuit Lighting switch 	<ol style="list-style-type: none"> Check bulb. Check harness between headlamp LH and lighting switch for open circuit. Check lighting switch. 	AT TF
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> Bulb Open in the RH high beam circuit Lighting switch 	<ol style="list-style-type: none"> Check bulb. Check harness between headlamp RH and lighting switch for open circuit. Check lighting switch. 	PD
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> Bulb Open in RH low beam circuit Lighting switch 	<ol style="list-style-type: none"> Check bulb. Check harness between headlamp RH and lighting switch for open circuit. Check lighting switch. 	AX SU
High beam indicator does not work.	<ol style="list-style-type: none"> Bulb Open in high beam circuit 	<ol style="list-style-type: none"> Check bulb in combination meter. Check the following. <ol style="list-style-type: none"> Harness between headlamp LH relay and combination meter for an open circuit Harness between high beam indicator and lighting switch 	BR ST
Battery saver control does not operate properly.	<ol style="list-style-type: none"> Door switch LH or RH circuit Lighting switch circuit Smart entrance control unit 	<ol style="list-style-type: none"> Check the following. <ol style="list-style-type: none"> Harness between smart entrance control unit and LH or RH door switch for open or short circuit. LH or RH door switch ground circuit. LH or RH door switch. Check the following. <ol style="list-style-type: none"> Harness between smart entrance control unit terminals 20 or 58 and lighting switch terminal 11 for open or short circuit Harness between lighting switch terminal 5 and ground Check smart entrance control unit. (EL-382) 	RS BT HA

SC

EL

IDX


HEADLAMP (FOR USA)

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
When outside is dark, neither tail lamp nor headlamp turn on by auto light operation.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Lighting switch "AUTO" check 3. Lighting switch circuit check 4. Lighting switch ground circuit check 5. Auto light sensor check 6. Auto light sensor circuit check 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit. 2. Check lighting switch (AUTO) input signal with "CONSULT-II" in "DATA MONITOR" mode. When lighting switch is in AUTO: AUTO LIGHT SWITCH ON When lighting switch is in OFF: AUTO LIGHT SWITCH OFF 3. Check harness for open or short between smart entrance control unit and lighting switch. 4. Check harness for lighting switch and ground. 5. Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: More than 3V When auto light sensor is not stuck by light: Approx. 0.5V (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 and ground. Refer to smart entrance control unit. (EL-382) 6. Check the following. <ol style="list-style-type: none"> a. Harness for open or short between smart entrance control unit terminal 8 and auto light sensor terminal 1 b. Harness for open or short between smart entrance control unit terminal 7 and auto light sensor terminal 2 c. Harness for open or short between smart entrance control unit terminal 9 and auto light sensor terminal 3
When outside is dark, tail lamp turns on but headlamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. Headlamp and tail lamp should turn on. (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-382)</p>
When outside is dark, headlamp turns on but tail lamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. Headlamp and tail lamp should turn on. (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-382)</p>
Light does not turn off when ignition key switch is turned to "OFF" (exterior lamp battery saver control is canceled).	<ol style="list-style-type: none"> 1. 7.5A fuse 2. IGN switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit. 2. Check harness for open or short between smart entrance control unit and fuse.

Symptom	Possible cause	Repair order
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.	Auto light sensor check	Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: More than 3V When auto light sensor is not stuck by light: Approx. 0.5V (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 (W/G) and ground. Refer to smart entrance control unit. (EL-382)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



SEL107X

Bulb Replacement

NAEL0261

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Disconnect the harness connector from the back side of the bulb.
3. Pull off the rubber cap.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Aiming Adjustment

NAEL0262

Before performing aiming adjustment, check the following.

For details, refer to the regulations in your own country.


- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).

HEADLAMP (FOR USA)


Aiming Adjustment (Cont'd)

LOW BEAM

NAEL0262S01



SEL671Y




MEL222P

1. Remove aiming adjusting screw cap.
 2. Turn headlamp low beam on.
 3. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**

HEADLAMP (FOR USA)

Aiming Adjustment (Cont'd)



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- **Basic illuminating area for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.**


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0263



System Description

NAEL0264

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

And battery saver system is controlled by the smart entrance control unit.

Power is supplied at all times

- to headlamp LH relay terminals 1 and 3
- through 15A fuse (No. 60, located in the fuse and fusible link box), and
- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

Ground is supplied

- to daytime light control unit terminal 16
- through body grounds E13 and E41
- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

When the ignition switch is in the ON or START position, power is also supplied

- to daytime light control unit terminal 3, and
- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

- through 10A fuse [No. 10, located in the fuse block (J/B)].

When the ignition switch is in the START position, power is supplied

- to daytime light control unit terminal 2
- through 7.5A fuse [No. 26, located in the fuse block (J/B)].

HEADLAMP OPERATION

Power Supply to Low Beam and High Beam

NAEL0264S01

When lighting switch is in 2ND or PASS position, ground is supplied

- to headlamp relay (LH and RH) terminal 2 from smart entrance control unit terminals 21 and 59
- through smart entrance control unit terminals 22 and 60
- from lighting switch terminal 12.

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

Low Beam Operation

NAEL0264S0102

When the lighting switch is turned to 2ND and LOW (“B”) positions, ground is supplied

- to terminal 2 of the headlamp LH
- through daytime light control unit terminals 11 and 15
- through lighting switch terminals 7 and 5
- through body grounds E13 and E41.

Ground is also supplied

- to terminal 2 of the headlamp RH
- through daytime light control unit terminals 8 and 12
- through lighting switch terminals 10 and 8
- through body grounds E13 and E41.

With power and ground supplied, the low beam headlamps illuminate.

High Beam Operation/Flash-to-pass Operation

NAEL0264S0103

When the lighting switch is turned to 2ND and HIGH (“A”) or PASS (“C”) positions, ground is supplied

- to terminal 1 of headlamp LH
- through daytime light control unit terminals 10 and 13, and
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 6 and 5
- through body grounds E13 and E41.

Ground is also supplied

- to terminal 1 of headlamp RH
- through daytime light control unit terminals 9 and 14
- through lighting switch terminals 9 and 8
- through body grounds E13 and E41.

With power and ground supplied, the high beam headlamps and HIGH BEAM indicator illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0264S02

Except for Auto Light Control Operation

NAEL0264S0201

Headlamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF.

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

Auto light control operation

NAEL0264S0202

While the headlamps are turned ON by “AUTO” operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the saver is discontinued and restarts and lasts for 45 seconds, then the headlamps will be turned off.

Exterior lamp battery saver control time can be changed using “WORK SUPPORT” mode in “HEAD-LAMP”.

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

AUTO LIGHT OPERATION

NAEL0264S03

For auto light operation, refer to “HEADLAMP” (EL-37).

DAYTIME LIGHT OPERATION

NAEL0264S04

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 7
- to terminal 3 of headlamp RH
- through terminal 1 of headlamp RH
- to daytime light control unit terminal 9
- through daytime light control unit terminal 6
- to terminal 3 of headlamp LH.

Ground is supplied to terminal 1 of headlamp LH.

- through daytime light control unit terminals 10 and 16
- through body grounds E13 and E41.

Because the high beam headlamps are now wired in series, they operate at half illumination.

OPERATION

NAEL0264S05

After starting the engine with the lighting switch in the “OFF” or “1ST” position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
Lighting switch		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
		Headlamp	High beam	X	X	O	X	X	O	O	X	O	△*	△*	O	△*	△*	O	O
Low beam	X		X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

A: "HIGH BEAM" position

B: "LOW BEAM" position

C: "FLASH TO PASS" position

O : Lamp "ON"

X : Lamp "OFF"

△ : Lamp dims. (Added functions)

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Schematic

NAEL0265

Schematic



MEL960R


HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

Wiring Diagram — DTRL —


NAEL0266

EL-DTRL-01



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

M114
W



11	1	2	
3	4	8	10

E8
W

REFER TO THE FOLLOWING.
 (M10), (E3) - FUSE BLOCK-
 JUNCTION BOX (J/B)





GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02





REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL953P

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)



REFER TO THE FOLLOWING.






- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-JUNCTION (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-04











REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

MEL955P

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-05



REFER TO THE FOLLOWING.

(B1) -SUPER
MULTIPLE JUNCTION (SMJ)

MEL956P

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

CONSULT-II Inspection Procedure

CONSULT-II Inspection Procedure

“HEADLAMP”

Refer to “HEADLAMP (FOR USA)” (EL-43).

NAEL0267

NAEL0267S01

CONSULT-II Application Items

“HEADLAMP”

Refer to “HEADLAMP (FOR USA)” (EL-44).

NAEL0268

NAEL0268S01

Trouble Diagnoses

NAEL0269

Symptom	Possible cause	Repair order
Neither headlamp operates.	<ol style="list-style-type: none">1. 7.5A fuse2. Lighting switch3. Daytime light control unit4. Smart entrance control unit	<ol style="list-style-type: none">1. Check the following.<ol style="list-style-type: none">a. 7.5A fuse [No. 24, located in fuse block (J/B)] Verify battery positive voltage is present at terminal 49 of smart entrance control unit.b. 7.5A fuse [No. 11, located in fuse block (J/B)] Verify battery positive voltage is present at terminal 3 of daytime light control unit.2. Check lighting switch.3. Check daytime light control unit (EL-63).4. Check smart entrance control unit. (EL-382)
LH headlamp (low and high beam) does not operate, but RH headlamp (low and high beam) does operate.	<ol style="list-style-type: none">1. 15A fuse2. Headlamp LH relay3. Headlamp LH relay circuit4. Headlamp LH ground circuit5. Lighting switch circuit6. Daytime light control unit7. Smart entrance control unit	<ol style="list-style-type: none">1. Check 15A fuse (No. 60, located in fusible link and fuse box). Verify battery positive voltage is present at terminal 1 and 3 of headlamp LH relay.2. Check headlamp LH relay.3. Check the following.<ol style="list-style-type: none">a. Harness between headlamp LH relay and daytime light control unitb. Harness between headlamp LH relay and smart entrance control unit4. Check harness between headlamp LH and daytime light control unit.5. Check harness between smart entrance control unit and lighting switch.6. Check daytime light control unit. (EL-63)7. Check smart entrance control unit. (EL-382)

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
RH headlamp (low and high beam) does not operate, but LH headlamp (low and high beam) does operate.	<ol style="list-style-type: none"> 15A fuse Headlamp RH relay Headlamp RH relay circuit Headlamp RH ground circuit Lighting switch circuit Daytime light control unit Smart entrance control unit 	<ol style="list-style-type: none"> Check 15A fuse (No. 59, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp RH relay. Check headlamp RH relay. Check the following. <ol style="list-style-type: none"> Harness between headlamp RH relay and daytime light control unit Harness between headlamp RH relay and smart entrance control unit Check harness between headlamp RH and daytime light control unit. Check harness between smart entrance control unit and lighting switch. Check daytime light control unit. (EL-63) Check smart entrance control unit. (EL-382) 	GI MA EM LC EC FE
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> Bulb Headlamp LH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	<ol style="list-style-type: none"> Check bulb. Check harness between LH headlamp and daytime light control unit. Check lighting switch. Check harness between daytime light control unit and lighting switch. Check daytime light control unit. (EL-63) 	CL MT
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> Bulb Headlamp LH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	<ol style="list-style-type: none"> Check bulb. Check harness between LH headlamp and daytime light control unit. Check lighting switch. Check harness between daytime light control unit and lighting switch. Check daytime light control unit. (EL-63) 	AT TF PD
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> Bulb Open in the RH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	<ol style="list-style-type: none"> Check bulb. Check harness between RH headlamp and daytime light control unit. Check lighting switch. Check harness between daytime light control unit and lighting switch. Check daytime light control unit. (EL-63) 	AX SU
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> Bulb Open in the RH high beams circuit Lighting switch Lighting switch circuit Daytime light control unit 	<ol style="list-style-type: none"> Check bulb. Check harness between RH headlamp and daytime light control unit. Check lighting switch. Check harness between daytime light control unit and lighting switch. Check daytime light control unit. (EL-63) 	BR ST
High beam indicator does not work.	<ol style="list-style-type: none"> Bulb Open in high beam circuit 	<ol style="list-style-type: none"> Check bulb in combination meter. Check the following. <ol style="list-style-type: none"> Harness between headlamp LH relay and combination meter for an open circuit Harness between high beam indicator and lighting switch 	RS BT
Battery saver control does not operate properly.	<ol style="list-style-type: none"> Door switch LH or RH circuit Smart entrance control unit 	<ol style="list-style-type: none"> Check the following. <ol style="list-style-type: none"> Harness between smart entrance control unit and LH or RH door switch for open or short circuit LH or RH door switch ground circuit LH or RH door switch Check smart entrance control unit. (EL-382) 	HA SC

EL

IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Daytime light control does not operate properly.	<ol style="list-style-type: none"> 1. Fuse check 2. Parking brake switch 3. Parking brake switch circuit 4. Alternator circuit 5. Daytime light control unit 	<ol style="list-style-type: none"> 1. Check the following. <ol style="list-style-type: none"> a. 7.5A fuse [No. 11, located in fuse block (J/B)] Verify battery positive voltage is present at terminal 3 of daytime light control unit. b. 7.5A fuse [No. 26, located in fuse block (J/B)] Verify battery positive voltage is present at terminal 2 of daytime light control unit. 2. Check parking brake switch. 3. Check harness between parking brake switch and daytime light control unit. 4. Check harness between alternator and daytime light control unit. 5. Check daytime light control unit. (EL-63)
When outside is dark, neither tail lamp nor headlamp turn on by auto light operation.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Lighting switch "AUTO" check 3. Lighting switch circuit check 4. Lighting switch ground circuit check 5. Auto light sensor check 6. Auto light sensor circuit check 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit. 2. Check lighting switch (AUTO) input signal with "CONSULT-II" in "DATA MONITOR" mode. When lighting switch is in AUTO: AUTO LIGHT SWITCH ON When lighting switch is in OFF: AUTO LIGHT SWITCH OFF 3. Check harness for open or short between smart entrance control unit and lighting switch. 4. Check harness for lighting switch and ground. 5. Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: More than 3V When auto light sensor is not stuck by light: Approx. 0.5V (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 and ground. Refer to smart entrance control unit. (EL-382) 6. Check the following. <ol style="list-style-type: none"> a. Harness for open or short between smart entrance control unit terminal 8 and auto light sensor terminal 1 b. Harness for open or short between smart entrance control unit terminal 7 and auto light sensor terminal 2 c. Harness for open or short between smart entrance control unit terminal 9 and auto light sensor terminal 3
When outside is dark, tail lamp turns on but headlamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. Headlamp and tail lamp should turn on. (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-382)</p>
When outside is dark, headlamp turns on but tail lamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. Headlamp and tail lamp should turn on. (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 57 and ground. Refer to smart entrance control unit. (EL-382)</p>

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Light does not turn off when ignition key switch is turned to "OFF" (exterior lamp battery saver control is canceled).	1. 7.5A fuse 2. IGN switch circuit	1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit. 2. Check harness for open or short between smart entrance control unit and fuse.
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.	Auto light sensor check	Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: More than 3V When auto light sensor is not stuck by light: Approx. 0.5V (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 (W/G) and ground. Refer to smart entrance control unit. (EL-382)

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NAEL0269S01

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)
1	Y/B	Alternator	 When turning ignition switch to "ON"	Less than 1V
			 When engine is running	12V
			 When turning ignition switch to "OFF"	Less than 1V
2	Y/R	Start signal	 When turning ignition switch to "ST"	Battery voltage
			 When turning ignition switch to "ON" from "ST"	Less than 1V
			 When turning ignition switch to "OFF"	Less than 1V
3	G	Power source	 When turning ignition switch to "ON"	Battery voltage
			 When turning ignition switch to "ST"	Battery voltage
			 When turning ignition switch to "OFF"	Less than 1V
4	R/L	Power source	 When turning ignition switch to "ON"	Battery voltage
			 When turning ignition switch to "OFF"	Battery voltage

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Terminal No.	Wire color	Item	Condition		Voltage (Approximate values)
5	R/W	Power source		When turning ignition switch to "ON"	Battery voltage
				When turning ignition switch to "OFF"	Battery voltage
6	R	LH hi beam		When lighting switch is turned to the 2ND position with "HI BEAM" position	12V
			 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. 6V
7	L/R	RH hi beam		When lighting switch is turned to the 2ND position with "HI BEAM" position	12V
			 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
9	PU	RH hi beam (ground)		When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V
			 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. 6V
10	GY	LH hi beam (ground)		When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V
			 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Less than 1V
13	L/W	Lighting switch (Hi beam)		When turning lighting switch to "HI BEAM"	Less than 1V
14	W/R			When turning lighting switch to "FLASH TO PASS"	Less than 1V
16	B	Ground		—	—
17	L/G	Parking brake switch		When parking brake is released	12V
				When parking brake is set	Less than 1.5V

Bulb Replacement

Refer to “HEADLAMP (FOR USA)” (EL-47).

GI
NAEL0270

MA

EM

LC

Aiming Adjustment

Refer to “HEADLAMP (FOR USA)” (EL-47).

EC
NAEL0271

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

PARKING, LICENSE AND TAIL LAMPS

System Description

System Description

NAEL0272

The parking, license and tail lamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. The battery saver system is controlled by the smart entrance control unit.

Power is supplied at all times

- to tail lamp relay terminals 1 and 3
- through 10A fuse (No. 61, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

LIGHTING OPERATION BY LIGHTING SWITCH

NAEL0272S01

When lighting switch is in 1ST (or 2ND) position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 20 and 58, and
- through lighting switch and body grounds E13 and E41.

Tail lamp relay is then energized and the parking, license and tail lamps illuminate.

LIGHTING OPERATION BY AUTO LIGHT CONTROL SYSTEM

NAEL0272S02

When lighting switch is in AUTO position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 43 and 64, and
- to body grounds M4, M66, M111, M147 and M157.

Tail lamp relay is then energized and the parking, license and tail lamps illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0272S03

Except for Auto Light Control Operation

NAEL0272S0301

Parking, license and tail lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF.

Continuity between terminals 19 and 20, and between terminals 57 and 58 of smart entrance control unit will be disturbed after 5 minutes, then the parking, license and tail lamps will be turned off.

When the lighting switch is turned from OFF to 2ND after parking, license and tail lamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57.

Then parking, license and tail lamps illuminate again.

Auto light control operation

NAEL0272S0302

While the parking, license and tail lamps are turned ON by "AUTO" operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off.

PARKING, LICENSE AND TAIL LAMPS

System Description (Cont'd)

- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes seconds, then the parking, license and tail lamps will be turned off. GI
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off. MA

Exterior lamp battery saver control time can be changed using “WORK SUPPORT” mode in “HEAD-LAMP”. EM

When the lighting switch is turned from OFF to 2ND after parking, license and tail lamps are turned to off by the exterior lamp battery saver control, ground is supplied LC

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to tail lamp relays terminal 2 from smart entrance control unit terminals 19 and 57. EC

Then parking, license and tail lamps illuminate again. FE

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

PARKING, LICENSE AND TAIL LAMPS

Schematic

Schematic

NAEL0273



MEL515P





PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

Wiring Diagram — TAIL/L —

NAEL0274

EL-TAIL/L-01



REFER TO THE FOLLOWING.

M10 - FUSE BLOCK-
JUNCTION BOX (J/B)







GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



REFER TO THE FOLLOWING.

- (E1) - SUPER MULTIPLE JUNCTION (SMJ)
- (E3) - FUSE BLOCK-JUNCTION BOX (J/B)



MEL958P

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-03

BD : With spare tire carrier
 OD : Without spare tire carrier



REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE
- JUNCTION (SMJ)
- (M91) -FUSE BLOCK-
- JUNCTION BOX (J/B)








GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

MEL959P

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)


EL-TAIL/L-04



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL960P




CONSULT-II Inspection Procedure

NAEL0275


“HEADLAMP”

NAEL0275S01


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “HEADLAMP”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PARKING, LICENSE AND TAIL LAMPS

CONSULT-II Application Items

CONSULT-II Application Items

NAEL0454

NAEL0454S01

NAEL0454S0101

“HEAD LAMP” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
AUTO LIGT SW	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
AUTO LIGT SENS	Displays “Illumination outside of the vehicle (close to 5V when light/close to 0V when dark)” as judged from the optical sensor signal.
LIGHT SW 1ST	Displays status of the lighting switch as judged from the lighting switch signal. (1ST or 2ND position: ON/Other than 1ST and 2ND position: OFF)
LIGHT SW 2ND	Displays status of the lighting switch as judged from the lighting switch signal. (2ND position: ON/Other than 2ND position: OFF)
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.

Active Test

NAEL0454S0102

Test Item	Description
TAIL LAMP	Tail lamp relay can be operated by on-off operation of the tail lamp.
HEAD LAMP	Headlamp relay can be operated by on-off operation of the headlamp.
AUTO LIGHT	Night time dimming signal can be operated by on-off operation.

Work Support

NAEL0454S0103

Work Item	Description
AUTO LIGHT SET	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● NORMAL/MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two modes. ● MODE 1 (ON)/MODE 2 (OFF)
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/ MODE 5 (90 sec.)/ MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

Trouble Diagnoses

NAEL0277

Symptom	Possible cause	Repair order
No lamps operate (including head-lamps).	<ol style="list-style-type: none"> 7.5A fuse Lighting switch Smart entrance control unit 	<ol style="list-style-type: none"> Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit. Check lighting switch. Check smart entrance control unit. (EL-382)

PARKING, LICENSE AND TAIL LAMPS

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
No parking, license and tail lamps operate, but headlamps do operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Tail lamp relay 3. Tail lamp relay circuit 4. Lighting switch 5. Lighting switch circuit 6. Smart entrance control unit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 61, located in fusible and fuse block). Verify battery positive voltage is present at terminals 1 and 3 of tail lamp relay. 2. Check tail lamp relay. 3. Check the following. <ol style="list-style-type: none"> a. Harness between smart entrance control unit terminals 19 and 57 and tail lamp relay terminal 2 b. Harness between tail lamp relay terminal 5 and fuse block 4. Check lighting switch. 5. Check the following. <ol style="list-style-type: none"> a. Harness between lighting switch terminal 11 and smart entrance control unit terminals 20 and 58 b. Harness between lighting switch terminal 5 and ground 6. Check smart entrance control unit. (EL-382) 	GI MA EM LC EC FE
Exterior lamp battery saver control does not operate properly.	<ol style="list-style-type: none"> 1. Driver, passenger or rear door switch circuit 2. Smart entrance control unit 	<ol style="list-style-type: none"> 1. Check the following. <ol style="list-style-type: none"> a. Harness between smart entrance control unit and driver, passenger or rear door switch for open or short circuit b. Driver passenger or rear door switch ground circuit c. Driver, passenger or rear door switch 2. Check smart entrance control unit. (EL-382) 	CL MT
Auto light malfunctioning	—	Refer to trouble diagnosis in "HEADLAMP". (EL-44)	AT

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

STOP LAMP



Wiring Diagram — STOP/L —

Wiring Diagram — STOP/L —

NAEL0278

EL-STOP/L-01

⬡ : With A/T
⬡ : With M/T





REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE
 JUNCTION (SMJ)
 (M10) -FUSE BLOCK-
 JUNCTION BOX (J/B)

MEL961P

STOP LAMP

Wiring Diagram — STOP/L — (Cont'd)

EL-STOP/L-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

MEL262M

IDX

BACK-UP LAMP



Wiring Diagram — BACK/L —

Wiring Diagram — BACK/L —

NAEL0279

EL-BACK/L-01

- A : With A/T
- M : With M/T
- 2M : With M/T and 2-wheel drive
- 4M : With M/T and 4-wheel drive



REFER TO THE FOLLOWING.

- B1 -SUPER MULTIPLE JUNCTION (SMJ)
- M10 -FUSE BLOCK-JUNCTION BOX (J/B)

MEL085Q

System Description

NAELO280

NAELO280S01

OUTLINE

Power is supplied at all times

- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)], and
- to front fog lamp relay terminal 3
- through 15A fuse (No. 53, located in the fuse and fusible link box).

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

When lighting switch is in 2ND position, ground is supplied

- to headlamp RH relay terminal 2 from smart entrance control unit terminals 21 and 59.
- through smart entrance control unit terminals 22 and 60,
- through lighting switch terminal 12, and
- through body grounds E13 and E41.

Headlamp RH relay is then energized.

FOG LAMP OPERATION

The front fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for front fog lamp operation.

With the front fog lamp switch in the ON position, ground is supplied

- to front fog lamp relay terminal 1
- through the front fog lamp switch, lighting switch and body grounds E13 and E41.

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal 5
- to terminal 1 of each front fog lamp.

Ground is supplied to terminal 2 of each front fog lamp through body grounds E13 and E41.

With power and ground supplied, the front fog lamps illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

Front fog lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the front fog lamps will be turned off.

When the lighting switch is turned from OFF to 2ND after front fog lamps are turned off by the battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then
- to headlamp RH relay terminal 2 from smart entrance control unit terminal 21 and 59
- through smart entrance control unit terminal 22 and 60 from lighting switch terminal 12.

Then the front fog lamps illuminate again.

NOTE:

For Trouble Diagnoses for battery saver control, refer to "HEADLAMP (FOR USA)", EL-44.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


FRONT FOG LAMP

Wiring Diagram — F/FOG —

Wiring Diagram — F/FOG —

NAEL0281

EL-F/FOG-01



Next page

Next page

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M114) W

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21	22	23	24			

(M121) W

25	26	27	28	29	30	31	32	33
34	35	36	37	38	39	40	41	42
43	44	45	46	47	48			

(M122) GY

49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64

(M123) GY



REFER TO THE FOLLOWING.


- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)

MEL962P

FRONT FOG LAMP


Wiring Diagram — F/FOG — (Cont'd)

EL-F/FOG-02



Refer to EL-POWER.


- U : For USA
- C : For Canada
- *1 Y/B : U
- G/R : C



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT FOG LAMP

Aiming Adjustment




Aiming Adjustment

NAEL0282


Before performing aiming adjustment, make sure of the following.

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps so that the top edge of the high intensity zone is 200 mm (7.9 in) below the height of the fog lamp centers as shown at left.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4, M66, M111, M147 and M157.

LH Turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 3
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 1 through body grounds E13 and E41.
 Ground is supplied to the rear combination lamp LH terminal 6 through body grounds B11, B22 and D210.
 Ground is supplied to combination meter terminal 30 through body grounds M4, M66, M111, M147 and M157.
 With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH Turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 3
- combination meter terminal 29
- rear combination lamp RH terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 1 through body grounds E13 and E41.
 Ground is supplied to the rear combination lamp RH terminal 6 through body grounds B55 and B75.
 Ground is supplied to combination meter terminal 30 through body grounds M4, M66, M111, M147 and M157.
 With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal 3 through:

- 15A fuse [No. 20, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4, M66, M111, M147 and M157.

Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 3
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Power is supplied through terminal 6 of the hazard switch to

- front turn signal lamp RH terminal 3
- combination meter terminal 29
- rear combination lamp RH terminal 5.

GI

NAEL0283

MA

NAEL0283S01

EM

LC

EC

FE

NAEL0283S0101

CL

MT

AT

TF

NAEL0283S0102

PD

AX

SU

BR

NAEL0283S02

ST

RS

BT

HA

SC

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.

Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 30 through body grounds M4, M66, M111, M147 and M157.

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

REMOTE KEYLESS ENTRY SYSTEM OPERATION

NAEL0283S03

Power is supplied at all times

- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminal 43 and 64
- through body ground M4, M66, M111, M147 and M157.

Refer to "REMOTE KEYLESS ENTRY SYSTEM", EL-314.

When smart entrance control unit receives LOCK or UNLOCK signal from keyfob with all doors closed, power is supplied

- through terminal 47 of smart entrance control unit
- to front turn signal lamp LH terminal 3
- to combination meter terminal 25
- to rear combination lamp LH terminal 5, and
- through terminal 48 of smart entrance control unit
- to front turn signal lamp RH terminal 3
- to combination meter terminal 29
- to rear combination lamp RH terminal 5.

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.

Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 30 through body grounds M4, M66, M111, M147 and M157.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.




TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

Wiring Diagram — TURN —

NAEL0284

EL-TURN-01



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-
JUNCTION BOX (J/B)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL964P

Trouble Diagnoses

NAEL0285

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Combination switch (turn signal) 4. Open in combination switch (turn signal) circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 12, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check combination switch (turn signal). 4. Check the wire between combination flasher unit terminal 3 and combination switch (turn signal) terminal 1 for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 15A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 15A fuse [No. 20, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check the wire between combination flasher unit terminal 3 and hazard switch terminal 4 for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E13 and E41 3. Open in front turn signal lamp circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E13 and E41. 3. Check harness between front turn signal lamp and combination switch.
Rear combination lamp LH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds B11, B22 and D210 3. Open in rear combination lamp LH circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds B11, B22 and D210. 3. Check harness between rear combination lamp LH and hazard switch.
Rear combination lamp RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds B55 and B75 3. Open in rear combination lamp RH circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds B55 and B75. 3. Check harness between rear combination lamp RH and hazard switch.
LH and RH turn indicators do not operate.	Grounds M4, M66, M111, M147 and M157	Check grounds M4, M66, M111, M147 and M157.
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Open in turn indicator circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check harness between combination meter and hazard switch.



Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NAEL0286

NAEL0286S01

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ILLUMINATION

System Description

System Description

NAEL0287

The illumination lamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. The battery saver system is controlled by smart entrance control unit. Power is supplied at all times

- to tail lamp relay terminals 1 and 3
- through 10A fuse (No. 61, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

LIGHTING OPERATION BY LIGHTING SWITCH

NAEL0287S01

When lighting switch is 1ST (or 2ND) position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 20 and 58, and
- through lighting switch and body grounds E13 and E41.

Tail lamp relay is then energized and illumination lamps illuminate.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The ground for all of the components except for grove box lamp, ashtray and compass and thermometer are controlled through terminals 2 and 3 of the illumination control switch and body grounds M4, M66, M111, M145 and M157.

LIGHTING OPERATION BY AUTO LIGHT CONTROL SYSTEM

NAEL0287S02

When auto light operation is operated, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 43 and 64, and
- to body grounds M4, M66, M111, M147 and M157.

Tail lamp relay is then energized and the illumination lamps illuminate.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M19	1	3
4WD shift switch	M141	7	8
Ashtray (without woody instrument finisher)	B76	1	2
Ashtray (with woody instrument finisher)	M155		
A/T device	B59	3	4
Cigarette lighter	M57	3	4
Audio unit	M48	8	7
Compass and thermometer	R4	5	2
Hazard switch	M35	7	8

ILLUMINATION

System Description (Cont'd)

Component	Connector No.	Power terminal	Ground terminal
Rear window defogger switch	M36	5	6
CD player	M92, M93	3	5
A/C switch illumination	M45	2	1
A/C auto amp.	M102	24	25
Clock	M40	3	4
Globe box lamp	M30	1	2
Combination meter (with normal meter)	M26	64	65
Combination meter (with fine vision meter)	M26	64	49
VDC off switch	M151	4	5

The ground for all of the components except for compass and thermometer, glove box lamp and ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M4, M66, M111, M147 and M157.

EXTERIOR LAMP BATTERY SAVER CONTROL

Except for Auto Light Control Operation

NAEL0287S03

Illumination lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. Continuity between terminals 19 and 20, and between terminals 57 and 58 of smart entrance control unit will be disturbed after 5 minutes, then the illumination lamp will be turned off.

When the lighting switch is turned from OFF to 1ST (or 2ND) after illumination lamps are turned off by the battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and
- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57.

Then illumination lamps illuminate again.

Auto light control operation

While the illumination lamps are turned ON by "AUTO" operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes seconds, then the illumination lamps will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.

Exterior lamp battery saver control time can be changed using "WORK SUPPORT" mode in "HEAD-LAMP".

When the lighting switch is turned from OFF to 2ND after illumination lamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to tail lamp relays terminal 2 from smart entrance control unit terminals 19 and 57.

Then illumination lamps illuminate again.

NOTE:


For Trouble Diagnoses for battery saver control, refer to "PARKING, LICENSE AND TAIL LAMPS" (EL-74).

ILLUMINATION

Schematic

NAEL0288





Schematic



ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02



REFER TO THE FOLLOWING.


- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-JUNCTION BOX (J/B)

MEL968P


ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



- (C) : For Canada
- (CT) : With compass and thermometer
- (MA) : With manual A/C
- (CD) : With CD player
- (AW) : With all-mode 4-wheel drive



REFER TO THE FOLLOWING.
 (M10) - FUSE BLOCK-
 JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL969P

ILLUMINATION


Wiring Diagram — ILL — (Cont'd)

EL-ILL-04

AA : With auto A/C

VD : With VDC

XN : With auto A/C and normal meter, with manual A/C




MEL935R

ILLUMINATION


Wiring Diagram — ILL — (Cont'd)

EL-ILL-05

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



(A) : With A/T
(WF) : With woody instrument finisher
(OW) : Without woody instrument finisher




REFER TO THE FOLLOWING.
(M91) - FUSE BLOCK-JUNCTION BOX (J/B)

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-06





25	26	27	28	29	30	31	32	33	M25 BR	45	46	47	48	49	50	51	52	53	54	55	M26 BR	71	70	M159 W			
34	35	36	37	38	39	40	41	42		43	44	56	57	58	59	60	61	62	63	64		65	66		67	68	75

MEL937R

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-07



REFER TO THE FOLLOWING.

(B1) -SUPER
MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description

System Description

NAEL0290

NAEL0290S01

POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to key switch terminal 2 and
- to smart entrance control unit terminal 49.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal 1
- to smart entrance control unit terminal 25.

With the ignition key switch in the ON or START position, power is supplied:

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied:

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

When the front driver side door is opened, ground is supplied:

- through body grounds B11, B22 and D210
- to front door switch (LH) terminal 2
- from front door switch (LH) terminal 1
- to smart entrance control unit terminal 1.

When the front passenger side door is opened, ground is supplied:

- through body grounds terminals B55 and B75
- to front door switch (RH) terminal 2
- from front door switch (RH) terminal 1
- to smart entrance control unit terminal 2.

When any other door (except front door) is opened, ground is supplied to smart entrance control unit terminal 3 in the same manner as the front door switch.

When the front LH door is unlocked by front door key cylinder switch, ground is supplied

- through body grounds M4, M66, M111, M147 and M157
- to front door key cylinder switch terminal 2
- through front key cylinder switch terminal 1
- to power window main switch terminal 6.

Power window main switch terminal 14 send unlock signal to smart entrance control unit terminal 33 with serial link communication line.

When back door is unlocked by back door key cylinder switch, ground is supplied

- through body grounds B11, B22 and D210
- to back door key cylinder switch terminal 4
- from back door key cylinder terminal 2
- to smart entrance control unit terminal 10.

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 31
- to interior lamp terminal 2.

With power and ground supplied, the interior lamp illuminates.

SWITCH OPERATION

When interior lamp switch is ON, ground is supplied:

- through case grounds of interior lamp
- to interior lamp.

And power is supplied:

- to interior lamp terminal 1
- from smart entrance control unit terminal 50.

When spot lamp (LH and/or RH) is ON, ground is supplied:

NAEL0290S02

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description (Cont'd)

- through body grounds M4, M66, M111, M147 and M157
- to spot lamp terminal 2.

And power is supplied:

- to spot lamp terminal 1
- from smart entrance control unit terminal 50.

When vanity mirror illumination (LH and/or RH) is ON, ground is supplied:

- through body grounds M4, M66, M111 and M147
- to vanity mirror illuminations (LH and RH) terminals 2.

And power is supplied:

- to vanity mirror illuminations (LH and RH) terminals 1
- from smart entrance control unit terminal 50.

With power and ground supplied, interior lamps turn ON.

INTERIOR LAMP TIMER OPERATION

When interior lamp switch is in the "DOOR" position, the smart entrance control unit keeps the interior lamp illuminated for about 30 seconds when:

- unlock signal is supplied from door lock and unlock switch while all doors are closed and key is out of ignition key cylinder
- unlock signal is supplied from keyfob or door key cylinder while driver's door is locked and all doors are closed
- key is removed from ignition key cylinder while all doors are closed
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or
- ignition switch is turned ON.

When driver's door is locked, interior room lamp timer is canceled as described before.

ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

INTERIOR LAMP BATTERY SAVER

The lamp turns off automatically when interior lamp, luggage room lamp, spot lamp and/or vanity mirror illumination is illuminated with the ignition key is in OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in ON position for more than 30 minutes.

After lamps turn OFF by the battery saver system, the lamps illuminate again when:

- driver's door is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Schematic

Schematic

NAEL0291



MEL407P


INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L —


Wiring Diagram — INT/L —

NAEL0292


EL-INT/L-01



Refer to EL-POWER.



REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M10), (E3) -FUSE BLOCK-
 JUNCTION BOX (J/B)







GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-02








REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL974P

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)



REFER TO THE FOLLOWING.









(B1) - SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)


EL-INT/L-04




MEL976P

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST



REFER TO THE FOLLOWING.
(B1) - SUPER MULTIPLE JUNCTION (SMJ)

RS
BT
HA
SC


EL

MEL939R

IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Inspection Procedure




CONSULT-II Inspection Procedure

=NAEL0293


“INT LAMP”/“BATTERY SAVER”

NAEL0293S01


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “INT LAMP” or “BATTERY SAVER”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available for “INT LAMP” and “BATTERY SAVER”.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Application Items

CONSULT-II Application Items

“INT LAMP” Data Monitor

NAEL0294

NAEL0294S01

NAEL0294S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.

Active Test

NAEL0294S0102

Test Item	Description
INT LAMP	This test enables to check interior lamp operation. When “ON” on CONSULT-II screen is touched: <ul style="list-style-type: none"> Interior lamp turns on when the switch is at DOOR. (Smart entrance control unit supplies power and ground to interior lamp.)
IGN ILLUM	This test enables to check ignition key hole illumination operation. The illumination turns on when “ON” on CONSULT-II screen is touched.
STEP LAMP	This test enables to check step lamp operation. The illumination turns on when “ON” on CONSULT-II screen is touched.

NOTE:

Even though ignition key hole illumination and step lamp are actually displayed on the CONSULT-II screen, those are not equipped, therefore, they cannot be activated.

Work Support

NAEL0294S0103

Work Item	Description
ROOM LAMP TIMER SET	Interior lamp timer mode can be changed by mode setting. Selects ON-OFF of the room lamp illumination at the time the driver door is unlocked. <ul style="list-style-type: none"> MODE 1 (ON)/MODE 2 (OFF) NOTE: Even though ignition keyhole illumination and step lamp are actually displayed on the CONSULT-II screen, those are not equipped, therefore, they cannot be activated.

“BATTERY SAVER” Data Monitor

NAEL0294S02

NAEL0294S0201

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Application Items (Cont'd)

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.

Active Test

NAEL0294S0202

Test Item	Description
BATTERY SAVER	<p>This test enables to check interior lamp and spot lamp and vanity mirror illuminations operations.</p> <p>When touch "ON" on CONSULT-II screen.</p> <ul style="list-style-type: none"> ● Interior lamp turns on when the switch is in ON. (Smart entrance control unit supplies power to interior lamp.) ● Spot lamp and vanity mirror illuminations turn on when the switch is in ON. (Smart entrance control unit supplies power to spot lamp, and vanity mirror illuminations.)

Work Support

NAEL0294S0203

Work Item	Description
ROOM LAMP BAT SAV SET	<p>Interior lamp battery saver control period can be changed by mode setting. Selects interior lamp battery saver control period between two modes.</p> <ul style="list-style-type: none"> ● MODE 1 (30 minutes)/MODE 2 (60 minutes)

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer


Trouble Diagnoses for Interior Lamp Timer

=NAEL0295

DIAGNOSTIC PROCEDURE 1

NAEL0295S01


SYMPTOM: Interior lamp timer does not operate.


1	CHECK IGNITION ON SIGNAL															
<p> With CONSULT-II Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.</p>																
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>IGN ON SW</td> <td>ON</td> </tr> </tbody> </table>		DATA MONITOR		MONITOR		IGN ON SW	ON									
DATA MONITOR																
MONITOR																
IGN ON SW	ON															
<p>When ignition switch is ON: IGN ON SW ON</p> <p>When ignition switch is OFF: IGN ON SW OFF</p>																
SEL318W																
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B) and ground.</p>																
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  <p>Smart entrance control unit connector</p>  </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>27</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table> </div>		Terminals		Ignition switch position			(+)	(-)	OFF	ACC	ON	27	Ground	0V	0V	Battery voltage
Terminals		Ignition switch position														
(+)	(-)	OFF	ACC	ON												
27	Ground	0V	0V	Battery voltage												
SEL003Y																
OK or NG																
OK	▶▶ GO TO 2.															
NG	▶▶ Check the following.															
	<ul style="list-style-type: none"> ● 7.5A fuse [No. 11, located in fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse 															

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Trouble Diagnoses for Interior Lamp Timer (Cont'd)


2	CHECK FRONT DOOR SWITCH LH INPUT SIGNAL							
<p> With CONSULT-II Check front door switch LH signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th></th></tr> <tr><td>DOOR SW-DR</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		DOOR SW-DR	OFF
DATA MONITOR								
MONITOR								
DOOR SW-DR	OFF							
		<p>When front door LH is open: DOOR SW-DR ON</p> <p>When front door LH is closed: DOOR SW-DR OFF</p>						
SEL319WB								
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/OR) and ground.</p>								
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Smart entrance control unit connector</p>  </div> <div style="flex: 1; text-align: center;">  </div> <div style="flex: 1;"> <p>Voltage [V]:</p> <p>Condition of front door LH: CLOSED Approx. 5</p> <p>Condition of front door LH: OPENED 0</p> </div> </div>								
SEL004YD								
OK or NG								
OK	▶	GO TO 4.						
NG	▶	GO TO 3.						

3	CHECK FRONT DOOR SWITCH LH	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Continuity between front door switch LH connector B9 terminals 1 and 2 ● Continuity between front door switch LH connector B9 terminal 3 and ground 		
<p style="text-align: center;">Front door switch LH connector</p> 		
		<p>Continuity:</p> <p>Door switch is pushed. No</p> <p>Door switch is released. Yes</p>
SEL277YA		
OK or NG		
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Front door switch LH ground circuit and condition ● Harness for open or short between smart entrance control unit and front door switch LH
NG	▶	Replace front door switch LH.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

4	CHECK FRONT DOOR SWITCH RH INPUT SIGNAL		GI MA EM LC EC FE CL MT AT TF PD AX						
<p> With CONSULT-II Check front door switch RH signal ("DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;"></th> </tr> </thead> <tbody> <tr> <td>DOOR SW-AS</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table> </div> <div style="margin-left: 20px;"> <p>When front door RH is open: DOOR SW-AS ON</p> <p>When front door RH is closed: DOOR SW-AS OFF</p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL153YA</p>				DATA MONITOR		MONITOR		DOOR SW-AS	OFF
DATA MONITOR									
MONITOR									
DOOR SW-AS	OFF								
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 2 (Y) and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="margin-bottom: 10px;"> <p style="text-align: center;">Smart entrance control unit connector</p>  </div> <div style="margin-left: 20px;"> <p>Voltage [V]: Condition of front door RH: CLOSED Approx. 5 Condition of front door RH: OPENED 0</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <p style="text-align: right; margin-top: 10px;">SEL152YB</p>									
OK		▶	GO TO 6.						
NG		▶	GO TO 5.						

5	CHECK FRONT DOOR SWITCH RH		SU BR ST RS BT HA SC
<p>Check the following.</p> <ul style="list-style-type: none"> ● Continuity between front door switch RH connector B68 terminals 1 and 2 ● Continuity between front door switch RH connector B68 terminal 3 and ground <div style="display: flex; justify-content: space-between; align-items: flex-start; margin-top: 10px;"> <div style="margin-bottom: 10px;"> <p style="text-align: center;">Front door switch RH connector</p>  </div> <div style="margin-left: 20px;"> <p>Continuity: Door switch is pushed. No Door switch is released. Yes</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <p style="text-align: right; margin-top: 10px;">SEL278YA</p>			
OK		▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Front door switch RH ground circuit and condition ● Harness for open or short between smart entrance control unit and front door switch RH
NG		▶	Replace front door switch RH.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Trouble Diagnoses for Interior Lamp Timer (Cont'd)


6	CHECK REAR AND BACK DOOR SWITCHES INPUT SIGNAL							
<p> With CONSULT-II Check door switches ("DOOR SW-RR") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>DOOR SW-RR</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		DOOR SW-RR	OFF
DATA MONITOR								
MONITOR								
DOOR SW-RR	OFF							
		<p>When rear door LH, RH and/or back door is open: DOOR SW-RR ON</p> <p>When rear door LH, RH and/or back door is closed: DOOR SW-RR OFF</p>						
SEL154YB								
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 3 (R/L) and ground.</p>								
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Smart entrance control unit connector</p> </div> <div style="flex: 1; text-align: center;"> <p>Voltage [V]:</p> <p>Condition of rear door LH, RH and/or back door: CLOSED Approx. 5</p> <p>Condition of rear door LH, RH and/or back door: OPENED 0</p> </div> </div>								
SEL155YB								
OK or NG								
OK	▶	GO TO 8.						
NG	▶	GO TO 7.						

7	CHECK REAR AND BACK DOOR SWITCHES	
<p>1. Disconnect door switch harness connector. 2. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between rear door switches connector B18 and B71 terminal 1 and ground ● Continuity between back door switch connector D208 terminals 1 and 2 		
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Rear door switch connector</p> </div> <div style="flex: 1;"> <p style="text-align: center;">Back door switch connector</p> </div> <div style="flex: 1; text-align: center;"> <p>Continuity:</p> <p>Door switch is pushed. No</p> <p>Door switch is released. Yes</p> </div> </div>		
SEL279Y		
OK or NG		
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Rear LH, RH and/or back door switch ground circuit or door switch ground condition ● Harness for open or short between smart entrance control unit and rear LH, RH and/or back door switch
NG	▶	Replace rear LH, RH and/or back door switch.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

8	CHECK KEY SWITCH INPUT SIGNAL	<p>Ⓟ With CONSULT-II Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table> <div style="margin-left: 20px;"> <p>When key is inserted to ignition key cylinder: KEY ON SW ON</p> <p>When key is removed from ignition key cylinder: KEY ON SW OFF</p> </div> </div> <p style="text-align: right; font-size: small;">SEL315W</p>	DATA MONITOR		MONITOR		KEY ON SW	ON	GI MA EM LC EC FE
DATA MONITOR									
MONITOR									
KEY ON SW	ON								
<p>⊗ Without CONSULT-II Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p> <p>Smart entrance control unit connector</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Voltage [V]:</p> <p>Condition of key switch: Key is inserted. Approx. 12</p> <p>Condition of key switch: Key is removed. 0</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <p style="text-align: right; font-size: small;">SEL011Y</p>		CL MT AT TF PD							
OK	▶	GO TO 10.							
NG	▶	GO TO 9.							

9	CHECK KEY SWITCH (INSERT)	<p>Check continuity between key switch connector terminals 1 and 2.</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Continuity:</p> <p>Condition of key switch: Key is inserted. Yes</p> <p>Condition of key switch: Key is removed. No</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p> <p style="text-align: right; font-size: small;">SEL308X</p>	SU BR ST RS BT HA
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between smart entrance control unit and key switch 	SC
NG	▶	Replace key switch.	EL

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

10 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

LOCK SW DR/AS ON

When lock/unlock switch is turned to UNLOCK:

UNLK SW DR/AS ON



SEL341W

Without CONSULT-II

1. Remove key from ignition key cylinder.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



Smart entrance control unit connector



Voltage:
12V → 9V (10 sec.) measurement
by analog circuit tester.

SEL699YA

OK or NG

OK



Door lock/unlock switch is OK.

NG



Check the following.

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the power window main switch.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

11 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF



When key inserted in front key cylinder is turned to LOCK:
KEY CYL LK-SW ON

When key inserted in front key cylinder is turned to UNLOCK:
KEY CYL UN-SW ON

SEL342W

Without CONSULT-II

1. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when key inserted in front key cylinder is turned "LOCK" or "UNLOCK".
2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Voltage:
12V → 9V (10 sec.)
measurement by analog
circuit tester.


SEL700YA

OK or NG

OK	▶	Door key cylinder switch LH is OK.
NG	▶	GO TO 12.

12 CHECK FRONT DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

Check voltage between power window main switch harness connector D6 terminals 4 (Y/L) or 6 (LG) and ground.



Door	Terminals		Key position	Voltage V
	(+)	(-)		
Front door LH	4	Ground	Neutral/Unlock	Approx. 5
			Lock	0
	6	Ground	Neutral/Lock	Approx. 5
			Unlock	0

SEL792Y

OK or NG

OK	▶	Replace smart entrance control unit.
NG	▶	GO TO 13.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

13 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back key cylinder is turned to LOCK:

KEY CYL LK-SW ON


When key inserted in back key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WB

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG), 11 (Y) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5

SEL680Y



OK or NG

OK ► Replace smart entrance control unit.

NG ► GO TO 14.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

14	CHECK DOOR KEY CYLINDER SWITCH																												
	<p>1. Disconnect door key cylinder switch harness connector. 2. Check continuity between each key cylinder switch connector terminals.</p> <ul style="list-style-type: none"> ● Front door key cylinder switch LH harness connector D9 <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Front door key cylinder switch connector</p> </div> <div style="text-align: left;"> <p>① : Door unlock switch terminal ② : Ground terminal ③ : Door lock switch terminal</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">③ - ②</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">① - ②</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL793Y</p> <ul style="list-style-type: none"> ● Back door key cylinder switch harness connector D201 <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="text-align: center;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL315X</p> <p style="text-align: center;">OK or NG</p>	Terminals	Key position	Continuity	③ - ②	Neutral/Unlock	No	Lock	Yes	① - ②	Neutral/Lock	No	Unlock	Yes	Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○		○	Between neutral and unlock (Back door)		○	○
Terminals	Key position	Continuity																											
③ - ②	Neutral/Unlock	No																											
	Lock	Yes																											
① - ②	Neutral/Lock	No																											
	Unlock	Yes																											
Key position	Terminals																												
	1	2	4																										
Between neutral and lock (Back door)	○		○																										
Between neutral and unlock (Back door)		○	○																										
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Front or back door key cylinder switch ground circuit ● Harness for open or short between back door key cylinder switch and smart entrance control unit connector ● Harness for open or short between front door key cylinder switch LH and power window main switch 																												
NG	<p>▶ Replace front or back door key cylinder switch.</p>																												

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

DIAGNOSTIC PROCEDURE 2

=NAEL0295S02

SYMPTOM: Interior lamp timer does not cancel properly.

1 CHECK IGNITION ON SIGNAL

With CONSULT-II

Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
IGN ON SW	ON

When ignition switch is ON:

IGN ON SW ON


When ignition switch is OFF:

IGN ON SW OFF

SEL318W

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B) and ground.



Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
27	Ground	0V	0V	Battery voltage


SEL995X



OK or NG

OK	▶	GO TO 2.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 11, located in fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

2	CHECK FRONT LH DOOR SWITCH INPUT SIGNAL		GI MA EM LC EC FE CL MT AT TF PD AX						
<p> With CONSULT-II Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>									
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th></th></tr> <tr><td>DOOR SW-DR</td><td>OFF</td></tr> </table>				DATA MONITOR		MONITOR		DOOR SW-DR	OFF
DATA MONITOR									
MONITOR									
DOOR SW-DR	OFF								
<p>When front door LH is open: DOOR SW-DR ON</p> <p>When front door LH is closed: DOOR SW-DR OFF</p>									
SEL319WB									
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/OR) and ground.</p>									
<div style="display: flex; justify-content: space-between;"> <div style="width: 40%;"> <p>Smart entrance control unit connector</p>  </div> <div style="width: 30%; text-align: center;">  </div> <div style="width: 25%;"> <p>Voltage [V]: Condition of front door LH: CLOSED Approx. 5 Condition of front door LH: OPENED 0</p> </div> </div>									
SEL004YD									
OK or NG									
OK	▶	GO TO 4.							
NG	▶	GO TO 3.							

3	CHECK FRONT DOOR SWITCH LH		SU BR ST RS BT HA SC
<p>Check the following.</p> <ul style="list-style-type: none"> ● Continuity between front door switch LH connector B9 terminals 1 and 2 ● Continuity between front door switch LH connector B9 terminal 3 and ground 			
<div style="display: flex; justify-content: space-between;"> <div style="width: 40%;"> <p>Front door switch LH connector</p>  </div> <div style="width: 30%; text-align: center;">  </div> <div style="width: 25%;"> <p>Continuity: Door switch is pushed. No Door switch is released. Yes</p> </div> </div>			
SEL277YA			
OK or NG			
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Front door switch LH ground circuit and condition ● Harness for open or short between smart entrance control unit and front door switch LH 	
NG	▶	Replace front door switch LH.	

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

4 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

LOCK SW DR/AS ON

When lock/unlock switch is turned to UNLOCK:

UNLK SW DR/AS ON



SEL341W

Without CONSULT-II

1. Remove key from ignition key cylinder.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



Smart entrance control unit connector



Voltage:
12V → 9V (10 sec.) measurement
by analog circuit tester.

SEL699YA

OK or NG

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

5 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF



When key inserted in front key cylinder is turned to LOCK:
KEY CYL LK-SW ON

When key inserted in front key cylinder is turned to UNLOCK:
KEY CYL UN-SW ON

SEL342W

Without CONSULT-II

- Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when key inserted in front key cylinder is turned "LOCK" or "UNLOCK".
- Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Voltage:
12V → 9V (10 sec.)
measurement by analog
circuit tester.


SEL700YA

OK or NG

OK	▶	Door key cylinder switch LH is OK.
NG	▶	GO TO 6.

6 CHECK FRONT DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

Check voltage between power window main switch harness connector D6 terminals 4 (Y/L) or 6 (LG) and ground.



Door	Terminals		Key position	Voltage V
	(+)	(-)		
Front door LH	4	Ground	Neutral/Unlock	Approx. 5
			Lock	0
	6	Ground	Neutral/Lock	Approx. 5
			Unlock	0

SEL792Y

OK or NG

OK	▶	Replace smart entrance control unit.
NG	▶	GO TO 7.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

7 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back key cylinder is turned to LOCK:

KEY CYL LK-SW ON


When key inserted in back key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WB

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG), 11 (Y) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5

SEL680Y



OK or NG

OK ► Replace smart entrance control unit.

NG ► GO TO 8.

INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

8	CHECK DOOR KEY CYLINDER SWITCH																
<p>1. Disconnect door key cylinder switch harness connector. 2. Check continuity between each key cylinder switch connector terminals.</p> <ul style="list-style-type: none"> ● Front door key cylinder switch harness connector D9 																	
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Front door key cylinder switch connector</p>  </div> <div style="width: 45%;"> <p>① : Door unlock switch terminal ② : Ground terminal ③ : Door lock switch terminal</p> <table border="1" data-bbox="763 420 1307 577"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">③ - ②</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">① - ②</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div>			Terminals	Key position	Continuity	③ - ②	Neutral/Unlock	No	Lock	Yes	① - ②	Neutral/Lock	No	Unlock	Yes		
Terminals	Key position	Continuity															
③ - ②	Neutral/Unlock	No															
	Lock	Yes															
① - ②	Neutral/Lock	No															
	Unlock	Yes															
SEL793Y																	
<ul style="list-style-type: none"> ● Back door key cylinder switch harness connector D201 																	
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Back door key cylinder switch (D201)</p>  </div> <div style="width: 45%;"> <table border="1" data-bbox="787 745 1421 934"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div>			Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○		○	Between neutral and unlock (Back door)		○	○
Key position	Terminals																
	1	2	4														
Between neutral and lock (Back door)	○		○														
Between neutral and unlock (Back door)		○	○														
SEL315X																	
OK or NG																	
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Front or back door key cylinder switch ground circuit ● Harness for open or short between back door key cylinder switch and smart entrance control unit connector ● Harness for open or short between front door key cylinder switch and power window main switch 																
NG	▶ Replace front or back door key cylinder switch.																


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0296



System Description

NAEL0297


UNIFIED CONTROL METER

NAEL0297S01

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NAEL0297S02



NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

NAEL0297S03

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to combination meter terminal 62.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 66.

Ground is supplied

- to combination meter terminal 59
- through body grounds M4, M66, M111, M147 and M157.

WATER TEMPERATURE GAUGE

NAEL0297S04

The water temperature gauge indicates the engine coolant temperature. ECM provides an engine coolant temperature signal to the combination meter for the water temperature gauge with CAN communication line. The needle on the gauge moves from "C" to "H".

TACHOMETER

NAEL0297S05

The tachometer indicates engine speed in revolutions per minute (rpm).

ECM provides an engine speed signal to the combination meter for the tachometer with CAN communication line.

FUEL GAUGE

NAEL0297S06

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 17 for the fuel gauge
- from terminal 3 of the fuel level sensor unit
- through terminal 2 of the fuel level sensor unit and
- through combination meter terminal 23.

SPEEDOMETER

NAEL0297S07

Without VDC

The ABS actuator and electric unit (control unit) provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- from combination meter terminal 15 for the speedometer
- to terminal 19 of the ABS actuator and electric unit (control unit).

The speedometer converts the voltage into the vehicle speed displayed.

With VDC

NAEL0297S0702

The ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter for the speedometer with CAN communication line.

CAN COMMUNICATION SYSTEM

NAEL0297S09

Combination meter receives vehicle speed signal and engine coolant temperature signal etc. from some control units with can communication line. Refer to "CAN COMMUNICATION" (EL-409).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

METERS AND GAUGES


Combination Meter/With Normal Meter

Combination Meter/With Normal Meter

NAEL0298



NAEL0298S01

CHECK



(For Canada)

(For USA)



Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W

(): Bulb socket color

- (U) : For USA
- (C) : For Canada
- (AW) : With all-mode 4-wheel drive
- (MP) : With M/T and part-time 4-wheel drive
- (A4) : With A/T and 4-wheel drive
- (TC) : With spare tire carrier
- (TW) : With low tire pressure warning system
- (AT) : With A/T
- (VD) : With VDC


MEL970R

METERS AND GAUGES

Combination Meter/With Normal Meter (Cont'd)

CONSTRUCTION

NAEL0298S02



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

METERS AND GAUGES

Combination Meter/With Fine Vision Meter (Cont'd)

CONSTRUCTION

NAEL0486S02



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


METERS AND GAUGES

Schematic/With Normal Meter

NAEL0299

Schematic/With Normal Meter

- (A)** : With A/T
- (C)** : For Canada
- (TC)** : With spare tire carrier
- (4W)** : With 4-wheel drive
- (AW)** : With all-mode 4-wheel drive
- (A4)** : With A/T and 4-wheel drive
- (VD)** : With VDC
- (TW)** : With low tire pressure warning system



MEL972R


METERS AND GAUGES

Schematic/With Fine Vision Meter

Schematic/With Fine Vision Meter

NAEL0487

- (C)** : For Canada
- (4W)** : With 4-wheel drive
- (VD)** : With VDC



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL973R


METERS AND GAUGES

Wiring Diagram — METER —

Wiring Diagram — METER —

NAEL0300

EL-METER-01



REFER TO THE FOLLOWING.

- (E1), (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)
- (F203) -ELECTRICAL UNITS

MEL940R

METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NAEL0301

DIAGNOSIS FUNCTION


NAEL0301S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.


HOW TO ALTERNATE DIAGNOSIS MODE

NAEL0301S02

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Push odo/trip meter switch 1 second.
5. Release odo/trip meter switch.
6. Push odo/trip meter switch more than three times. (Within 7 seconds after the ignition switch is turned ON.)



SEL176W



SEL177W

7. All odo/trip meter segments should be turned on.

NOTE:

If some segments are not turned on, unified meter control unit with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.

8. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE:

It takes about a few seconds for indication of fuel gauge and water temperature gauge to become stable.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


METERS AND GAUGES

Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK FOR NORMAL METER

NAEL0302

NAEL0302S01



SEL494Y

*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-133)

*2: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-137)

*3: Symptom Chart (EL-134)

SYMPTOM CHART FOR NORMAL METER

NAEL0302S02

Symptom	Possible causes	Repair order
One of speedometer/tachometer/fuel gauge/water temp. gauge is malfunctioning.	1. Sensor signal - Vehicle speed signal - Engine speed signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL WITH VDC (Refer to EL-137.) INSPECTION/VEHICLE SPEED SIGNAL WITHOUT VDC (Refer to EL-138.) INSPECTION/ENGINE SPEED SIGNAL (Refer to EL-138.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-139.) INSPECTION/WATER TEMPERATURE SIGNAL (Refer to EL-140.)
Multiple meter/gauge are malfunctioning. (except odo/trip meter)		2. Replace unified meter control unit assembly.


Before starting trouble diagnoses below, perform PRELIMINARY CHECK FOR NORMAL METER, EL-134.

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK FOR FINE VISION METER

NAEL0302S12



*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-133)
 *2: METER/GAUGE RESISTANCE CHECK FOR FINE VISION METER (EL-140)

*3: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-137)
 *4: Symptom Chart 1 (EL-136)

*5: Symptom Chart 2 (EL-136)

SEL361W

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART FOR FINE VISION METER Symptom Chart 1 (Malfunction is Indicated in Diagnosis Mode)

NAEL0302S13

NAEL0302S1301



Symptom	Possible causes	Repair order
Odo/trip meter indicate(s) malfunction in Diagnosis mode.	Unified meter control unit	Replace unified meter control unit.
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of speedometer/tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ol style="list-style-type: none"> Meter/Gauge Unified meter control unit 	<ol style="list-style-type: none"> Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK FOR FINE VISION METER", EL-140. If the resistance of meter/gauge is OK, replace unified meter control unit.

Symptom Chart 2 (No Malfunction is Indicated in Diagnosis Mode)

NAEL0302S1302

Symptom	Possible causes	Repair order
One of speedometer/tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> Sensor signal <ul style="list-style-type: none"> Vehicle speed signal Engine revolution signal Fuel gauge Water temp. gauge Unified meter control unit 	<ol style="list-style-type: none"> Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL WITH VDC (Refer to EL-137.) INSPECTION/VEHICLE SPEED SIGNAL WITHOUT VDC (Refer to EL-138.) INSPECTION/ENGINE SPEED SIGNAL (Refer to EL-138.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-139.) INSPECTION/WATER TEMPERATURE SIGNAL (Refer to EL-140.) Replace unified meter control unit assembly.
Multiple meter/gauge are malfunctioning. (except odo/trip meter)		

Before starting trouble diagnoses below, perform PRELIMINARY CHECK FOR FINE VISION METER, EL-135.



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NAEL0302S03

Power Supply Circuit Check

NAEL0302S0301

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
M25*	31 (G/R)	Ground	0V	Battery voltage	Battery voltage
M26	62 (G/R)	Ground	Battery voltage	Battery voltage	Battery voltage
	66 (W/B)	Ground	0V	0V	Battery voltage

*: With fine vision meter

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 10A fuse [No. 8, located in fuse block (J/B)]
- 10A fuse [No. 9, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter

Ground Circuit Check

NAEL0302S0302

Terminals			Continuity
(+)		(-)	
Connector	Terminal (wire color)		
M26	59 (B)	Ground	Yes

INSPECTION/VEHICLE SPEED SIGNAL WITH VDC

NAEL0302S11

1	CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) OUTPUT	
Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to BR-103, "CONSULT-II Functions".		
OK or NG		
OK	▶	Replace combination meter.
NG	▶	Check ABS actuator and electric unit (control unit). Refer to BR-91, "Trouble Diagnosis".



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/VEHICLE SPEED SIGNAL WITHOUT VDC

=NAEL0302S04

1	CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) OUTPUT SIGNAL	
<p> With CONSULT-II</p> <ol style="list-style-type: none"> Lift up drive wheels. Start engine and drive vehicle at more than 20 km/h (12 MPH). Check signal between combination meter harness connector M24 terminal 15 (G/Y) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.) 		
		
SEL938W		
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> Lift up drive wheels. Start engine and drive vehicle at more than 20 km/h (12 MPH). Check voltage between combination meter harness connector M24 terminal 15 (G/Y) and ground when rotating wheels with engine at idle. 		
		
Combination meter connector		Voltage: Approx. 0 - 5V
		
OK or NG		
OK	▶	ABS actuator and electric unit (control unit) is OK.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> Harness for open or short between ABS actuator and electric unit (control unit) and combination meter. ABS actuator and electric unit (control unit). Refer to BR-56, "Wheel Sensor or Rotor".

SEL939WB


INSPECTION/ENGINE SPEED SIGNAL

NAEL0302S05


1	CHECK ECM SELF-DIAGNOSIS	
Perform ECM self-diagnosis. Refer to EC-78, "Emission-related Diagnostic Information".		
OK or NG		
OK	▶	Replace combination meter.
NG	▶	Perform "Diagnostic Procedure" for displayed DTC.

INSPECTION/FUEL LEVEL SENSOR UNIT

=NAEL0302S06

1	CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT	<ol style="list-style-type: none"> 1. Turn ignition switch to OFF position. 2. Disconnect combination meter connector and fuel level sensor connector. 3. Check continuity between combination meter harness connector M24 terminal 23 (B) and fuel level sensor unit harness connector B12 terminal 2 (B). 4. Check continuity between combination meter harness connector M24 terminal 23 (B) and ground. <div style="display: flex; justify-content: space-around; align-items: flex-start; margin-top: 10px;"> <div style="text-align: center;">  <p>Combination meter connector</p> </div> <div style="text-align: center;">  <p>Fuel level sensor unit connector</p> </div> <div style="margin-left: 20px;"> <p>Continuity:</p> <p>Combination meter terminal 23 and fuel level sensor unit terminal 2</p> <p style="padding-left: 20px;">Yes</p> <p>Combination meter terminal 23 and ground</p> <p style="padding-left: 20px;">No</p> </div> </div>  <p style="text-align: right; margin-top: 10px;">SEL794Y</p>
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair harness or connector.

2	CHECK FUEL LEVEL SENSOR UNIT	<p>Refer to "FUEL LEVEL SENSOR UNIT CHECK" (EL-140).</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>
OK	▶	GO TO 3.
NG	▶	Replace fuel level sensor unit.

3	CHECK HARNESS FOR OPEN OR SHORT	<ol style="list-style-type: none"> 1. Disconnect combination meter connector and fuel level sensor unit connector. 2. Check continuity between combination meter harness connector terminal 17 and fuel level sensor unit harness connector terminal 3. 3. Check continuity between combination meter harness connector terminal 17 and ground. <div style="display: flex; justify-content: space-around; align-items: flex-start; margin-top: 10px;"> <div style="text-align: center;">  <p>Combination meter connector (M24)</p> </div> <div style="text-align: center;">  <p>Fuel level sensor unit connector (B12)</p> </div> <div style="margin-left: 20px;"> <p>Continuity:</p> <p>Combination meter terminal 17 and fuel level sensor unit terminal 3</p> <p style="padding-left: 20px;">Yes</p> <p>Combination meter terminal 17 and ground</p> <p style="padding-left: 20px;">No</p> </div> </div>  <p style="text-align: right; margin-top: 10px;">SEL300X</p>
OK or NG		
OK	▶	Fuel level sensor unit is OK.
NG	▶	Repair harness or connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/WATER TEMPERATURE SIGNAL

NAEL0302S07

1	CHECK ECM SELF-DIAGNOSIS	
Perform ECM self-diagnosis. Refer to EC-78, "Emission-related Diagnostic Information".		
OK or NG		
OK	▶	Replace combination meter.
NG	▶	Perform "Diagnostic Procedure" for display DTC.

Electrical Components Inspection



METER/GAUGE RESISTANCE CHECK FOR FINE VISION METER

NAEL0303

NAEL0303S05

Check resistance between installation screws of meter/gauge.

Screws		Resistance value Ω
Tacho/Speedometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 190 - 260
B - D	B - C	Approx. 230 - 310



FUEL LEVEL SENSOR UNIT CHECK

NAEL0303S02


- For removal, refer to FE-4, "FUEL SYSTEM".
- Check the resistance between terminals 3 and 2.

Ohmmeter		Float position mm (in)			Resistance value Ω
(+)	(-)				
3	2	*1	Full	95 (3.74)	Approx. 4 - 6
		*2	1/2	184 (7.24)	Approx. 31 - 34
		*3	Empty	265 (10.43)	Approx. 80 - 83

*1 and *3: When float rod is in contact with stopper.

System Description

GI
NAEL0304



This unit displays following items:

- Earth magnetism and heading direction of vehicle.
- Outside air temperature.
- Caution for frozen road surfaces.

OUTSIDE TEMPERATURE DISPLAY

Push the switch when the ignition key is in the “ACC” or “ON” position. The outside temperature will be displayed in “°F”. NAEL0304S01

- Selecting the indication range
Push the switch to change from “°F” to “°C”.
- When the outside temperature drops below freezing point, ICE is displayed on the unit.
- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F).
- When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only “---” though it is operating. This is not a problem.
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds. (This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
 - c) The ignition key has been turned to the “OFF” position for more than 4 hours. (The engine is cold.)

DIRECTION DISPLAY

Push the switch when the ignition key is in the “ACC” or “ON” position. The direction will be displayed. NAEL0304S02

MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL



IDX

COMPASS AND THERMOMETER

Wiring Diagram — COMPAS —

Wiring Diagram — COMPAS —

NAEL0305



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)
- (E142) -ELECTRICAL UNITS

Trouble Diagnoses

NAEL0306

PRELIMINARY CHECK FOR THERMOMETER

NAEL0306S01

1	COOL DOWN CHECK	
1. Turn the ignition key switch to the "ACC" position. 2. Cool down the ambient air temperature sensor with water or ice, so that the indicated temperature falls.		
Does the indicated temperature fall?		
Yes	▶	GO TO 2.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

2	WARM UP CHECK	
1. Leave the vehicle for 10 minutes, so that the indicated temperature rises. 2. With the ignition key in the "ACC" position, disconnect and reconnect the ambient air temperature sensor connector.		
Does the indicated temperature rise?		
Yes	▶	The system is OK.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

NOTE:

- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F). When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "---".
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
 - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
 - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds. (This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
 - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

INSPECTION/COMPASS AND THERMOMETER

NAEL0306S02

Symptom	Possible causes	Repair order
No display at all	1. 10A fuse 2. Ground circuit 3. Compass and thermometer	1. Check 10A fuse [No. 9, located in fuse block (J/B)]. Turn the ignition switch ON and verify that battery positive voltage is at terminal 7 of compass and thermometer. 2. Check ground circuit for compass and thermometer. 3. Replace compass and thermometer.
Forward direction indication slips off the mark or incorrect.	1. In manual correction mode (Bar and display vanish.) 2. Zone variation change is not done.	1. Drive the vehicle and turn at an angle of 90°. 2. Perform the zone variation change.
Compass reading remains unchanged.	1. Vehicle speed signal is not entered. 2. Compass and thermometer	1. Check harness for open or short between combination meter terminal 13 and compass and thermometer terminal 1. 2. Replace compass and thermometer.
Displays wrong temperature when ambient temperature is between -30°C (-20°F) and 55°C (130°F). (See NOTE above.)	1. Check operation 2. Ambient air temperature sensor circuit 3. Vehicle speed signal is not entered. 4. Ambient air temperature sensor 5. Compass and thermometer	1. Perform preliminary check shown above. 2. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 3. Check harness for open or short between combination meter terminal 13 and compass and thermometer terminal 1. 4. Replace ambient air temperature sensor. 5. Replace compass and thermometer.


COMPASS AND THERMOMETER

Calibration Procedure for Compass

NAEL0307

The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.

Zone Variation Chart




The chart shows magnetic declination zones across North America, numbered 1 through 15. Zone 1 is in the northwest, zone 2 in the north, zone 3 in the north-central, zone 4 in the central, zone 5 in the south-central, zone 6 in the south, zone 7 in the southeast, zone 8 in the south-southeast, zone 9 in the east-southeast, zone 10 in the east, zone 11 in the northeast, zone 12 in the north-northeast, zone 13 in the north-northwest, zone 14 in the northwest, and zone 15 in the north-northwest.

1. Determine your location on the zone map. Record your zone number.
2. Turn the ignition switch to ACC or ON position.
3. Push the "Mode" switch continuously for five seconds until the current zone entry number is displayed.
4. Press the "Mode" switch repeatedly until the desired zone number is displayed.

Once the desired zone number is displayed, stop pressing the "Mode" switch and the display will show compass direction after a few seconds.

SEL738UA



CORRECTION FUNCTIONS OF COMPASS

NAEL0307S01

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

INITIAL CORRECTION PROCEDURE FOR COMPASS

NAEL0307S02

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The direction bar starts blinking.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.

NOTE:


In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.

WARNING LAMPS

Schematic/With Normal Meter

Schematic/With Normal Meter

NAEL0308



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)

EL-WARN-02

TC : With spare tire carrier

COMBINATION METER (M24) , (M26)



REFER TO THE FOLLOWING.
 (E1) , (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC

EL



MEL942R

IDX

WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)

EL-WARN-03




REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)

EL-WARN-04



REFER TO THE FOLLOWING.



E1 -SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)

EL-WARN-05



REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL985P



WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)

EL-WARN-06

- VD : With VDC
- XA : With A/T and 4-wheel drive without VDC
- PW : With A/T and part-time 4-wheel drive
- AW : With all-mode 4-wheel drive
- A4 : With A/T and 4-wheel drive

- *1 Y/R : PW
- L/B : AW



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC



EL

MEL944R

WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)





EL-WARN-07



MEL987P

WARNING LAMPS

Wiring Diagram — WARN —/With Normal Meter (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MEL988P

WARNING LAMPS

Schematic/With Fine Vision Meter

Schematic/With Fine Vision Meter

NAEL0488



MEL962R

WARNING LAMPS



Wiring Diagram — WARN —/With Fine Vision Meter

Wiring Diagram — WARN —/With Fine Vision Meter

NAEL0489

EL-WARN-09

-  : DATA LINE
-  : For Canada
-  : With 4-wheel drive



REFER TO THE FOLLOWING.




-  -SUPER MULTIPLE JUNCTION (SMJ)
-  -FUSE BLOCK-JUNCTION BOX (J/B)
-  -ELECTRICAL UNITS

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING LAMPS

Wiring Diagram — WARN —/With Fine Vision Meter (Cont'd)

EL-WARN-10




REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

MEL964R

WARNING LAMPS


Wiring Diagram — WARN —/With Fine Vision Meter (Cont'd)

EL-WARN-11



U : For USA
C : For Canada

COMBINATION METER
M24 , M26



REFER TO THE FOLLOWING.
E1 , B1 -SUPER
MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL



MEL965R

IDX

WARNING LAMPS

Wiring Diagram — WARN —/With Fine Vision Meter (Cont'd)

EL-WARN-12





REFER TO THE FOLLOWING.
 (E1) -SUPER MULTIPLE JUNCTION (SMJ)

WARNING LAMPS

Wiring Diagram — WARN — With Fine Vision Meter (Cont'd)

EL-WARN-13




REFER TO THE FOLLOWING.
 (B1) - SUPER MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

WARNING LAMPS





Wiring Diagram — WARN —/With Fine Vision Meter (Cont'd)



EL-WARN-14

- ◊4V : With 4 wheel drive and VDC
- ◊4O : With 4-wheel drive without VDC
- ◊4W : With 4-wheel drive

Refer to EL-POWER.



REFER TO THE FOLLOWING.



(M10) - FUSE BLOCK-
 JUNCTION BOX (J/B)

WARNING LAMPS

Wiring Diagram — WARN — With Fine Vision Meter (Cont'd)

EL-WARN-15

⬡4W : With 4-wheel drive



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

MEL969R

IDX


WARNING LAMPS

Wiring Diagram — WARN —/With Fine Vision Meter (Cont'd)



MEL945R

WARNING LAMPS



Fuel Warning Lamp Sensor Check

NAEL0310

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector B12.
3. Connect a resistor (80Ω) between fuel tank gauge unit harness connector terminals 2 and 3.
4. Turn ignition switch "ON".

The fuel warning lamp should come on.

NOTE:

ECM might store the 1st trip DTC P0180 during this inspection. If the DTC is stored in ECM memory, erase the DTC after reconnecting fuel tank gauge unit harness connector. Refer to EC-78, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

GI

MA

EM

LC


EC

FE

CL

MT

AT



Electrical Components Inspection

NAEL0311

OIL PRESSURE SWITCH CHECK

NAEL0311S01

Condition	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine running	More than 10 - 20 (0.1 - 0.2, 1 - 3)	No
Engine stopped	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	Yes

Check the continuity between the terminals of oil pressure switch and body ground.

PD

AX


SU

BR

ST

RS

BT



DIODE CHECK

NAEL0311S02

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.
- Check diodes at the combination meter harness connector instead of checking them on the combination meter assembly. Refer to EL-146, "WARNING LAMP" wiring diagrams.

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.

HA

SC

EL


IDX

WARNING CHIME

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0312



System Description

NAEL0313

The warning chime is controlled by the smart entrance control unit.
The warning chime is located in the smart entrance control unit.
Power is supplied at all times

- through 7.5A fuse [No. 24, located in fuse block (J/B)]
- to smart entrance control unit terminal 49 and
- to key switch terminal 2,
- through 10A fuse (No. 61, located in the fuse and fusible link box
- to tail lamp relay terminals 1 and 3.

When the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

IGNITION KEY WARNING CHIME

When the key in the ignition switch in the OFF position, and the driver's door open, the warning chime will sound. Power is supplied

NAEL0313S01

WARNING CHIME

System Description (Cont'd)

- from key switch terminal 1
- to smart entrance control unit terminal 25.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 1.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

LIGHT WARNING CHIME

When ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied.

- from tail lamp relay terminal 2
- to smart entrance control unit terminal 19 and 57.

Ground is supplied

- from front door switch LH terminal 1
- to smart entrance control unit terminal 1.

Front door switch LH terminal 2 is grounded through body grounds B11, B22 and D210.

SEAT BELT WARNING CHIME

With ignition switch turned ON and seat belt unfastened (seat belt buckle switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied

- from seat belt buckle switch terminal 1
- to smart entrance control unit terminal 28.

Seat belt switch terminal 2 is grounded through body grounds B11, B22 and D210.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX





WARNING CHIME

Wiring Diagram — CHIME —

Wiring Diagram — CHIME —

NAEL0314

EL-CHIME-01



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)

(M10), (E3) - FUSE BLOCK - JUNCTION BOX (J/B)







MEL989P

WARNING CHIME

Wiring Diagram — CHIME — (Cont'd)

EL-CHIME-02




REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL990P

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING CHIME




CONSULT-II Inspection Procedure “KEY WARN ALM”/“LIGHT WARN ALM”/“SEAT BELT ALM”


=NAEL0315

NAEL0315S01


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “KEY WARN ALM”, “LIGHT WARN ALM” or “SEAT BELT ALM”.



7. Select diagnosis mode.
“DATA MONITOR” and “ACTIVE TEST” are available for the warning chime.

WARNING CHIME

CONSULT-II Application Items

CONSULT-II Application Items

“KEY WARNING ALARM”

NAEL0316

Data Monitor

NAEL0316S01

NAEL0316S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW DR	Indicates [ON/OFF] condition of front door switch LH.

Active Test

NAEL0316S0102

Test Item	Description
CHIME	This test is able to check key warning chime operation. Key warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

“LIGHT WARN ALM”

NAEL0316S02

Data Monitor

NAEL0316S0201

Monitored Item	Description
LIGHT SW 1ST	Indicates [ON/OFF] condition of lighting switch.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

Active Test

NAEL0316S0202

Test Item	Description
CHIME	This test is able to check light warning chime operation. Light warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

“SEAT BELT WARM ALM”

NAEL0316S03

Data Monitor

NAEL0316S0301

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt switch.

Active Test

NAEL0316S0302

Test Item	Description
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WARNING CHIME


Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NAEL0317

NAEL0317S01

REFERENCE PAGE (EL-)	170	172	173	174	175
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X	X			X
Ignition key warning chime does not activate.	X		X		X
Seat belt warning chime does not activate.	X			X	X
All warning chimes do not activate.	X				X



POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check

NAEL0317S02

NAEL0317S0201


Terminals			Voltage
(+)		(-)	
Connector	Terminal (Wire color)		
M123	49 (G/R)	Ground	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

WARNING CHIME

Trouble Diagnoses (Cont'd)



Ground Circuit Check

NAEL0317S0202

Terminals		(-)	Continuity
(+)	Terminal (Wire color)		
Connector		Ground	Yes
M122	43 (B)		
M123	64 (B)		

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)

-NAEL0317S03



1	CHECK LIGHTING SWITCH INPUT SIGNAL							
<p> With CONSULT-II Check lighting switch ("LIGHT SW 1ST") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> </thead> <tbody> <tr> <td>LIGHT SW 1ST</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		LIGHT SW 1ST	OFF
DATA MONITOR								
MONITOR								
LIGHT SW 1ST	OFF							
		<p>When lighting switch is in 1st or 2nd position: LIGHT SW 1ST ON</p> <p>When lighting switch is in OFF position: LIGHT SW 1ST OFF</p>						
SEL991X								
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 19 (R/G), connector M123 terminal 57 (R) and ground.</p>								
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Smart entrance control unit connector</p>  </div> <div style="flex: 1; padding-left: 20px;"> <p>Voltage [V]:</p> <p>Condition of lighting switch: 1ST or 2ND 0</p> <p>Condition of lighting switch: OFF Approx. 12</p> </div> </div>								
SEL992XA								
OK or NG								
OK	▶	Replace smart entrance control unit.						
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse (No. 61, located in the fuse and fusible link box) ● Harness for open or short between smart entrance control unit and tail lamp relay 						


WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)

-NAEL0317S04

1	CHECK KEY SWITCH INPUT SIGNAL								
<p> With CONSULT-II Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p>									
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table>		DATA MONITOR		MONITOR		KEY ON SW	ON	<p>When key is inserted to ignition key cylinder: KEY ON SW ON</p> <p>When key is removed from ignition key cylinder: KEY ON SW OFF</p>	
DATA MONITOR									
MONITOR									
KEY ON SW	ON								
SEL315W									
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p>									
<p>Smart entrance control unit connector</p> 		<p> CONNECT</p>  <p>Approx. 12V 0V</p>							
		<p>Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is removed. 0</p>							
SEL011Y									
OK or NG									
OK	▶	Replace smart entrance control unit.							
NG	▶	GO TO 2.							

2	CHECK KEY SWITCH (INSERT)		
Check continuity between key switch connector terminals 1 and 2.			
<p>Key switch connector </p> 		<p> DISCONNECT</p> 	
		<p>Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p>	
SEL308X			
OK or NG			
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between smart entrance control unit and key switch 	
NG	▶	Replace key switch.	


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)

-NAEL0317S05

1	CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL						
<p> With CONSULT-II Check seat belt buckle switch ("SEAT BELT SW") in "DATA MONITOR" mode with CONSULT-II.</p>							
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th></th></tr> <tr><td>SEAT BELT SW</td><td>ON</td></tr> </table>		DATA MONITOR		MONITOR		SEAT BELT SW	ON
DATA MONITOR							
MONITOR							
SEAT BELT SW	ON						
<p>When seat belt is fastened: SEAT BELT SW ON</p> <p>When seat belt is released: SEAT BELT SW OFF</p>							
SEL317W							
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between smart entrance control unit harness connector M122 terminal 28 (B/Y) and ground. 							
<p>Smart entrance control unit connector</p> 							
<p>Voltage [V]:</p> <p>Condition of seat belt buckle switch: Fastened Approx. 5</p> <p>Condition of seat belt buckle switch: Unfastened 0</p>							
SEL994X							
OK or NG							
OK	▶ Replace smart entrance control unit.						
NG	▶ GO TO 2.						

2	CHECK SEAT BELT BUCKLE SWITCH
Check continuity between seat belt buckle switch connector terminals 1 and 2 when seat belt is fastened and unfastened.	
<p>Seat belt buckle switch connector (B6)</p> 	
<p>Continuity:</p> <p>Seat belt is fastened. No</p> <p>Seat belt is unfastened. Yes</p>	
SEL381X	
OK or NG	
OK	▶ Check the following.
<ul style="list-style-type: none"> ● Seat belt buckle switch ground circuit ● Harness for open or short between smart entrance control unit and seat belt buckle switch 	
NG	▶ Replace seat belt buckle switch.

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

NAEL0317S06

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK IGNITION ON SIGNAL

With CONSULT-II

Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
IGN ON SW	ON


When ignition switch is ON:
IGN ON SW ON

When ignition switch is OFF:
IGN ON SW OFF

SEL318W

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B) and ground.



Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
27	Ground	0V	0V	Battery voltage

SEL995X

OK or NG



OK ► GO TO 2.


NG ► **Check the following.**

- 7.5A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

WARNING CHIME

Trouble Diagnoses (Cont'd)

2	CHECK DOOR SWITCH INPUT SIGNAL		
<p> With CONSULT-II Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>			
		<p>When driver's door is open: DOOR SW-DR ON</p> <p>When driver's door is closed: DOOR SW-DR OFF</p>	
SEL319W			
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/OR) and ground.</p>			
<p>Smart entrance control unit connector</p> 		<p>Voltage [V]: Condition of driver's door: CLOSED Approx. 5 Condition of driver's door: OPENED 0</p>	
SEL996X			
OK or NG			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

3	CHECK DRIVER SIDE DOOR SWITCH		
<p>Check continuity between front door switch LH connector terminals 1 and 2.</p>			
<p>Front door switch LH connector </p> 		<p>Continuity: Door switch is pushed. No Door switch is released. Yes</p>	
SEL383X			
OK or NG			
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Driver side door switch ground circuit and condition ● Harness for open or short between smart entrance control unit and front door switch LH 	
NG	▶	Replace front door switch LH.	

WARNING CHIME

Trouble Diagnoses (Cont'd)

4	CHECK WARNING CHIME									
<p> With CONSULT-II Perform "CHIME" in "ACTIVE TEST" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <table border="1"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>CHIME</td><td>OFF</td></tr> <tr><td colspan="2" style="height: 100px;"></td></tr> <tr><td>ON</td><td></td></tr> </table> </div> <div style="text-align: center; flex-grow: 1;"> <p>Warning chime should operate.</p> </div> <div style="text-align: right;"> <p>SEL320W</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p>			ACTIVE TEST		CHIME	OFF			ON	
ACTIVE TEST										
CHIME	OFF									
ON										
OK	▶	System is OK.								
NG	▶	Replace smart entrance control unit.								

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

FRONT WIPER AND WASHER

System Description

System Description

NAEL0318

NAEL0318S01

WIPER OPERATION

The front wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to front wiper motor terminal 1, and
- to front wiper switch terminal 15.

Low and High Speed Wiper Operation

NAEL0318S0101

Ground is supplied to front wiper switch terminal 17 through body grounds E13 and E41.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the front wiper switch
- to front wiper motor terminal 5.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the front wiper switch
- to front wiper motor terminal 3.

With power and ground supplied, the front wiper motor operates at high speed.

Auto Stop Operation

NAEL0318S0102

With front wiper switch turned OFF, front wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with front wiper switch OFF, ground is provided

- from terminal 14 of the front wiper switch
- to front wiper motor terminal 5, in order to continue front wiper motor operation at low speed.

Ground is also supplied

- to terminal 13 of the front wiper switch
- through front wiper motor terminal 4
- through terminal 6 of the front wiper motor, and
- through body grounds E13 and E41.

When wiper arms reach base of windshield, front wiper motor terminals 1 and 4 are connected instead of terminals 4 and 6. Wiper motor will then stop wiper arms at the PARK position.

Intermittent Operation

NAEL0318S0103

The front wiper motor operates the wiper arms one time at low speed at a set interval of approximately 2 to 13 seconds. This feature is controlled by the wiper amplifier built in the front wiper switch.

When the front wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier (INT SW)
- from front wiper switch terminal 17
- through body grounds E13 and E41,
- to front wiper motor terminal 5
- through the front wiper switch terminal 14 and
- through wiper amplifier (OUTPUT).

WASHER OPERATION

NAEL0318S02

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to front washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to front washer motor terminal 2
- through terminal 18 of the front wiper switch

FRONT WIPER AND WASHER

System Description (Cont'd)

- through terminal 17 of the front wiper switch, and
- through body grounds E13 and E41.

With power and ground supplied, the front washer motor operates.

When the lever is pulled to the WASH position for one second or more, the front wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



FRONT WIPER AND WASHER

Wiring Diagram — WIPER —


Wiring Diagram — WIPER —

NAEL0319

EL-WIPER-01



REFER TO THE FOLLOWING.
E4 - FUSE BLOCK-
JUNCTION BOX (J/B)



Removal and Installation

NAEL0320

WIPER ARMS

NAEL0320S01


1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".

Clearance "L₁": 29 - 39 mm (1.14 - 1.54 in)

Clearance "L₂": 32 - 42 mm (1.26 - 1.65 in)

- Tighten wiper arm nuts to specified torque.


Front wiper: 21 - 26 N·m (2.1 - 2.7 kg·m, 15 - 20 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

WIPER LINKAGE

NAEL0320S02



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT WIPER AND WASHER

Removal and Installation (Cont'd)

Removal

NAEL0320S0201

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation

NAEL0320S0202

- Grease ball joint portion before installation.



Installation is the reverse order of removal.

Washer Nozzle Adjustment

NAEL0321

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$



Unit: mm (in)

*1	251 (9.88)	*6	459 (18.07)
*2	351 (13.82)	*7	256 (10.08)
*3	165 (6.50)	*8	67 (2.64)
*4	269 (10.59)	*9	42 (1.65)
*5	167 (6.57)		

*A: The diameters of these circles are less than 80 mm (3.15 in).


*B: The diameters of these circles are less than 138 × 80 mm (5.43 × 3.15 in).

*C: The diameters of these circles are less than 96 × 80 mm (3.78 × 3.15 in).

*D: The diameters of these circles are less than 90 × 80 mm (3.54 × 3.15 in).

Washer Tube Layout

NAEL0322



System Description

WIPER OPERATION

Power Supply and Ground

Power is supplied at all times

- through 10A fuse [No. 5, located in fuse block (J/B)]
- to rear wiper motor terminal 1.

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 29, located in the fuse block (J/B)]
- to rear wiper motor terminal 4.

When the glass hatch switch is OPEN, ground is supplied

- to rear wiper motor terminal 6
- through glass hatch switch terminals 1 and 2
- through body grounds B11, B22 and D210.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

Wiper Operation

When the rear wiper switch is turned ON, ground is supplied

- to rear wiper motor terminal 2
- through combination switch terminals 22 and 24
- through body grounds E13 and E41.

Then, power is supplied

- to rear wiper motor terminal 4.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

With power and ground supplied, the wiper motor operates.

Auto Stop Operation

With rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arm reaches rear wiper stopper.

Then wiper motor turns the other way and wiper arm moves once until wiper arm reaches stopper.

Intermittent Operation

The rear wiper motor operates the wiper arms at low speed approximately every 7 seconds.

When the wiper switch is placed in the INT position, ground is supplied

- to rear wiper motor terminal 3
- through rear wiper switch terminals 21 and 24
- through body grounds E13 and E41.

Then, power is supplied

- to rear wiper motor terminal 4.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

With power and ground supplied, rear wiper operates at intermittent.

WIPER OPERATION PROHIBIT CONTROL

When glass hatch is open with back door key cylinder while rear wiper is operated, wiper operation is stopped. (Wiper operation prohibit control)

When glass hatch is closed and rear wiper switch turns from OFF and then rear wiper switch is turned to ON, wiper operation prohibit control is canceled.

WASHER OPERATION

When the rear wiper switch is turned to WASH position, ground is supplied

GI

NAEL0323

NAEL0323S01

MA

NAEL0323S0101

EM

LC

EC

FE

CL

NAEL0323S0102

MT

AT

TF

PD

AX

NAEL0323S0103

SU

BR

NAEL0323S0104

ST

RS

BT

HA

SC

NAEL0323S02

EL

IDX

NAEL0323S03

REAR WIPER AND WASHER

System Description (Cont'd)

- to rear wiper motor terminal 5
- through terminals 23 and 24
- through body grounds E13 and E41.

Then, power is supplied

- to rear washer motor terminal 2
- through 10 A fuse [No. 29, located in the fuse block (J/B)].

Ground is supplied

- to rear washer motor terminal 1
- through rear wiper switch terminals 23 and 24
- through body grounds E13 and E41.

With power and ground supplied, the rear washer motor operates.

When the rear wiper switch is turned to WASH position for 0.4 seconds or more, the rear wiper motor operates approximately 3 times after the rear wiper switch is released.



REAR WIPER AND WASHER

Wiring Diagram — WIP/R —

Wiring Diagram — WIP/R —

NAEL0324

EL-WIP/R-01



REFER TO THE FOLLOWING.
 (E1) , (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M81) , (M91) -FUSE BLOCK-
 JUNCTION BOX (J/B)



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL122S

REAR WIPER AND WASHER

Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-02



MEL993P

Trouble Diagnoses

NAEL0325

NAEL0325S01



REAR WIPER MOTOR INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition		Voltage (Approximate value)	
1	Power supply (BAT)		—	Battery voltage	
2	ON switch		Rear wiper switch	ON	Less than 1V
				OFF or INT	12V
3	Intermittent switch		Rear wiper switch	INT	Less than 1V
				OFF, ON or WASH	12V
4	Power supply (ACC)		—	Battery voltage	
5	Washer switch		Rear wiper switch	WASH	Less than 1V
				OFF, ON or INT	12V
6	Glass hatch switch		Glass hatch	Open	Less than 1V
				Closed	5V
7	Park switch		Trunk lid opener switch	ON	11.5V
				OFF	Battery voltage
8	Ground		—	—	

NOTE:

Power to the rear wiper motor will be interrupted when the rear glass hatch is opened. In that case, conduct the inspection of the rear wiper motor with the rear glass hatch closed, unless otherwise indicated.



Removal and Installation

NAEL0326

WIPER ARMS

NAEL0326S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Install wiper arm to portion A as in figure below and tighten wiper arm nut to specification.
3. Then, set wiper arm to portion B.


 : 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WIPER AND WASHER

Washer Nozzle Adjustment




Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.


Adjustable range: ±10° (In any direction)

NAEL0327



Washer Tube Layout


NAEL0328



Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.



NAEL0329



Wiring Diagram — HORN —

NAEL0330

EL-HORN-01



* : This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

Wiring Diagram — CIGAR —









NAEL0331

EL-CIGAR-01



- : For Canada
- : With woody instrument finisher
- : Without woody instrument finisher
- *1 5:
- 1:

REFER TO THE FOLLOWING.



- SUPER MULTIPLE JUNCTION (SMJ)
- FUSE BLOCK - JUNCTION BOX (J/B)

MEL946R


CLOCK

Wiring Diagram — CLOCK —

Wiring Diagram — CLOCK —


NAEL0332

EL-CLOCK-01



Refer to EL-POWER.

P/G → To EL-ILL



REFER TO THE FOLLOWING.
M10 - FUSE BLOCK-
JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MEL947R

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0333



SEL674YB

System Description

NAEL0334

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 20A fuse (No. 56, located in the fuse and fusible link box) and
- to rear window defogger relay terminal 6
- through 20A fuse (No. 57, located in the fuse and fusible link box)
- to smart entrance control unit terminal 49
- through 7.5A [No. 24, located in fuse block (J/B)].

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to the rear window defogger relay terminal 1, and
- to smart entrance control unit terminal 27.

Ground is supplied

- to terminal 1 of the rear window defogger switch (with auto A/C and normal meter, with manual A/C) or
- to terminal 32 of A/C auto amp. (with auto A/C and fine vision meter) and
- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

When the rear window defogger switch is turned ON, ground is supplied

REAR WINDOW DEFOGGER

System Description (Cont'd)

- through terminal 2 of the rear window defogger switch (with auto A/C and normal meter, with manual A/C) or
- through terminal 31 of A/C auto amp. (with auto A/C and fine vision meter)
- to smart entrance control unit terminal 14.

Terminal 37 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch (with auto A/C and normal meter, with manual A/C) or
- to terminal 30 of A/C auto amp. (with auto A/C and fine vision meter)
- from terminal 7 of the rear window defogger relay.

Terminal 4 of the rear window defogger switch (with auto A/C and normal meter, with manual A/C) or terminal 32 of A/C auto amp. (with auto A/C and fine vision meter) is grounded through body grounds M4, M66, M111, M147 and M157.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC



EL

IDX

REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02



REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL998P

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

WITH AUTO A/C AND FINE VISION METER

NAEL0335S02

EL-DEF-03





REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M10), (E3) -FUSE BLOCK-
 JUNCTION BOX (J/B)

MEL999P

REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-04



REFER TO THE FOLLOWING.


(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL001Q

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER

CONSULT-II Inspection Procedure




CONSULT-II Inspection Procedure

NAEL0336


NAEL0336S01

“REAR DEFOGGER”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “REAR DEFOGGER”.



7. Select diagnosis mode.
“DATA MONITOR” and “ACTIVE TEST” are available.

REAR WINDOW DEFOGGER

CONSULT-II Application Items

CONSULT-II Application Items

“REAR DEFOGGER” Data Monitor

NAEL0337

NAEL0337S01

NAEL0337S0101

GI

MA

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
REAR DEF SW	Indicates [ON/OFF] condition of rear window defogger switch.

EM

LC

Active Test

NAEL0337S0102

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger activates when “ON” on CONSULT-II screen is touched.

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


REAR WINDOW DEFOGGER

Trouble Diagnoses

Trouble Diagnoses DIAGNOSTIC PROCEDURE SYMPTOM: Rear window defogger does not activate, or does not go off after activating.


NAEL0338

NAEL0338S01

1	CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL
<p> With CONSULT-II Select "ACTIVE TEST" in "REAR DEFOGGER" with CONSULT-II.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>ACTIVE TEST</p> <p>REAR DEFOGGER OFF</p> <p style="background-color: black; color: white; padding: 2px;">ON</p> </div> <div style="text-align: center;"> <p>Rear window defogger and rear window defogger switch indicator should operate when the "ON" button on the CONSULT-II screen is touched.</p> </div> </div> <p style="text-align: right;">SEL353W</p>	
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to ON position. 2. Check voltage between smart entrance control unit harness connector M122 terminal 37 (G/B) and ground. <div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Voltage [V]:</p> <p>Rear window defogger switch is "OFF". Approx. 12</p> <p>Rear window defogger switch is "ON". 0</p> </div> </div> <p style="text-align: right;">SEL997X</p> <p style="text-align: center;">OK or NG</p>	
OK	<p>Check the following.</p> <ul style="list-style-type: none"> ● Rear window defogger relay (Refer to EL-203.) ● Rear window defogger circuit ● Rear window defogger filament (Refer to EL-204.)
NG	GO TO 2.

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

2	CHECK DEFOGGER RELAY COIL SIDE CIRCUIT	
<ol style="list-style-type: none"> 1. Disconnect smart entrance control unit connector. 2. Turn ignition switch to ON position. 3. Check voltage between smart entrance control unit harness connector M122 terminal 37 (G/B) and ground. 		
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;">  <p>Smart entrance control unit connector</p> </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> </div> <p style="text-align: right;">SEL998X</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 11, located in the fuse block (J/B)] ● Rear window defogger relay ● Harness for open or short between fuse and rear window defogger relay ● Harness for open or short between rear window defogger relay and smart entrance control unit

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC


EL

IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)


3	CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL							
<p> With CONSULT-II Select "REAR DEF SW" in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>REAR DEF SW</td><td>ON</td></tr> </table>			DATA MONITOR		MONITOR		REAR DEF SW	ON
DATA MONITOR								
MONITOR								
REAR DEF SW	ON							
<p>When rear window defogger switch is pushed: REAR DEF SW should be ON.</p>								
SEL352W								
<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 14 (OR) and ground.</p>								
								
<p>Voltage [V]: Rear window defogger switch is pushed. Approx. 5 Rear window defogger switch is released. 0</p>								
SEL685Y								
OK or NG								
OK	▶	GO TO 4.						
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Rear window defogger switch (Refer to EL-203.) ● Harness for open or short between smart entrance control unit and rear window defogger switch ● Rear window defogger switch ground circuit 						

4	CHECK POWER SUPPLY AND IGNITION INPUT SIGNAL																					
<p>Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B), M123 terminal 49 (G/R) and ground.</p>																						
																						
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>49</td> <td>Ground</td> <td>Battery voltage</td> <td>Battery voltage</td> <td>Battery voltage</td> </tr> <tr> <td>27</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table>			Terminals		Ignition switch position			(+)	(-)	OFF	ACC	ON	49	Ground	Battery voltage	Battery voltage	Battery voltage	27	Ground	0V	0V	Battery voltage
Terminals		Ignition switch position																				
(+)	(-)	OFF	ACC	ON																		
49	Ground	Battery voltage	Battery voltage	Battery voltage																		
27	Ground	0V	0V	Battery voltage																		
SEL001Y																						
OK or NG																						
OK	▶	GO TO 5.																				
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 11 or No. 24, located in the fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse 																				

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

5	CHECK CONTROL UNIT GROUND CIRCUIT	
<p>Check continuity between smart entrance control unit harness connector M122 terminal 43 (B), M123 terminal 64 (B) and ground.</p>		
SEL002Y		
Yes	▶	Replace smart entrance control unit.
No	▶	Repair harness or connectors.



Electrical Components Inspection


REAR WINDOW DEFOGGER RELAY

NAEL0339

Check continuity between terminals 3 and 5, 6 and 7.

NAEL0339S01

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



REAR WINDOW DEFOGGER SWITCH

With Auto A/C and Normal Meter, and With Manual A/C

NAEL0339S02

NAEL0339S0201


Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REAR WINDOW DEFOGGER


Electrical Components Inspection (Cont'd)



With Auto A/C and Fine Vision Meter


Check voltage between A/C auto amp. and ground, when rear window switch is pushed and released. =NAEL0339S0202

Terminals			Condition	Voltage (V)
(+)		(-)		
Connector	Terminal (Wire color)	(-)		
M102	31 (OR)	Ground	Rear window defogger switch is pushed	0
			Rear window defogger switch is released	12



Filament Check


1. Attach probe circuit tester (in volt range) to middle portion of each filament. NAEL0340



2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

REAR WINDOW DEFOGGER

Filament Check (Cont'd)



- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

GI
MA
EM
LC
EC

Filament Repair


REPAIR EQUIPMENT

NAEL0341

NAEL0341S01

- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth

FE
CL
MT



REPAIRING PROCEDURE

NAEL0341S02

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

AT
TF

Shake silver composition container before use.


3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in) of the break.

PD
AX
SU


4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

BR
ST

Do not touch repaired area while test is being conducted.



RS
BT



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

HA
SC

EL

IDX

System Description

NAEL0342

Refer to Owner's Manual for audio system operating instructions.

BASE SYSTEM

NAEL0342S01

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio unit terminal 6, and
- to CD player terminal 4 (with CD player).

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio unit terminal 10, and
- to CD player terminal 1 (with CD player).

Ground is supplied through the case of the audio unit.

When the audio unit power knob is pushed to the ON position, audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

BOSE SYSTEM

NAEL0342S02

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio unit terminal 6,
- to audio amp. relay terminal 3,
- to rear speaker amp. terminal 11 and
- to AUX box terminal 7 (with rear TV).

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio unit terminal 10,
- to AUX box terminal 6 (with rear TV).

Ground is supplied through the case of the audio unit.

Ground is supplied

- to audio amp. relay terminal 2,
- to front door speaker LH terminal 5 and
- to front door speaker RH terminal 5
- through body grounds M4, M66, M111, M147 and M157
- to rear speaker amp. terminal 24 and
- to AUX box terminal 8 (with rear TV)
- through body grounds B11, B22 and D210
- to rear TV switch terminal 3
- through body grounds M4, M66, M111, M147 and M157.

When the audio unit POWER button is pressed, power is supplied to rear speaker amp. terminal 9 and audio amp. relay terminal 1 from audio unit terminal 12. Then audio amp. relay is energized and power is supplied

- to front door speaker LH terminal 4 and
- to front door speaker RH terminal 4.

Audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 2 and 6 of the LH and RH front speakers and terminals 5, 7, 18 and 20 of the rear speaker amp.
- to LH and RH tweeters through terminals 1 and 3 of the front door speakers
- to rear LH and RH speakers through terminals 1, 2, 25 and 26 of the rear speaker amp.

AUDIO



Wiring Diagram — AUDIO —/Base System

Wiring Diagram — AUDIO —/Base System

NAEL0343

EL-AUDIO-01

Ⓢ : With CD player






REFER TO THE FOLLOWING.
 (M10), (M81) - FUSE BLOCK - JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUDIO

Wiring Diagram — AUDIO —/Base System (Cont'd)

EL-AUDIO-02




REFER TO THE FOLLOWING.

(B1) -SUPER
MULTIPLE JUNCTION (SMJ)

MEL038M

Schematic/BOSE System

NAEL0344



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

MEL002Q

IDX

AUDIO

Wiring Diagram — AUDIO —/BOSE System



Wiring Diagram — AUDIO —/BOSE System

NAEL0345

EL-AUDIO-03

⬡RT⬡ : With rear TV

Refer to EL-POWER.





REFER TO THE FOLLOWING.
 (M10), (M81) - FUSE BLOCK-
 JUNCTION BOX (J/B)

AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)



EL-AUDIO-04



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)




REFER TO THE FOLLOWING.
 (B1) - SUPER MULTIPLE JUNCTION (SMJ)

AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)




EL-AUDIO-06



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)




MEL006Q


AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

EL-AUDIO-07



- : With rear TV
- : With woody instrument finisher
- : Without woody instrument finisher



REFER TO THE FOLLOWING.
 -SUPER MULTIPLE JUNCTION (SMJ)

MEL007Q

Trouble Diagnoses

NAEL0346

NAEL0346S01

AUDIO UNIT

Symptom	Possible causes	Repair order
Audio unit inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse Poor audio unit case ground Audio unit 	<ol style="list-style-type: none"> Check 10A fuse [No. 10, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of audio unit. Check audio unit case ground. Remove audio unit for repair.
Audio unit presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 15A fuse Audio unit 	<ol style="list-style-type: none"> Check 15A fuse [No. 4, located in fuse block (J/B)] and verify that battery positive voltage is present at terminal 6 of audio unit. Remove audio unit for repair.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor audio unit ground Audio unit 	<ol style="list-style-type: none"> Check antenna. Check audio unit ground. Remove audio unit for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Audio unit 	<ol style="list-style-type: none"> Check window antenna. Remove audio unit for repair.
Audio unit generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor audio unit ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Audio unit 	<ol style="list-style-type: none"> Check audio unit ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove audio unit for repair.
Audio unit generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor audio unit ground Antenna Accessory ground Faulty accessory 	<ol style="list-style-type: none"> Check audio unit ground. Check antenna. Check accessory ground. Replace accessory.

BASE SYSTEM

NAEL0346S02

Symptom	Possible causes	Repair order
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Audio unit output Speaker circuit Audio unit 	<ol style="list-style-type: none"> Check speaker. Check audio unit output voltages. Check wires for open or short between audio unit and speaker. Remove audio unit for repair.

BOSE SYSTEM

NAEL0346S03

Symptom	Possible causes	Repair order
Audio unit controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> 15A fuse Audio unit output Audio unit 	<ol style="list-style-type: none"> Check 15A fuse [No. 4, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of audio amp. relay. Check audio unit output voltage (Terminal 12). Remove audio unit for repair.
All front speakers are inoperative.	<ol style="list-style-type: none"> Audio amp. relay Audio amp. relay ground Amp. ON signal 	<ol style="list-style-type: none"> Check audio amp. relay. Check audio amp. relay ground (Terminal 2). Turn ignition switch ACC and audio unit ON. Verify battery positive voltage is present at terminal 1 of audio amp. relay.
Individual front speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker ground Power supply Audio unit output Speaker 	<ol style="list-style-type: none"> Check speaker ground (Terminal 5). Check power supply for speaker (Terminal 4). Check audio unit output voltage for speaker. Replace speaker.

AUDIO

Trouble Diagnoses (Cont'd)

Symptom	Possible causes	Repair order
Both rear speakers are inoperative.	<ol style="list-style-type: none">1. Poor rear speaker amp. ground2. Power supply3. Amp. ON signal4. Rear speaker amp.	<ol style="list-style-type: none">1. Check rear speaker amp. ground circuit.2. Check power supply for rear speaker amp. (Terminal 11).3. Turn ignition switch ACC and audio unit ON. Verify battery positive voltage is present at terminal 9 of rear speaker amp.4. Remove rear speaker amp. for repair.
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none">1. Speaker2. Audio unit/amp. output3. Speaker circuit4. Audio unit	<ol style="list-style-type: none">1. Check speaker.2. Check audio unit/amp. output.3. Check wires for open or short between audio unit/amp. and speakers.4. Remove audio unit for repair.

Inspection

NAEL0347

AUDIO UNIT AND AMP.

NAEL0347S01

All voltage inspections are made with:

- Ignition switch ON or ACC
- Audio unit ON
- Audio unit and amps. connected (If audio unit or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

ANTENNA

NAEL0347S02

Using a jumper wire, clip an auxiliary ground between antenna and body.

- If reception improves, check antenna ground (at body surface).
- If reception does not improve, check main feeder cable for short circuit or open circuit.

Audio Unit Removal and Installation

NAEL0348

1. Lock the CD changer unit mechanism (if so equipped) prior to removing a malfunctioning CD changer unit. Refer to "LOCKING CD CHANGER UNIT MECHANISM", EL-216.
2. Remove CD changer unit. Refer to BT-24, "INSTRUMENT PANEL ASSEMBLY".

LOCKING CD CHANGER UNIT MECHANISM

NAEL0348S01

CAUTION:

- **Prior to removing a malfunctioning CD changer unit that will be shipped for repair, the changer mechanism MUST BE LOCKED to prevent the mechanism from being damaged during shipping.**
 - **If a CD is jammed or unable to be removed from the unit, do NOT lock the changer mechanism. If the unit is to be shipped for repair, carefully package the unit to prevent vibration and shock.**
1. Eject and remove any CDs from the CD changer unit.
 2. Turn ignition switch OFF. Wait until CD changer unit display is off and mechanism stops moving (mechanism sound stops).
 3. Press any one of the disc selection buttons once. When a display shows on the CD changer unit, press the same disc selection button again within 5 seconds.
 - The changer mechanism will lock itself within 10 seconds.
 4. After mechanism stops moving (mechanism sound stops), disconnect the CD changer unit connectors.


NOTE:

After installing a new or remanufactured CD changer unit, switching the CD changer unit ON will automatically unlock the mechanism. A special unlocking procedure is not required.


Wiring Diagram — REMOTE —

NAEL0349

EL-REMOTE-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
 (E1) - SUPER MULTIPLE JUNCTION (SMJ)
 (M10) - FUSE BLOCK-JUNCTION BOX (J/B)

* : This connector is not shown in "HARNESS LAYOUT", EL section.

AUDIO ANTENNA

System Description

System Description

NAEL0350

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to power antenna terminal 6.

Ground is supplied to the power antenna terminal 2 through body grounds M4, M66, M111, M147 and M157.

When the audio unit is turned to the ON position, battery positive voltage is supplied

- through audio unit terminal 5
- to power antenna terminal 4.

The antenna raises and is held in the extended position.

When the audio unit is turned to the OFF position, battery positive voltage is interrupted

- from audio unit terminal 5
- to power antenna terminal 4.

The antenna retracts.


AUDIO ANTENNA

Wiring Diagram — P/ANT —

Wiring Diagram — P/ANT —

NAEL0351

EL-P/ANT-01



REFER TO THE FOLLOWING.
 (M10) - FUSE BLOCK -
 JUNCTION BOX (J/B)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

MEL009Q

AUDIO ANTENNA

Trouble Diagnoses

Trouble Diagnoses

NAEL0352



NAEL0352S01

POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 7.5A fuse Audio unit signal Grounds M4, M66, M111, M147 and M157 	<ol style="list-style-type: none"> Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal 6 of power antenna. Turn ignition switch and audio unit ON. Verify that battery positive voltage is present at terminal 4 of power antenna. Check grounds M4, M66, M111, M147 and M157.

Location of Antenna

NAEL0353



Antenna Rod Replacement REMOVAL


NAEL0354

NAEL0354S01

- Remove antenna nut and antenna base.

AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)



2. Withdraw antenna rod while raising it by operating antenna motor.


GI

MA

EM

LC

EC



INSTALLATION

NAEL0354S02

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

System Description

NAEL0355

NAEL0355S01

OUTLINE

Electric sunroof system consists of

- Sunroof switch
- Sunroof motor
- Smart entrance control unit

Smart entrance control unit controls retained power operation.

OPERATION

NAEL0355S02

The sunroof can be tilted up or down with the tilt switch.

The sunroof can be opened or closed automatically with the sunroof switch.

RETAINED POWER OPERATION

NAEL0355S04

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds

- to power window relay terminal 2
- from smart entrance control unit terminal 46.

Ground is always supplied

- to power window relay terminal 1
- through body grounds M4, M66, M111, M147 and M157.

When power and ground are supplied, power window relay continues to be energized, and the electrical sunroof can be operated.

When power is supplied, the electrical sunroof can be operated.

The retained power operation is canceled when the driver or passenger side door is opened.

RAP signal period can be changed by CONSULT-II. (EL-226)

INTERRUPTION DETECTION FUNCTION

NAEL0355S05

The CPU of sunroof motor monitors the sunroof motor operation and the sunroof position (full closed or other) for sunroof by the signals from encoder and limit switch in sunroof motor.

When sunroof motor detects interruption during the following close operation,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

sunroof switch controls the motor for open and the sunroof will operate about 150 mm (5.91 in).

POWER SUNROOF


Wiring Diagram — SROOF —

Wiring Diagram — SROOF —

NAEL0356


EL-SROOF-01


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (B1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M10) - FUSE BLOCK - JUNCTION BOX (J/B)






CONSULT-II Inspection Procedure

=NAEL0357


NAEL0357S01

“RETAINED PWR”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “RETAINED PWR”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER SUNROOF

CONSULT-II Application Items

CONSULT-II Application Items

NAEL0455

“RETAINED PWR”

NAEL0455S01

Data Monitor

NAEL0455S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

Active Test

NAEL0455S0102

Test Item	Description
RETAINED PWR	<p>This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system. Those systems can be operated when turning on “RETAINED PWR” on CONSULT-II screen even if the ignition switch is tuned OFF.</p> <p>NOTE: During this test, CONSULT-II can be operated with ignition switch “OFF” position. “RETAINED PWR” should be turned “ON” or “OFF” on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF for checking retained power operation. CONSULT-II might be stuck if “RETAINED PWR” is turned “ON” or “OFF” on CONSULT-II screen when ignition switch is OFF.</p>

Work Support

NAEL0455S0103

Work Item	Description
RETAINED PWR SET	<p>RAP signal's power supply period can be changed by mode setting. Selects RAP signal's power supply period between three steps.</p> <ul style="list-style-type: none"> ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (2 min.)

Trouble Diagnoses

NAEL0456

Symptom	Possible cause	Repair order
Power sunroof cannot be operated using any switch.	<ol style="list-style-type: none"> 1. 7.5A fuse, 40A fusible link and M145 circuit breaker 2. Power window relay ground circuit 3. Sunroof motor ground circuit 4. Power window relay 5. Sunroof motor circuit 6. Sunroof switch 7. Sunroof switch circuit 8. Sunroof motor 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 11, located in fuse block (J/B)], 40A fusible link (letter f, located in fuse and fusible link box) and M145 circuit breaker. Turn ignition switch “ON” and verify battery positive voltage is present at terminals 2 and 3 of power window relay and terminal 1 of sunroof motor. 2. Check power window relay ground circuit. 3. Check sunroof motor ground circuit. 4. Check power window relay. 5. Check the wire between power window relay and sunroof motor. 6. Check sunroof switch. 7. Check harness between sunroof switch and sunroof motor. 8. Check sunroof motor.
Power sunroof cannot be operated using one of the sunroof switches.	<ol style="list-style-type: none"> 1. Sunroof switch 2. Sunroof switch circuit 	<ol style="list-style-type: none"> 1. Check sunroof switch. 2. Check the harness between sunroof motor and sunroof switch.

POWER SUNROOF

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Power sunroof cannot be opened or closed fully.	<ol style="list-style-type: none"> 1. Full closed position not initialized 2. Sunroof slide mechanism 3. Sunroof switch 4. Sunroof switch circuit 5. Sunroof motor 	<ol style="list-style-type: none"> 1. Initialize full closed position. 2. Check the following. <ol style="list-style-type: none"> a. Check obstacles in sunroof, etc. b. Check worn or deformed sunroof. c. Check sunroof sash tilted too far inward or outward. 3. Check sunroof switch. 4. Check harness between sunroof motor and sunroof switch. 5. Replace sunroof motor.
Retained power operation does not operate properly.	<ol style="list-style-type: none"> 1. RAP signal circuit 2. Driver or passenger side door switch circuit 3. Smart entrance control unit 	<ol style="list-style-type: none"> 1. Check RAP signal. <ol style="list-style-type: none"> a. (With CONSULT-II) Check RAP signal with CONSULT-II. Use "ACTIVE TEST" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-226.) If NG, go to the step b. below. b. Verify 12 positive voltage from smart entrance control unit is present at terminal 2 of power window relay: <ul style="list-style-type: none"> ● Within 45 seconds after ignition switch turns off. ● When front door LH and RH is closed. 2. Check harness between smart entrance control unit and driver or passenger side door switch. Check driver or passenger side door switch. Check driver or passenger side door switch. 3. Check smart entrance control unit. (EL-382)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DOOR MIRROR

Wiring Diagram — MIRROR —

Wiring Diagram — MIRROR —

NAEL0360

EL-MIRROR-01



REFER TO THE FOLLOWING.
 (M10) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MEL012Q



GLASS HATCH OPENER

Wiring Diagram — T&FLID —

Wiring Diagram — T&FLID —

NAEL0460

EL-T&FLID-01



REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M81) -FUSE BLOCK-JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



POWER SEAT

Wiring Diagram — SEAT —

Wiring Diagram — SEAT —

NAEL0361

EL-SEAT-01




REFER TO THE FOLLOWING.
 (E1), (B1) - SUPER
 MULTIPLE JUNCTION (SMJ)

MEL830L

POWER SEAT

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-02



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

MEL601F

IDX



HEATED SEAT

Wiring Diagram — HSEAT —

Wiring Diagram — HSEAT —

NAEL0362

EL-HSEAT-01



* : This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.


- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M91) -FUSE BLOCK-JUNCTION BOX (J/B)

MEL013Q

HEATED SEAT


Wiring Diagram — HSEAT — (Cont'd)

EL-HSEAT-02



W/B → A Next page

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC



REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M91) -FUSE BLOCK-JUNCTION BOX (J/B)

* : This connector is not shown in "HARNES LAYOUT", EL section.

EL

MEL950R


IDX

HEATED SEAT

Seatback Heating Unit

Seatback Heating Unit

NAEL0363



Trim temperature °C (°F)	Increasing to 35 - 45 (95 - 113)	Decreasing to 25 - 35 (77 - 95)
Thermostat operation	OFF	ON

SBT314

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

AUTOMATIC DRIVE POSITIONER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0364



SEL701Y

System Description

OPERATIVE CONDITION

The drive position can be set in 2 ways, manually and automatically.

Manual Operation

The driver's seat can be adjusted for sliding, reclining, front cushion height and rear cushion height with the LH power seat switches. The manual operation can be adjusted with the IGN key in any position.

Automatic Operation

The driver's seat is adjusted to the proper positions for the driver automatically, in 3 different ways: MEMORY AUTOMATIC SET, AUTOMATIC EXITING SETTING and AUTOMATIC SET RETURN. (Automatic Drive Positioner = ADP)

CONDITIONS INHIBITING AUTOMATIC OPERATION

Automatic memory setting procedures are suspended under any of the following conditions:

- 1) When vehicle speed is more than 7 km/h (4 MPH).
- 2) When driver's side power seat switch is turned on.
- 3) When any two of the switches (set switch and memory switches 1 and 2) are turned ON.
- 4) When cancel switch is turned on.
- 5) When selector lever is in any position other than "P".
- 6) When ignition switch is turned to "START" position.
(Operation resumes when ignition switch is returned to "ON".)
- 7) When detention switch malfunction is detected:
 - Detention switch failure is sensed when detention switch remains off for at least 2 seconds at a vehicle speed of greater than 7 km/h (4 MPH).

FAIL-SAFE SYSTEM

Output Failure

When the ignition switch is in the ON position, if any of the parts (indicated in the following chart) move more than the specified amount within a period "T2" when no "ON" input is sent from any of the switches (indicated in the following chart), or an output from the automatic drive positioner is not produced, an output failure is sensed. Motor operation will be suspended automatically, and all automatic operations will be ineffective. (In this case, the motor will not operate manually.)

OPERATED PORTION	T2	Allowable measurement
Seat sliding	Approx. 2.5 sec.	Within 6 mm (0.24 in)
Seat reclining	Same as above	Change angle within 1°

Absolving

When moving selector lever back to "P" position after having moved it to any position except "P", fail-safe operation will be canceled.

INITIALIZATION

After reconnecting battery cable, perform initialization procedure A or B. If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- 1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- 2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- 3) End

PROCEDURE B

- 1) Drive the vehicle at more than 25 km/h (16 MPH).
- 2) End

GI
=NAEL0365
NAEL0365S01
MA
EM
NAEL0365S0101
NAEL0365S0102
LC
EC
NAEL0365S02
FE
CL
MT
AT
TF
NAEL0365S03
NAEL0365S0301
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER


System Description (Cont'd)

MEMORY AUTOMATIC SET

=NAEL0365S05

Two drive positions can be retained in the memory. Press memory switch to set driver's seat to preset position.

PROCEDURE FOR STORING MEMORY




SEL592W

NOTE:

- When memory switch for which driver's seat positions are already retained in memory is pressed, new seat positions will be retained in memory in place of the previously set positions.
- Drive position is erased from the memory when battery cable is disconnected more than 30 seconds. After connecting battery cable, perform initialization procedures.

SELECTING THE MEMORIZED POSITION



SEL593W

AUTOMATIC DRIVE POSITIONER

System Description (Cont'd)

NOTE:

- 1) Do not keep cancel switch pressed as it will not operate.
- 2) Automatic exiting setting will be performed.
- 3) The driver's seat position (see the following Table) operates in the order of priority.


The order of priority	Operated portion
1	Seat sliding
2	Seat reclining
3	Seat front lifting
4	Seat rear lifting

AUTOMATIC EXITING SETTING

NAEL0365S06

“Exiting” positions:

Driver's seat ... Slides about 40 mm (1.57 in) rear from normal sitting position.




SEL594W

AUTOMATIC SET RETURN

NAEL0365S07

With driver's seat set to the “exiting” position, operating one of the following procedures moves it to the position previously retained in memory.



SEL595W


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER

Schematic

Schematic

NAEL0366



MEL016Q


AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP —

Wiring Diagram — AUT/DP —


NAEL0367

EL-AUT/DP-01



Refer to EL-POWER.

Next page



* : This connector is not shown in "HARNES LAYOUT", EL section.








REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M10), (E3) -FUSE BLOCK-
 JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-02



* : This connector is not shown in "HARNESS LAYOUT", EL section.

REFER TO THE FOLLOWING.







(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL018Q

AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-04





* : This connector is not shown in "HARNESS LAYOUT", EL section.

MEL186M

AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-05



* : This connector is not shown in "HARNESS LAYOUT", EL section.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MEL187M

AUTOMATIC DRIVE POSITIONER

On Board Diagnosis


On Board Diagnosis

NAEL0368



HOW TO PERFORM SELF-DIAGNOSIS

NAEL0368S01



SEL596W

*1: If no malfunction is indicated, self-diagnosis will end after the vehicle speed sensor diagnosis is performed.

*2: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.





AUTOMATIC DRIVE POSITIONER

On Board Diagnosis (Cont'd)

MALFUNCTION CODE TABLE

=NAEL0368S02

In this mode, a malfunction code is indicated by the number of flashes from the automatic drive positioner indicator lamps (indicator lamp 1, indicator lamp 2) as shown below.

Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation
1	Seat sliding	IND1, IND2 	While the seat motors are moving for 2.5 seconds, if the number of seat sliding/reclining/lifting encoder pulses changes 2 times or less, the seat device is determined to be malfunctioning.
2	Seat reclining	IND1, IND2 	
3	Seat lifting front	IND1, IND2 	
4	Seat lifting rear	IND1, IND2 	
9	Vehicle speed signal circuit	IND1, IND2 	If the vehicle speed signal output of less than 7 km/h (4 MPH) is detected, the ABS actuator and electric unit is determined to be malfunctioning.
-	No malfunction in the above items		—


SEL597WA

Code No.	Detected items	Diagnostic procedure	Reference page	Code No.	Detected items	Diagnostic procedure	Reference page
1	Seat sliding	PROCEDURE 2 (Sliding encoder check) PROCEDURE 6 (Sliding motor check)	EL-253 EL-261	4	Seat lifting rear	PROCEDURE 5 [Lifting encoder (rear) check] PROCEDURE 9 [Lifting motor (rear) check]	EL-259 EL-264
2	Seat reclining	PROCEDURE 3 (Reclining encoder check) PROCEDURE 7 (Reclining motor check)	EL-255 EL-262	9	Vehicle speed sensor	PROCEDURE 12 (Vehicle speed sensor check)	EL-267
3	Seat lifting front	PROCEDURE 4 [Lifting encoder (front) check] PROCEDURE 8 [Lifting motor (front) check]	EL-257 EL-263				

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses WORK FLOW



*1 EL-246


*2 EL-247

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK

NAEL0369S02



SEL600W

*1: After reconnecting battery cable, perform initialization procedure A or B.

If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- 1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- 2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- 3) End

PROCEDURE B

- 1) Drive the vehicle at more than 30 km/h (19 MPH).

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

2) End

After performing preliminary check, go to symptom chart below.

Before starting trouble diagnoses below, perform preliminary check, EL-249. Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

NAEL0369S03

PROCEDURE		Diagnostic procedure							
REFERENCE PAGE (EL-)		252	253	255	257	259	261	262	
SYMPTOM		DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for Driver's seat control unit)	DIAGNOSTIC PROCEDURE 2 (Sliding encoder check)	DIAGNOSTIC PROCEDURE 3 (Reclining encoder check)	DIAGNOSTIC PROCEDURE 4 [Lifting encoder (front) check]	DIAGNOSTIC PROCEDURE 5 [Lifting encoder (rear) check]	DIAGNOSTIC PROCEDURE 6 (Sliding motor check)	DIAGNOSTIC PROCEDURE 7 (Reclining motor check)	
1	No seat system functions operate.	X							
2	Some of the seat system functions do not operate during automatic/manual operation.	Sliding					X		
		Reclining						X	
		Lifting (Front)							
		Lifting (Rear)							
3	No functions operate during automatic operation, and some/all functions do not during manual operation.								
4	Some of the seat system functions do not operate during automatic operation.	Sliding		X					
		Reclining			X				
		Lifting (Front)				X			
		Lifting (Rear)					X		
5	No automatic operation functions operate.								
6	Drive position cannot be retained in the memory.								
7	Does not operate during manual operation. (Operates during automatic operation.)	Sliding							
		Reclining							
		Lifting (Front)							
		Lifting (Rear)							
8	Automatic operation cannot be canceled.								
9	Memory indicator does not light up.								

X : Applicable

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)


PROCEDURE		Diagnostic procedure						
REFERENCE PAGE (EL-)		263	264	265	266	267	270	270
SYMPTOM		DIAGNOSTIC PROCEDURE 8 [Lifting motor (front) check]	DIAGNOSTIC PROCEDURE 9 [Lifting motor (rear) check]	DIAGNOSTIC PROCEDURE 10 (Power seat switch check)	DIAGNOSTIC PROCEDURE 11 (Cancel switch check)	DIAGNOSTIC PROCEDURE 12 (Key, park position, door switch and vehicle speed sensor check)	DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)	DIAGNOSTIC PROCEDURE 14 (Memory indicator check)
1	No seat system functions operate.							
2	Some of the seat system functions do not operate during automatic/manual operation.	Sliding						
		Reclining						
		Lifting (Front)	X					
		Lifting (Rear)		X				
3	No functions operate during automatic operation, and some/all functions do not during manual operation.			X		X (ACC, ON START signal)		
4	Some of the seat system functions do not operate during automatic operation.	Sliding						
		Reclining						
		Lifting (Front)						
		Lifting (Rear)						
5	No automatic operation functions operate.				X	X		
6	Drive position cannot be retained in the memory.					X (IGN ON signal)	X	
7	Does not operate during manual operation. (Operates during automatic operation.)	Sliding			X			
		Reclining			X			
		Lifting (Front)			X			
		Lifting (Rear)			X			
8	Automatic operation cannot be canceled.				X			
9	Memory indicator does not light up.							X

X : Applicable

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 1

=NAEL0369S04

(Power supply and ground circuit for driver's seat control unit)

Power Supply Circuit Check


NAEL0369S0401

Check voltage between seat control unit LH terminal 1 and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
1 - Ground	Battery voltage			

If NG, check the following.

- 40A fusible link (letter f, located in the fuse and fusible link box)
- Circuit breaker
- Harness for open or short between circuit breaker and seat control unit LH



Ground Circuit Check

NAEL0369S0402

Check continuity between seat control unit LH terminal 33 and ground.

Terminals	Continuity
33 - Ground	Yes



AUTOMATIC DRIVE POSITIONER


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 (Sliding encoder check)

=NAEL0369S05

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1	CHECK SLIDING ENCODER OUTPUT SIGNAL	
<p>Measure voltage between seat control unit LH terminal 18 and ground with CONSULT-II or oscilloscope when power seat slide is operated.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (8512)</p>  </div> <div style="text-align: center;">  <p>HI: Approx. 5V LO: Approx. 0V</p> </div> </div>		
SEL603W		
OK or NG		
OK	▶	Sliding encoder is OK.
NG	▶	GO TO 2.

2	CHECK SLIDING ENCODER INPUT SIGNAL	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (8512)</p>  </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> </div>		
SEL604W		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

3	CHECK SLIDING ENCODER OPEN CIRCUIT												
<p>1. Disconnect seat control unit LH connector and sliding device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and sliding device LH connector.</p>													
<table border="1" style="margin-left: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Continuity</th> </tr> <tr> <th>Seat control unit LH</th> <th>Sliding device LH (Sliding encoder)</th> </tr> </thead> <tbody> <tr> <td>17</td> <td>3</td> <td rowspan="3" style="text-align: center;">Yes</td> </tr> <tr> <td>18</td> <td>4</td> </tr> <tr> <td>28</td> <td>5</td> </tr> </tbody> </table>		Terminals		Continuity	Seat control unit LH	Sliding device LH (Sliding encoder)	17	3	Yes	18	4	28	5
Terminals		Continuity											
Seat control unit LH	Sliding device LH (Sliding encoder)												
17	3	Yes											
18	4												
28	5												
SEL605WA													
OK or NG													
OK	▶	GO TO 4.											
NG	▶	Repair harness.											

4	CHECK SLIDING ENCODER SHORT CIRCUIT						
<p>Check harness continuity between seat control unit LH connector and ground.</p>							
<table border="1" style="margin-left: auto;"> <thead> <tr> <th>Terminals</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>17 - Ground</td> <td rowspan="3" style="text-align: center;">No</td> </tr> <tr> <td>18 - Ground</td> </tr> <tr> <td>28 - Ground</td> </tr> </tbody> </table>		Terminals	Continuity	17 - Ground	No	18 - Ground	28 - Ground
Terminals	Continuity						
17 - Ground	No						
18 - Ground							
28 - Ground							
SEL606W							
OK or NG							
OK	▶	Replace sliding encoder.					
NG	▶	Repair harness.					

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3 (Reclining encoder check)

=NAEL0369S06

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1	CHECK RECLINING ENCODER OUTPUT SIGNAL	
<p>Measure voltage between seat control unit LH terminal 29 and ground with CONSULT-II or oscilloscope when power seat reclining is operated.</p>		
SEL607W		
OK or NG		
OK	▶	Reclining encoder is OK.
NG	▶	GO TO 2.

2	CHECK RECLINING ENCODER INPUT SIGNAL	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
SEL608W		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

3	CHECK RECLINING ENCODER OPEN CIRCUIT												
<p>1. Disconnect seat control unit LH connector and reclining device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and reclining LH connector.</p>													
<table border="1" style="margin-left: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Continuity</th> </tr> <tr> <th>Seat control unit LH</th> <th>Reclining device LH (Reclining encoder)</th> </tr> </thead> <tbody> <tr> <td>17</td> <td>4</td> <td rowspan="3" style="text-align: center;">Yes</td> </tr> <tr> <td>28</td> <td>6</td> </tr> <tr> <td>29</td> <td>5</td> </tr> </tbody> </table>		Terminals		Continuity	Seat control unit LH	Reclining device LH (Reclining encoder)	17	4	Yes	28	6	29	5
Terminals		Continuity											
Seat control unit LH	Reclining device LH (Reclining encoder)												
17	4	Yes											
28	6												
29	5												
SEL609WA													
OK or NG													
OK	▶	GO TO 4.											
NG	▶	Repair harness.											

4	CHECK RECLINING ENCODER SHORT CIRCUIT						
<p>Check harness continuity between seat control unit LH connector and ground.</p>							
<table border="1" style="margin-left: auto;"> <thead> <tr> <th>Terminals</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>17 - Ground</td> <td rowspan="3" style="text-align: center;">No</td> </tr> <tr> <td>28 - Ground</td> </tr> <tr> <td>29 - Ground</td> </tr> </tbody> </table>		Terminals	Continuity	17 - Ground	No	28 - Ground	29 - Ground
Terminals	Continuity						
17 - Ground	No						
28 - Ground							
29 - Ground							
SEL610W							
OK or NG							
OK	▶	Replace reclining encoder.					
NG	▶	Repair harness.					

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

[Lifting encoder (front) check]

=NAEL0369S07

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

1	CHECK LIFTING ENCODER (FRONT) OUTPUT SIGNAL	
<p>Measure voltage between seat control unit LH terminal 19 and ground with CONSULT-II or oscilloscope when power seat lifting (front) is operated.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Seat control unit LH (B512)</p> </div> <div style="text-align: center;"> <p>HI: Approx. 5V LO: Approx. 0V</p> </div> </div>		
SEL611W		
OK or NG		
OK	▶	Lifting encoder (front) is OK.
NG	▶	GO TO 2.

2	CHECK LIFTING ENCODER (FRONT) INPUT SIGNAL	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;"> <p>Seat control unit LH (B512)</p> </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> </div>		
SEL612W		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

3	CHECK LIFTING ENCODER (FRONT) OPEN CIRCUIT	
<p>1. Disconnect seat control unit LH connector and front lifting device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and front lifting device LH connector.</p>		
		SEL613WA
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair harness.

Terminals		Continuity
Seat control unit LH	Front lifting device LH Lifting encoder (front)	
17	4	Yes
19	5	
28	6	

4	CHECK LIFTING ENCODER (FRONT) SHORT CIRCUIT	
Check harness continuity between seat control unit LH connector and ground.		
		SEL614W
OK or NG		
OK	▶	Replace lifting encoder (front).
NG	▶	Repair harness.

Terminals	Continuity
17 - Ground	No
19 - Ground	
28 - Ground	

DIAGNOSTIC PROCEDURE 5

[Lifting encoder (rear) check]

=NAEL0369S08

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1	CHECK LIFTING ENCODER (REAR) OUTPUT SIGNAL	
<p>Measure voltage between seat control unit LH terminal 30 and ground with CONSULT-II or oscilloscope when power seat lifting (rear) is operated.</p>		
SEL615W		
OK or NG		
OK	▶	Lifting encoder (rear) is OK.
NG	▶	GO TO 2.

2	CHECK LIFTING ENCODER (REAR) INPUT SIGNAL	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
SEL616W		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

3	CHECK LIFTING ENCODER (REAR) OPEN CIRCUIT	
<p>1. Disconnect seat control unit LH connector and rear lifting device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and rear lifting device LH connector.</p>		
		SEL617WA
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair harness.

Terminals		Continuity
Seat control unit LH	Rear lifting device LH Lifting encoder (rear)	
17	4	Yes
28	6	
30	5	

4	CHECK LIFTING ENCODER (REAR) SHORT CIRCUIT	
Check harness continuity between seat control unit LH connector and ground.		
		SEL618W
OK or NG		
OK	▶	Replace lifting encoder (rear).
NG	▶	Repair harness.

Terminals	Continuity
17 - Ground	No
28 - Ground	
30 - Ground	

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 (Sliding motor check)

=NAEL0369S09

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK OUTPUT SIGNAL TO SLIDING MOTOR

Check voltage between seat control unit LH terminals 3 or 10 and ground.

Condition of sliding switch	Terminals		Voltage [V]
	+	-	
Forward	3	Ground	Approx. 12
Backward	10	Ground	Approx. 12

SEL619W

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace seat control unit LH.

2 CHECK SLIDING MOTOR

1. Disconnect sliding device LH connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
+	-	
2	1	Forward
1	2	Backward

SEL620WA

OK or NG


OK	▶	Check harness for operation between seat control unit LH and sliding motor.
NG	▶	Replace sliding motor.

AUTOMATIC DRIVE POSITIONER


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 (Reclining motor check)

=NAEL0369S10

1	CHECK OUTPUT SIGNAL TO RECLINING MOTOR	<p>Check voltage between seat control unit LH terminals 4 or 12 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>CONNECT</p>  </div> <div style="text-align: center;">  <p>Seat control unit LH (8513)</p> </div> </div> <table border="1" style="margin-top: 20px; border-collapse: collapse; width: 40%;"> <thead> <tr> <th rowspan="2">Condition of reclining switch</th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>Forward</td> <td>4</td> <td>Ground</td> <td>Approx. 12</td> </tr> <tr> <td>Backward</td> <td>12</td> <td>Ground</td> <td>Approx. 12</td> </tr> </tbody> </table>		Condition of reclining switch	Terminals		Voltage [V]	+	-	Forward	4	Ground	Approx. 12	Backward	12	Ground	Approx. 12
Condition of reclining switch	Terminals		Voltage [V]														
	+	-															
Forward	4	Ground	Approx. 12														
Backward	12	Ground	Approx. 12														
OK or NG																	
OK	▶	GO TO 2.															
NG	▶	Replace seat control unit LH.															

SEL621W

2	CHECK RECLINING MOTOR	<p>1. Disconnect reclining device LH connector. 2. Apply 12V DC direct current to motor and check operation.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>DISCONNECT</p>  <p>Reclining device LH (8515)</p> </div> <table border="1" style="margin-top: 20px; border-collapse: collapse; width: 30%;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>3</td> <td>Forward</td> </tr> <tr> <td>3</td> <td>1</td> <td>Backward</td> </tr> </tbody> </table> </div>		Terminals		Operation	+	-	1	3	Forward	3	1	Backward
Terminals		Operation												
+	-													
1	3	Forward												
3	1	Backward												
OK or NG														
OK	▶	Check harness for operation between seat control unit LH and reclining motor.												
NG	▶	Replace reclining motor.												

SEL622WA

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

[Lifting motor (front) check]

=NAEL0369S11

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK OUTPUT SIGNAL TO LIFTING MOTOR (FRONT)

Check voltage between seat control unit LH terminals 5 or 13 and ground.

Condition of lifting switch (front)	Terminals		Voltage [V]
	+	-	
Up	13	Ground	Approx. 12
Down	5	Ground	Approx. 12

SEL623W

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace seat control unit LH.

2 CHECK LIFTING MOTOR (FRONT)

1. Disconnect front lifting device LH connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
+	-	
3	1	Up
1	3	Down

SEL624WA

OK or NG

OK	▶	Check harness for operation between seat control unit LH and lifting motor (front).
NG	▶	Replace lifting motor (front).

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

[Lifting motor (rear) check]

=NAEL0369S12

1	CHECK OUTPUT SIGNAL TO LIFTING MOTOR (REAR)	
<p>Check voltage between seat control unit LH terminals 6 or 7 and ground.</p>		
SEL625W		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace seat control unit LH.

2	CHECK LIFTING MOTOR (REAR)	
<p>1. Disconnect rear lifting device LH connector. 2. Apply 12V DC direct current to motor and check operation.</p>		
SEL626WA		
OK or NG		
OK	▶	Check harness for operation between seat control unit LH and lifting motor (rear).
NG	▶	Replace lifting motor (rear).


AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 10 (Power seat switch check)

=NAEL0369S13

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


1	CHECK POWER SEAT SWITCH	<p>1. Disconnect power seat switch LH connector. 2. Check continuity between power seat switch terminals.</p>																																																																																																																											
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Power seat switch LH (B514)</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>8</td><td>9</td><td>10</td></tr> </table> <p>1, 2, 3, 4, 5, 6, 9, 10</p>  </div> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Switch</th> <th rowspan="2">Condition</th> <th colspan="10">Terminals</th> </tr> <tr> <th>8</th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>9</th><th>10</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Sliding</td> <td>Forward</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>○</td> </tr> <tr> <td>Backward</td> <td>○</td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Reclining</td> <td>Forward</td> <td>○</td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Backward</td> <td>○</td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Lifting (Front)</td> <td>Up</td> <td>○</td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Down</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Lifting (Rear)</td> <td>Up</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td> </tr> <tr> <td>Down</td> <td>○</td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table> </div> </div>				1	2	3	4	5	6	8	9	10	Switch	Condition	Terminals										8	1	2	3	4	5	6	9	10	Sliding	Forward	○									○	Backward	○				○						Reclining	Forward	○	○									Backward	○		○								Lifting (Front)	Up	○					○					Down	○						○				Lifting (Rear)	Up	○							○			Down	○			○						
1	2	3	4																																																																																																																										
5	6	8	9	10																																																																																																																									
Switch	Condition	Terminals																																																																																																																											
		8	1	2	3	4	5	6	9	10																																																																																																																			
Sliding	Forward	○									○																																																																																																																		
	Backward	○				○																																																																																																																							
Reclining	Forward	○	○																																																																																																																										
	Backward	○		○																																																																																																																									
Lifting (Front)	Up	○					○																																																																																																																						
	Down	○						○																																																																																																																					
Lifting (Rear)	Up	○							○																																																																																																																				
	Down	○			○																																																																																																																								
SEL569X																																																																																																																													
OK or NG																																																																																																																													
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Ground circuit for power seat switch ● Harness for open or short between seat control unit LH and power seat switch 																																																																																																																											
NG	▶	<p>Replace power seat switch.</p>																																																																																																																											

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 11 (Cancel switch check)

=NAEL0369S14


1	CHECK CANCEL SWITCH										
<p>1. Disconnect cancel switch connector. 2. Check continuity between cancel switch terminals.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="width: 25%;">Terminals</th> <th style="width: 25%;">Cancel switch condition</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1-2</td> <td>ON</td> <td>Yes</td> </tr> <tr> <td>OFF</td> <td>No</td> </tr> </tbody> </table> </div> </div>				Terminals	Cancel switch condition	Continuity	1-2	ON	Yes	OFF	No
Terminals	Cancel switch condition	Continuity									
1-2	ON	Yes									
	OFF	No									
SEL628WA											
OK or NG											
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Ground circuit for cancel switch ● Harness for open or short between seat control unit LH and cancel switch 									
NG	▶	Replace cancel switch.									


AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 12

(Key, detention, door switch and vehicle speed signal check) =NAEL0369S15


1	CHECK KEY SWITCH INPUT SIGNAL							
<p>Check voltage between seat control unit LH terminal 2 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (6513)</p>  </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="border: none;">Condition</th> <th style="border: none;">Voltage [V]</th> </tr> </thead> <tbody> <tr> <td style="border: none;">Key is inserted</td> <td style="border: none;">Approx. 12</td> </tr> <tr> <td style="border: none;">Key is removed</td> <td style="border: none;">0</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">SEL629W</p>			Condition	Voltage [V]	Key is inserted	Approx. 12	Key is removed	0
Condition	Voltage [V]							
Key is inserted	Approx. 12							
Key is removed	0							
OK or NG								
OK	▶	GO TO 2.						
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Key switch ● Harness for open or short between key switch and fuse ● Harness for open or short between seat control unit LH and key switch 						


2	CHECK IGNITION SWITCH INPUT SIGNAL (ON AND START)																					
<p>Check voltage between seat control unit LH terminals and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (6512)</p>  </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2" style="border: none;">Terminals</th> <th colspan="3" style="border: none;">Ignition switch position</th> </tr> <tr> <th style="border: none;">+</th> <th style="border: none;">-</th> <th style="border: none;">OFF</th> <th style="border: none;">ON</th> <th style="border: none;">START</th> </tr> </thead> <tbody> <tr> <td style="border: none;">20</td> <td style="border: none;">Ground</td> <td style="border: none;">Approx. 0V</td> <td colspan="2" style="border: none;">Battery voltage</td> </tr> <tr> <td style="border: none;">31</td> <td style="border: none;">Ground</td> <td colspan="2" style="border: none;">Approx. 0V</td> <td style="border: none;">Batttery voltage</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">SEL630W</p>			Terminals		Ignition switch position			+	-	OFF	ON	START	20	Ground	Approx. 0V	Battery voltage		31	Ground	Approx. 0V		Batttery voltage
Terminals		Ignition switch position																				
+	-	OFF	ON	START																		
20	Ground	Approx. 0V	Battery voltage																			
31	Ground	Approx. 0V		Batttery voltage																		
OK or NG																						
OK	▶	GO TO 3.																				
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 11, located in fuse block (J/B)] ● 7.5A fuse [No. 26, located in fuse block (J/B)] ● Harness for open or short between seat control unit LH and fuse 																				

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)


3	CHECK PARK POSITION SWITCH INPUT SIGNAL							
<p>Check voltage between seat control unit LH terminal 21 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (8512)</p>  </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage [V]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Selector lever is in "P" position</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">Except above</td> <td style="text-align: center;">Approx. 12</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;">SEL631W</p>			Condition	Voltage [V]	Selector lever is in "P" position	0	Except above	Approx. 12
Condition	Voltage [V]							
Selector lever is in "P" position	0							
Except above	Approx. 12							
OK or NG								
OK	▶	GO TO 4.						
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Park position switch ● Park position switch ground circuit ● Harness for open or short between seat control unit LH and park position switch 						

4	CHECK DRIVER DOOR SWITCH INPUT SIGNAL							
<p>Check voltage between seat control unit LH terminal 9 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (8513)</p>  </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage [V]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Driver's door is open</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">Driver's door is closed</td> <td style="text-align: center;">Approx. 12</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;">SEL632W</p>			Condition	Voltage [V]	Driver's door is open	0	Driver's door is closed	Approx. 12
Condition	Voltage [V]							
Driver's door is open	0							
Driver's door is closed	Approx. 12							
OK or NG								
OK	▶	GO TO 5.						
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Driver door switch ● Driver door switch ground circuit ● Harness for open or short between seat control unit LH and driver door switch 						

5	CHECK VEHICLE SPEED SIGNAL	
<p>Does speedometer operate normally?</p> <p style="text-align: center;">Yes or No</p>		
OK	▶	GO TO 6.
NG	▶	Check speedometer and ABS actuator and electric unit circuit. Refer to EL-138.

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

6	CHECK VEHICLE SPEED SIGNAL PULL UP VOLTAGE	
<p>1. Turn ignition switch "ON". 2. Check voltage between seat control unit LH terminal 32 and ground.</p> <div style="text-align: center;">  <p>Seat control unit LH (B512)</p> <p>OR</p> <p>Approx. 5V should exist.</p> <p>SEL633W</p> <p>OK or NG</p> </div>		
OK	▶	Harness for open or short between seat control unit LH and combination meter.
NG	▶	Repair harness.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)


=NAEL0369S16

1	CHECK SEAT MEMORY SWITCH																													
<p>1. Disconnect seat memory switch connector. 2. Check continuity between seat memory switch terminals.</p>																														
																														
<table border="1" style="margin-left: auto;"> <thead> <tr> <th rowspan="2">Switch</th> <th rowspan="2">Condition</th> <th colspan="4">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Memory-1</td> <td>ON</td> <td style="text-align: center;">○</td> <td></td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Memory-2</td> <td>ON</td> <td></td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Set</td> <td>ON</td> <td></td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table>			Switch	Condition	Terminals				1	2	3	4	Memory-1	ON	○			○	Memory-2	ON		○		○	Set	ON			○	○
Switch	Condition	Terminals																												
		1	2	3	4																									
Memory-1	ON	○			○																									
Memory-2	ON		○		○																									
Set	ON			○	○																									
SEL634WA																														
OK or NG																														
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Ground circuit for seat memory switch ● Harness for open or short between seat control unit LH and seat memory switch 																												
NG	▶	Replace seat memory switch.																												

DIAGNOSTIC PROCEDURE 14 (Memory indicator check)

NAEL0369S17

1	CHECK INDICATOR LAMP	
Check indicator lamp illumination.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace seat memory switch (indicator lamp).

2	CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP	
<p>1. Disconnect seat memory switch connector. 2. Check voltage between seat memory switch terminal and ground.</p>		
		
Battery voltage should exist.		
SEL635WA		
OK or NG		
OK	▶	Check harness for open or short between seat control unit LH and seat memory switch
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 24 located in the fuse block (J/B)] ● Harness for open or short between fuse and indicator lamp

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description

System Description

Refer to EC-73, "Automatic Speed Control Device (ASCD) System" in "ENGINE AND EMISSION ^{NAEL0461} BASIC DESCRIPTION CONTROL SYSTEM".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

POWER WINDOW

System Description

System Description

NAEL0378

Power is supplied at all times

- from 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3,
- to power window main switch terminal 19, and
- to front power window switch RH terminal 10.

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27
- to smart entrance control unit terminal 46 and
- to power window relay terminal 2.

Ground is supplied to power window relay terminal 1

- through body grounds M4, M66, M111, M147 and M157.

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to power window main switch terminal 10,
- to front power window switch RH terminal 14 and
- to rear power window switch LH and RH terminals 4.

MANUAL OPERATION

NAEL0378S01

Front Door LH

Ground is supplied

- to power window main switch terminal 17
- through body grounds M4, M66, M111, M147 and M157.

WINDOW UP

When the front LH switch in the power window main switch is pressed in the up position, power is supplied

- to front power window motor LH terminal 1
- through power window main switch terminal 8.

Ground is supplied

- to front power window motor LH terminal 3
- through power window main switch terminal 11.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to front power window motor LH terminal 3
- through power window main switch terminal 11.

Ground is supplied

- to front power window motor LH terminal 1
- through power window main switch terminal 8.

Then, the motor lowers the window until the switch is released.

Front Door RH

Ground is supplied

- to power window main switch terminal 17
- through body grounds M4, M66, M111, M147 and M157.

NAEL0378S0102

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

POWER WINDOW MAIN SWITCH OPERATION

When front RH switch in the power window main switch is pressed UP or DOWN, power window main switch sends window up or down signal to front power window switch RH with power window serial link communication line. Refer to "POWER WINDOW SERIAL LINK" (EL-274). Signals are supplied

- through power window main switch terminal 14
- to front power window switch RH terminal 16.

The subsequent operation is the same as the front power window switch RH operation.

FRONT POWER WINDOW SWITCH RH OPERATION

Power is supplied

- through front power window switch RH (8, 9)
- to front power window motor RH (1, 3).

Ground is supplied

- to front power window motor RH (3, 1)
- through front power window switch RH (9, 8)
- to front power window RH terminal 11
- through body grounds M4, M66, M111, M147 and M157.

Then, the motor raises or lowers the window until the switch is released.

Rear Door LH

Ground is supplied

- to power window main switch terminal 17
- through body grounds the M4, M66, M111, M147 and M157.

NOTE:

Numbers in parentheses are terminal numbers, when the power window switch is pressed in the UP and DOWN positions.

POWER WINDOW MAIN SWITCH OPERATION

Power is supplied

- through power window main switch terminal (1, 3)
- to rear power window switch LH terminal (5, 2)

The subsequent operation is the same as the rear power window switch LH operation.

REAR POWER WINDOW SWITCH LH

Power is supplied

- through rear power window switch LH (1, 3)
- to rear power window motor LH (1, 2)

Ground is supplied

- to rear power window motor LH (2, 1)
- through rear power window switch LH (3, 1)
- to rear power window switch LH terminal (2, 5)
- through power window main switch terminal (3, 1)

Then, the motor raises or lowers the window until the switch is released.

Rear Door RH

Rear door RH windows will rise and lower in the same manner as the rear door LH window.

AUTO OPERATION

The power window AUTO feature enables the driver or front passenger to open or close the driver's and front passenger's window without holding the window switch in the up or down position.

The AUTO feature only operates on the driver's and front passenger's window upward and downward movement.

POWER WINDOW LOCK

The power window lock is designed to lock operation of all windows except for driver's door window.

When the lock switch is pressed to lock position, the ground of the front and rear power window switches, in the power window main switch, is disconnected. This prevents the power window motors from operating.

GI

MA

EM

LC

EC

FE

CL

NAEL0378S0103

MT

AT

TF

PD

AX

SU

BR

ST

RS

NAEL0378S0104

BT

NAEL0378S02

HA

SC

NAEL0378S03

EL

IDX

POWER WINDOW

System Description (Cont'd)

RETAINED POWER OPERATION

NAEL0378S04

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds

- to power window relay terminal 2
- from smart entrance control unit terminal 46.

Ground is always supplied

- to power window relay terminal 1
- through body grounds M4, M66, M111, M147 and M157.

When power and ground are supplied, the power window relay continues to be energized, and the power window can be operated.

The retained power operation is canceled when the driver or passenger side door is opened.

RAP signal's period can be changed by CONSULT-II. (EL-282)

INTERRUPTION DETECTION FUNCTION

NAEL0378S05

Power window main switch and front power window switch RH monitor the power window motor operation and the power window position (full closed or other) for driver's and passenger's power window by the signals from encoder and limit switch in front power window motor LH or RH.

When power window main switch or front power window switch RH detects interruption during the following close operation in the driver's or front passenger's side door,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

Power window main switch or front power window switch RH controls driver's or front passenger's power window motor for open and the power window will be lowered about 150 mm (5.91 in).

POWER WINDOW OPENED/CLOSED OPERATION WITH KEY CYLINDER

NAEL0378S06

When ignition key switch is OFF, front power window can be opened or closed by turning the front door key cylinder LH to UNLOCK/LOCK position.

- Power window can be opened as the door key cylinder is kept fully turning to the UNLOCK position.
- Power window can be closed as the door key cylinder is kept fully turning to the LOCK position.

The power window opening stops when the following operations are carried out:

- While performing open/close the window, power window is stopped at the position as the door key cylinder is placed on Neutral.
- When the ignition switch is turned ON while the power window opening is operated.

POWER WINDOW SERIAL LINK

NAEL0378S07

Power window main switch, front power window switch RH and smart entrance control unit transmit and receive the signal by power window serial link.

The under-mentioned signal is transmitted from smart entrance control unit to power window main switch or front power window switch RH.

- Door lock or unlock signal (remote keyless entry system)
- Power window down signal (remote keyless entry system)

The under-mentioned signal is transmitted from power window main switch to front power window switch RH.


- Door lock or unlock signal (remote keyless entry system)
- Power window open/closed operation signal by key cylinder
- Power window lock signal

POWER WINDOW

Schematic

NAEL0379

Schematic



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



POWER WINDOW

Wiring Diagram — WINDOW —

Wiring Diagram — WINDOW —

NAEL0380

EL-WINDOW-01



REFER TO THE FOLLOWING.

- (E1), (B1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK -
- JUNCTION BOX (J/B)








MEL021Q

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02




GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL953R

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03





MEL023Q

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-05



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(B52) W

1	2	3	4		
5	6	7	8	9	10

(D4), (D50), (D70) W

7	6	5	4	3	2	1		
16	15	14	13	12	11	10	9	8

(D6) W

REFER TO THE FOLLOWING.
(B1) -SUPER MULTIPLE JUNCTION (SMJ)


2	1
---	---

(D51), (D71) B

4	1	3	2	5
---	---	---	---	---

(D52), (D72) W

MEL955R




CONSULT-II Inspection Procedure

NAEL0381


NAEL0381S01

“RETAINED PWR”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “RETAINED PWR”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER WINDOW

CONSULT-II Application Items

CONSULT-II Application Items

NAEL0382

NAEL0382S01

NAEL0382S0101

“RETAINED PWR”

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

Active Test

NAEL0382S0102

Test Item	Description
RETAINED PWR	<p>This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system and headlamp battery saver control unit. Those systems can be operated when turning on “RETAINED PWR” on CONSULT-II screen even if the ignition switch is tuned OFF.</p> <p>NOTE: During this test, CONSULT-II can be operated with ignition switch in “OFF” position. “RETAINED PWR” should be turned “ON” or “OFF” on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF to check retained power operation. CONSULT-II might be stuck if “RETAINED PWR” is turned “ON” or “OFF” on CONSULT-II screen when ignition switch is OFF.</p>

Work Support

NAEL0382S0103

Work Item	Description
RETAINED PWR SET	<p>Rap signal's power supply period can be changed by mode setting. Selects rap signal's power supply period between three steps.</p> <ul style="list-style-type: none"> ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (2 min.)

Trouble Diagnoses

NAEL0383

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> 1. 7.5A fuse, 40A fusible link 2. M145 circuit breaker 3. Power window relay 4. M145 circuit breaker circuit 5. Power window relay circuit 6. Ground circuit 7. Power window main switch 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 11, located in fuse block (J/B)], 40A fusible link (letter f, located in fuse and fusible link box). 2. Check M145 circuit breaker. 3. Check power window relay. 4. Check the following. <ol style="list-style-type: none"> a. Harness between M145 circuit breaker and 40A fusible link b. Harness between M145 circuit breaker and power window main switch 5. Check the following. <ol style="list-style-type: none"> a. Harness between 7.5A fuse and power window relay b. Harness between M145 circuit breaker and power window relay 6. Check the following. <ol style="list-style-type: none"> a. Ground circuit of power window main switch terminal 17 b. Power window relay ground circuit 7. Check power window main switch.

POWER WINDOW

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> 1. Front power window motor LH circuit 2. Front power window motor LH 3. Power window main switch 	<ol style="list-style-type: none"> 1. Check harness between power window main switch and front power window motor LH for open or short circuit. 2. Check front power window motor LH. 3. Check power window main switch. 	GI MA EM
Passenger side power window cannot be operated but other window can be operated.	<ol style="list-style-type: none"> 1. Power supply for front power window switch RH 2. Front power window switch RH ground circuit 3. Front power window switch RH circuit 4. Front power window motor RH circuit 5. Front power window motor RH 6. Power window main switch 7. Front power window switch RH 	<ol style="list-style-type: none"> 1. Check power supply for front power window switch RH terminals 10 and 14. 2. Check front power window switch RH ground circuit. 3. Check harness between front power window switch RH and power window main switch. 4. Check harness between front power window switch RH and front power window motor RH for open or short circuit. 5. Check front power window motor RH. 6. Check power window main switch. 7. Check front power window switch RH. 	LC EC FE
One or more rear power windows except front window cannot be operated.	<ol style="list-style-type: none"> 1. Rear power window switches 2. Rear power window motors 3. Power window main switch 4. Rear power window circuit 	<ol style="list-style-type: none"> 1. Check rear power window switches. 2. Check rear power window motor. 3. Check power window main switch. 4. Check the following. <ol style="list-style-type: none"> a. Harness between the rear power window switches (LH and RH) terminal 5 and power window relay terminal 4 b. Harnesses between power window main switch and rear power window switches for open/short circuit c. Harnesses between rear power window switches and rear power window motor for open/short circuit 	CL MT AT TF
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window switches.	Power window main switch	Check power window main switch.	PD AX
Driver side power window automatic operation does not function properly.	<ol style="list-style-type: none"> 1. Power window main switch 2. Encoder and limit switch 	<ol style="list-style-type: none"> 1. Check power window main switch. 2. Check encoder and limit switch. (EL-285) 	SU
Front passenger side power window automatic operation does not function properly.	<ol style="list-style-type: none"> 1. Front power window switch RH 2. Encoder and limit switch 	<ol style="list-style-type: none"> 1. Check front power window switch RH. 2. Check encoder and limit switch. (EL-285) 	BR
Retained power operation does not operate properly.	<ol style="list-style-type: none"> 1. RAP signal circuit 2. Driver or passenger side door switch circuit 3. Smart entrance control unit 	<ol style="list-style-type: none"> 1. Check RAP signal. <ol style="list-style-type: none"> a. (With CONSULT-II) <ul style="list-style-type: none"> ● Check RAP signal with CONSULT-II. Use "WORK SUPPORT" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-282.) ● Check RAP signal with CONSULT-II. Use "ACTIVE TEST" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-281.) If NG, go to the step b. below. 2. Verify 12 positive voltage from smart entrance control unit terminal 46 is present at terminal 2 of power window relay: <ul style="list-style-type: none"> ● Within 45 seconds after ignition switch turns off.*1 ● When front door LH and RH is closed. 3. Check the following. <ol style="list-style-type: none"> a. Harness between smart entrance control unit and driver or passenger side door switch for short circuit b. Driver or passenger side door switch ground circuit c. Driver or passenger side door switch 4. Check smart entrance control unit. (EL-382) 	ST RS BT HA SC EL IDX

POWER WINDOW

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Passenger side power window cannot be operated using power window main switch but can be operated by passenger side power window switch.	<ol style="list-style-type: none"> 1. Power window main switch 2. Power window main switch circuit 	<ol style="list-style-type: none"> 1. Check power window main switch. (EL-287) 2. Check harness for open or short circuit between power window main switch terminal 14 and front power window switch RH terminal 16.
Rear LH power window cannot be operated using power window main switch but can be operated by rear LH power window switch.	Power window main switch	Check power window main switch. (EL-287)
Rear RH power window cannot be operated using power window main switch but can be operated by rear RH power window switch.	Power window main switch	Check power window main switch. (EL-287)
Power window open/close operation with key cylinder does not operate properly.	<ol style="list-style-type: none"> 1. Front door key cylinder switch LH 2. Front door key cylinder switch LH circuit 3. Power window main switch 	<ol style="list-style-type: none"> 1. Check front door key cylinder switch LH. 2. Check harness for open or short circuit between front door key cylinder switch LH and power window main switch. 3. Check power window main switch.

*1: RAP signal's period can be changed by CONSULT-II. (EL-282)





POWER WINDOW



Trouble Diagnoses (Cont'd)

ENCODER AND LIMIT SWITCH CHECK

=NAEL0383S01

1	CHECK DOOR WINDOW SLIDE MECHANISM	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Obstacles in window, glass molding, etc. ● Worn or deformed glass molding ● Door sash tilted too far inward or outward ● Door window motor <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Remove obstacles or repair door window slide mechanism.

2	CHECK POWER SUPPLY TO LIMIT SWITCH	
<p>1. Disconnect front power window motor LH or RH harness connector.</p> <p>2. Check voltage between power window main switch harness connector D6 terminal 9 (G/W) or front power window switch RH harness connector D44 terminal 15 (G/W) and ground.</p>		
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Power window main switch connector</p> </div> <div style="text-align: center;">  <p>Front power window switch RH connector</p> </div> <div style="text-align: center;"> <p>Voltage: 5V</p>   </div> </div> <p>NOTE: Check voltage when front power window motor LH or RH harness connector is disconnected.</p> <p style="text-align: right;">SEL686YA</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Replace power window main switch or front power window switch RH.

3	CHECK LIMIT SWITCH OPERATION										
<p>1. Connect front power window motor LH or RH harness connector.</p> <p>2. Check voltage between power window main switch harness connector D6 terminal 9 (G/W) or front power window switch RH harness connector D44 terminal 15 (G/W) and ground during power window closing operation.</p>											
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Power window main switch connector</p> </div> <div style="text-align: center;">  <p>Front power window switch RH connector</p> </div> <div style="text-align: center;"> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Terminal No.</th> <th>Condition</th> <th>Voltage (DCV)</th> </tr> </thead> <tbody> <tr> <td>Power window main switch: 9 Front power window switch RH: 15</td> <td>Approx. 15 mm (0.59 in) below the full closed position to full closed position</td> <td style="text-align: center;">Approx. 5</td> </tr> <tr> <td></td> <td>Other positions</td> <td style="text-align: center;">Approx. 0</td> </tr> </tbody> </table> </div> </div> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEL687Y</p>			Terminal No.	Condition	Voltage (DCV)	Power window main switch: 9 Front power window switch RH: 15	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5		Other positions	Approx. 0
Terminal No.	Condition	Voltage (DCV)									
Power window main switch: 9 Front power window switch RH: 15	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5									
	Other positions	Approx. 0									
OK	▶	GO TO 5.									
NG	▶	GO TO 4.									


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER WINDOW

Trouble Diagnoses (Cont'd)

4 RESET LIMIT SWITCH

Reset limit switch. Refer to BT-22, "Front Door Glass Limit Switch Reset". Then check voltage between power window main switch harness connector D6 terminal 9 (G/W) or front power window switch RH harness connector D44 terminal 15 (G/W) and ground during power window closing operation at least ten times.



Terminal No.	Condition	Voltage (DCV)
Power window main switch: 9 Front power window switch RH: 15	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0



SEL687Y

OK or NG

OK	▶	GO TO 5.
NG	▶	Replace front power window motor.

5 CHECK ENCODER

Measure voltage between power window main switch harness connector D6 terminal 13 (G/Y) or front power window switch RH harness connector D44 terminal 12 (G/Y) and ground with oscilloscope when power window is in automatic closing operation.

HI: Approx. 5V
LO: Approx. 0V


SEL688Y

OK or NG

OK	▶	Replace power window main switch.
NG	▶	Replace front power window motor.

POWER WINDOW

Trouble Diagnoses (Cont'd)

2	CHECK SIGNAL CIRCUIT
<p data-bbox="154 199 1468 254">1. Check continuity between power window switch harness connector D6 terminal 14 (BR) and front power window switch RH harness connector D44 terminal 16 (Y).</p> <div data-bbox="370 279 1263 577"><p>The diagram shows two 12-pin connectors. The left connector is labeled 'Power window main switch connector' and has terminal 14 highlighted. The right connector is labeled 'Front power window switch RH connector' and has terminal 16 highlighted. A hand icon with 'H.S.' and a 'DISCONNECT' symbol indicates the connectors should be disconnected. A continuity tester (represented by a square with an Ω symbol) is connected between terminal 14 and terminal 16. The text 'Continuity should exist.' is written to the right of the diagram.</p></div> <p data-bbox="1377 579 1468 600">SEL691YB</p>	
Yes or No	
Yes	▶ INSPECTION END
No	▶ Repair harness or connectors.

POWER WINDOW

Trouble Diagnoses (Cont'd)

Rear LH Side Window Operation

=NAEL0383S0202

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

- Turn ignition switch to ON position.
- Check voltage between power window main switch harness connector D6 terminal 1 (R/B) or 3 (G/W) and ground when rear power window LH side is in open or close operation.

Power window main switch connector

Terminals		Main switch condition	
(+)	(-)	Open	Close
1	Ground	0V	12V
3	Ground	0V	12V

SEL692YA

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace power window main switch.

2 CHECK SIGNAL CIRCUIT

- Turn ignition switch to OFF position.
- Disconnect power window main switch connector and rear power window switch LH connector.
- Check continuity between power window main switch harness connector D6 terminal 3 (G/W) and rear power window switch LH harness connector D52 terminal 2 (B/W).
- Check continuity between power window main switch harness connector D6 terminal 1 (R/B) and rear power window switch LH harness connector D52 terminal 5 (W/B).

Power window main switch connector

Rear power window switch LH connector

Continuity should exist.

SEL796YA

Yes or No


Yes	▶	INSPECTION END
No	▶	Repair harness or connectors.


POWER WINDOW

Trouble Diagnoses (Cont'd)

Rear RH Side Window Operation

=NAEL0383S0203

1	CHECK POWER WINDOW MAIN SWITCH OUTPUT	<p>1. Turn ignition switch to ON position.</p> <p>2. Check voltage between power window main switch harness connector D6 terminal 5 (B/W) or 7 (W/B) and ground when rear power window RH side is in open or close operation.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>CONNECT H.S. Power window main switch connector</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="2">Main switch condition</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>Open</th> <th>Close</th> </tr> </thead> <tbody> <tr> <td>5</td> <td>Ground</td> <td>0V</td> <td>12V</td> </tr> <tr> <td>7</td> <td>Ground</td> <td>0V</td> <td>12V</td> </tr> </tbody> </table> </div>	Terminals		Main switch condition		(+)	(-)	Open	Close	5	Ground	0V	12V	7	Ground	0V	12V	SEL694YA
Terminals		Main switch condition																	
(+)	(-)	Open	Close																
5	Ground	0V	12V																
7	Ground	0V	12V																
OK or NG																			
OK	▶	GO TO 2.																	
NG	▶	Replace power window main switch.																	


2	CHECK SIGNAL CIRCUIT	<p>1. Turn ignition switch to OFF position.</p> <p>2. Disconnect power window main switch connector and rear power window switch RH connector.</p> <p>3. Check continuity between power window main switch harness connector D6 terminal 7 (W/B) and rear power window switch RH harness connector D72 terminal 5 (W/B).</p> <p>4. Check continuity between power window main switch harness connector D6 terminal 5 (B/W) and rear power window switch RH harness connector D72 terminal 2 (B/W).</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>DISCONNECT H.S. Power window main switch connector</p> <p>Rear power window switch RH connector</p> </div> <div style="text-align: center; padding-top: 20px;"> <p>Continuity should exist.</p> </div> </div>	SEL795YA
Yes or No			
Yes	▶	INSPECTION END	
No	▶	Repair harness or connectors.	

POWER DOOR LOCK

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0384



System Description

NAEL0385

OPERATION

NAEL0385S01

- The lock/unlock switch (LH and RH) on door trim can lock and unlock all doors.
- With the door key inserted in the key cylinder on front LH or back door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from door key cylinder switch)
- If the ignition key is in the ignition key cylinder and one or more of doors are open, setting the lock/unlock switch to "LOCK" locks the doors once but then immediately unlock them. (Combination signals from key switch and door switches) - (KEY REMINDER DOOR SYSTEM)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Schematic

Schematic

NAEL0386



MEL431P

POWER DOOR LOCK

Wiring Diagram — D/LOCK —



Wiring Diagram — D/LOCK —

NAEL0387

NAEL0387S01

FIG. 1

EL-D/LOCK-01



REFER TO THE FOLLOWING.
 (E1), (B1) -SUPER
 MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL026Q


POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

NAEL0387S02


FIG. 2

EL-D/LOCK-02



Refer to EL-POWER.

SMART ENTRANCE CONTROL UNIT (M122), (M123)



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-JUNCTION BOX (J/B)



POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 3

NAEL0387S03

EL-D/LOCK-03



REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL028Q

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX





POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

NAEL0387S04

FIG. 4

EL-D/LOCK-04



REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL434P



POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 5

NAEL0387S05

EL-D/LOCK-05



REFER TO THE FOLLOWING.
(B1) - SUPER MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX









POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


FIG. 6

NAEL0387S06

EL-D/LOCK-06



MEL029Q




CONSULT-II Inspection Procedure

=NAEL0388


NAEL0388S01

“DOOR LOCK”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Turn “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “DOOR LOCK”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

CONSULT-II Application Items

CONSULT-II Application Items “DOOR LOCK” Data Monitor

NAEL0389

NAEL0389S01

NAEL0389S0101

Monitored Item	Description
KEY ON SW	Indicates [ON/OFF] condition of key switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
DOOR SW-RR	Indicates [ON/OFF] condition of door switch (Rear).
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from key cylinder.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

Active Test

NAEL0389S0102

Test Item	Description
ALL D/LK MTR	This test is able to check all door lock actuators lock operation. These actuators lock when “ON” on CONSULT-II screen is touched.
DR D/UN MTR	This test is able to check front door lock actuator LH unlock operation. The actuator unlocks when “ON” on CONSULT-II screen is touched.
NON DR D/UN	This test is able to check door lock actuators (except front door lock actuator LH) unlock operation. These actuators unlock when “ON” on CONSULT-II screen is touched.

Work Support

NAEL0389S0103

Work Item	Description
DOOR LOCK-UNLOCK SET	Select unlock mode can be changed in this mode. Selects ON-OFF of select unlock mode. <ul style="list-style-type: none">● MODE 1 (ON)/MODE 2 (OFF)
ANTI-LOCK OUT SET	Key reminder door mode can be changed in this mode. Selects ON-OFF of key reminder door mode. <ul style="list-style-type: none">● MODE 1 (ON)/MODE 2 (OFF)

POWER DOOR LOCK

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NAEL0390

NAEL0390S01

REFERENCE PAGE (EL-)	302	303	305	306	307	309	311
SYMPTOM	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR SWITCH CHECK	KEY SWITCH (INSERT) CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	FRONT DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	DOOR LOCK ACTUATOR CHECK
Key reminder door system does not operate properly.	X	X	X				X
Specific door lock actuator does not operate.	X						X
Power door lock does not operate with door lock and unlock switch (LH and RH) on door trim.	X			X			
Power door lock does not operate with front door key cylinder operation.	X				X		
Power door lock does not operate with back door key cylinder operation.	X					X	

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)




MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

=NAEL0390S02

Main Power Supply Circuit Check

NAEL0390S0201

Terminals		Ignition switch			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M123	49 (G/R)	Ground	Battery voltage	Battery voltage	Battery voltage
	51 (W/R)				



Ground Circuit Check

NAEL0390S0202

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M122	43 (B)	Ground	Yes
M123	64 (B)		

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DOOR SWITCH CHECK

=NAEL0390S03

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RR") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
DOOR SW-RR	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF

When any doors are open:

DOOR SW-DR ON
DOOR SW-AS ON
DOOR SW-RR ON

When any doors are closed:



DOOR SW-DR OFF
DOOR SW-AS OFF
DOOR SW-RR OFF

SEL009Y

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.

Smart entrance control unit connector



	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door switch	1	Ground	Open	0
			Closed	Approx. 5
Front RH door switch	2	Ground	Open	0
			Closed	Approx. 5
Rear door switches	3	Ground	Open	0
			Closed	Approx. 5

SEL010Y




Refer to wiring diagram in EL-293.

OK or NG

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

2	CHECK DOOR SWITCH																							
<p>1. Disconnect door switch connector.</p> <p>2. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between front door switch connector B9 (LH) or B68 (RH) terminals 1 and 2 ● Continuity between front door switch connector B9 (LH) or B68 (RH) terminal 3 and ground ● Continuity between back door switch connector D208 terminals 1 and 2 ● Continuity between rear door switch connector B18 (LH) or B71 (RH) terminal 1 and ground 																								
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Front door switch connector</p>  </div> <div style="text-align: center;">  <p>Back door switch connector</p>  </div> </div>																								
<div style="display: flex; justify-content: center; align-items: center;">  <p>Rear door switch connector</p>  </div>																								
<table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switches</td> <td>1 - 2</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>3 - Ground</td> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Back door switch</td> <td rowspan="2">1 - 2</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Rear door switches</td> <td rowspan="2">1 - Ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table>			Terminals	Condition	Continuity	Front door switches	1 - 2	Closed	No	3 - Ground	Open	Yes	Back door switch	1 - 2	Closed	No	Open	Yes	Rear door switches	1 - Ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity																					
Front door switches	1 - 2	Closed	No																					
	3 - Ground	Open	Yes																					
Back door switch	1 - 2	Closed	No																					
		Open	Yes																					
Rear door switches	1 - Ground	Closed	No																					
		Open	Yes																					
SEL287YA																								
OK or NG																								
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Door switches ground circuit (Front or back door) or rear door switches ground condition ● Harness for open or short between smart entrance control unit and door switch 																							
NG	<p>▶ Replace door switch.</p>																							

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK

=NAEL0390S04

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1	CHECK KEY SWITCH INPUT SIGNAL	<p>With CONSULT-II Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; align-items: flex-start;"> <table border="1" style="margin-right: 20px;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table> <div style="margin-top: 10px;"> <p>When key is inserted to ignition key cylinder: KEY ON SW ON</p> <p>When key is removed from ignition key cylinder: KEY ON SW OFF</p> </div> </div> <p style="text-align: right; margin-top: 20px;">SEL315W</p>	DATA MONITOR		MONITOR		KEY ON SW	ON
DATA MONITOR								
MONITOR								
KEY ON SW	ON							
		<p>Without CONSULT-II Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p> <p>Smart entrance control unit connector</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>CONNECT</p> </div> <div style="margin-right: 20px;"> <p>Approx. 12V</p> </div> <div> <p>Approx. 0V</p> </div> </div> <p>Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is removed. 0</p> <p style="text-align: right; margin-top: 20px;">SEL011Y</p> <p>Refer to wiring diagram in EL-294.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>						
OK		▶ Key switch is OK.						
NG		▶ GO TO 2.						

2	CHECK KEY SWITCH (INSERT)	<p>Check continuity between key switch connector terminals 1 and 2.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>DISCONNECT</p> </div> <div style="margin-right: 20px;"> <p>Yes</p> </div> <div> <p>No</p> </div> </div> <p>Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No</p> <p style="text-align: right; margin-top: 20px;">SEL308X</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>
OK		▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between smart entrance control unit and key switch
NG		▶ Replace key switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH CHECK

=NAEL0390S05

1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

LOCK SW DR/AS ON

When lock/unlock switch is turned to UNLOCK:

UNLK SW DR/AS ON


SEL341W

Without CONSULT-II


1. Remove key from ignition key cylinder.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



Smart entrance control unit connector



Refer to wiring diagram in EL-298.



Voltage:

12V → 9V (10 sec.) measurement by analog circuit tester.

SEL699YA

OK or NG

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

FRONT DOOR KEY CYLINDER SWITCH CHECK

=NAEL0390S06

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK FRONT DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front door key cylinder is turned to LOCK:

KEY CYL LK-SW ON



When key inserted in front door key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WF

Without CONSULT-II

1. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when key inserted in front door key cylinder is turned "LOCK" or "UNLOCK".
2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Voltage:
12V → 9V (10 sec.)
measurement by analog
circuit tester.

SEL700YA


Refer to wiring diagram in EL-298.

OK or NG

OK	▶	Front door key cylinder switch LH is OK.
NG	▶	GO TO 2.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

2	CHECK FRONT DOOR KEY CYLINDER SWITCH														
1. Disconnect front door key cylinder switch connector. 2. Check continuity between front door key cylinder switch LH connector terminals.															
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>Front door key cylinder switch LH connector </p>  </div> <div style="width: 45%;"> <p>① : Door unlock switch terminal ② : Ground terminal ③ : Door lock switch terminal</p> <table border="1" data-bbox="795 409 1356 567"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LH: 3 - 2</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">LH: 1 - 2</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL313XB</p>			Terminals	Key position	Continuity	LH: 3 - 2	Neutral/Unlock	No	Lock	Yes	LH: 1 - 2	Neutral/Lock	No	Unlock	Yes
Terminals	Key position	Continuity													
LH: 3 - 2	Neutral/Unlock	No													
	Lock	Yes													
LH: 1 - 2	Neutral/Lock	No													
	Unlock	Yes													
OK or NG															
OK	▶	Check the following. <ul style="list-style-type: none"> ● Front door key cylinder switch LH ground circuit ● Harness for open or short between smart entrance control unit and power window main switch ● Harness for open or short between power window main switch and front door key cylinder switch LH 													
NG	▶	Replace front door key cylinder switch LH.													

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

BACK DOOR KEY CYLINDER SWITCH CHECK

=NAEL0390S07

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back door key cylinder is turned to LOCK:

KEY CYL LK-SW ON


When key inserted in back door key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WG

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG) or 11 (Y) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
Back door	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5

SEL286Y


Refer to wiring diagram in EL-295.

OK or NG

OK	▶	Back door key cylinder switch is OK.
NG	▶	GO TO 2.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

2	CHECK BACK DOOR KEY CYLINDER SWITCH																
1. Disconnect back door key cylinder switch connector. 2. Check continuity between back door key cylinder switch terminals.																	
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="width: 45%;"> <table border="1" data-bbox="787 336 1421 514"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL315X</p> <p style="text-align: center;">OK or NG</p>			Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○	—	○	Between neutral and unlock (Back door)		○	○
Key position	Terminals																
	1	2	4														
Between neutral and lock (Back door)	○	—	○														
Between neutral and unlock (Back door)		○	○														
OK	▶	Check the following. <ul style="list-style-type: none"> ● Back door key cylinder switch ground circuit ● Harness for open or short between smart entrance control unit and back door key cylinder switch 															
NG	▶	Replace back door key cylinder switch.															

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DOOR LOCK ACTUATOR CHECK

=NAEL0390S08

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

1 CHECK DOOR LOCK ACTUATOR OPERATION

With CONSULT-II

1. Select "ACTIVE TEST" in "DOOR LOCK" with CONSULT-II.
2. Select "ALL D/LK MTR" and touch "ON".
3. Then, select "DR D/UN MTR" and touch "ON".
4. Select "NON DR D/UN" and touch "ON".

ACTIVE TEST	
ALL D/LK MTR	OFF
or	
(DR D/UN MTR	OFF)
(NON DR D/UN	OFF)
ON	

Door lock motor should operate.

SEL343W

NOTE:



If CONSULT-II is not available, skip this procedure and go to the next step.

OK or NG

OK	▶	Door lock actuator is OK.
NG	▶	GO TO 2.

POWER DOOR LOCK


Trouble Diagnoses (Cont'd)

2	CHECK DOOR LOCK ACTUATOR CIRCUIT													
<ul style="list-style-type: none"> Door lock actuator front LH Check voltage between smart entrance control unit harness connector M123 terminal 54 (L), 55 (W/PU) and ground. 														
<p>Smart entrance control unit connector</p>  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Door lock/unlock switch condition</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage V</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td>54</td> <td>Ground</td> <td rowspan="2">Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>55</td> <td>Ground</td> </tr> </tbody> </table>		Door lock/unlock switch condition	Terminal No.		Voltage V	(+)	(-)	Lock	54	Ground	Approx. 12	Unlock	55	Ground
Door lock/unlock switch condition	Terminal No.		Voltage V											
	(+)	(-)												
Lock	54	Ground	Approx. 12											
Unlock	55	Ground												
SEL014Y														
<ul style="list-style-type: none"> Door lock actuator front RH and rear Check voltage between smart entrance control unit harness connector M123 terminal 54 (L), 56 (Y/B) and ground. 														
<p>Smart entrance control unit connector</p>  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Door lock/unlock switch condition</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage V</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td>54</td> <td>Ground</td> <td rowspan="2">Approx. 12</td> </tr> <tr> <td>Unlock</td> <td>56</td> <td>Ground</td> </tr> </tbody> </table>		Door lock/unlock switch condition	Terminal No.		Voltage V	(+)	(-)	Lock	54	Ground	Approx. 12	Unlock	56	Ground
Door lock/unlock switch condition	Terminal No.		Voltage V											
	(+)	(-)												
Lock	54	Ground	Approx. 12											
Unlock	56	Ground												
SEL015Y														
Refer to wiring diagram in EL-296.														
OK or NG														
OK	▶	GO TO 2.												
NG	▶	Replace smart entrance control unit. (Before replacing smart entrance control unit, perform "DOOR LOCK/UNLOCK SWITCH CHECK".)												

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


3 CHECK DOOR LOCK ACTUATOR

1. Disconnect door lock actuator connector.
2. Apply 12V direct current to door lock actuator and check operation.



- **Door lock actuator operation:**
Terminals between (+): 3 and (-): 1
Unlocked → Locked
Terminals between (+): 1 and (-): 3
Locked → Unlocked

SEL318X



- **Back door lock actuator operation:**
Terminals between (+): 1 and (-): 2
Unlocked → Locked
Terminals between (+): 2 and (-): 1
Locked → Unlocked

SEL319X

OK or NG


OK	▶	Check harness for open or short between smart entrance control unit connector and door lock actuator.
NG	▶	Replace door lock actuator.

REMOTE KEYLESS ENTRY SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0391



System Description

NAEL0392

NAEL0392S01

INPUTS

Power is supplied at all times

- to smart entrance control unit terminal 49 and
- to key switch terminal 2
- through 7.5A fuse [No. 24, located in the fuse block (J/B)], and
- to smart entrance control unit terminal 51
- through circuit breaker terminals 2 and 1 and
- through 40A fusible link (letter f, located in fuse and fusible link box).

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 1
- to smart entrance control unit terminal 25.

When the front door switch LH is ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 1
- to front door switch LH terminal 2
- through body grounds B11, B22 and D210.

When the front door switch RH is ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal 1

- to front door switch RH terminal 2
- through body grounds B55 and B75.

When the all doors switches are ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 3
- through front door switches terminal 3
- to front door switches case grounds, and
- through rear door switches terminal 1
- to rear door switches case grounds, and
- through back door switch terminal 2
- to back door switch terminal 1
- through body grounds B11, B22 and D210.

When lock/unlock switch LH is LOCK/UNLOCK, ground is supplied

- to power window main switch terminal 17
- through body grounds M4, M66, M111, M147 and M157.

Door lock or unlock operation signal is supplied

- through power window main switch terminal 14
- to smart entrance control unit terminal 33.

When lock/unlock switch RH is LOCK/UNLOCK, ground is supplied

- to front power window switch RH terminal 11
- through body grounds M4, M66, M111, M147 and M157.

Door lock or unlock operation signal is supplied

- through power window main switch terminal 14
- to smart entrance control unit terminal 33.

Remote controller signal is inputted to smart entrance control unit (The antenna of the system is combined with smart entrance control unit).

Smart entrance control unit is connected to power window main switch (door lock and unlock switch) and front power window switch RH (door lock and unlock switch) as serial link communication line. Refer to "POWER WINDOW SERIAL LINK" (EL-274).

OPERATION

The remote keyless entry system controls operation of the

- power door lock
- auto door lock
- interior lamp
- panic alarm
- hazard and horn reminder
- power window opener

OPERATED PROCEDURE

Power Door Lock Operation

Smart entrance control unit receives a LOCK signal from keyfob. Smart entrance control unit locks all doors with input of LOCK signal from keyfob.

When an UNLOCK signal is sent from keyfob once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from keyfob again within 5 seconds, all other door will be unlocked.

Select unlock mode can be changed by CONSULT-II (EL-324).

Auto Door Lock Operation

Auto lock function signal is sent for operation when any of the following signals are not sent within 5 minutes after the unlock signal is sent from the keyfob:

- when door switch is turned ON for open.
- when the ignition switch is turned ON.
- when the lock signal is sent from the keyfob.

Auto door lock mode can be changed by CONSULT-II (EL-324).

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

NAEL0392S02

SU

BR

ST

NAEL0392S03

RS

NAEL0392S0301

BT

HA

NAEL0392S0308

SC

EL

IDX

REMOTE KEYLESS ENTRY SYSTEM

System Description (Cont'd)

NAEL0392S0302

Hazard and Horn Reminder

Power is supplied at all times

- to horn relay terminals 1 and 3
- through 7.5A fuse (No. 52, located in the fusible link and fuse box), and
- to horn relay terminal 6
- through 10A fuse (No. 54, located in the fusible link and fuse box)

When smart entrance control unit receives LOCK or UNLOCK signal from keyfob with all doors closed, ground is supplied

- to horn relay terminal 2
- through smart entrance control unit terminal 42, and
- to smart entrance control unit terminals 47 and 48 from hazard warning lamp system.

Horn relay are now energized, and hazard warning lamp flashes and horn sounds as a reminder. The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

Operating function of hazard and horn reminder

	Lock		Unlock	
	Hazard warning lamp flash	Horn sound	Hazard warning lamp flash	Horn sound
C MODE	Twice	Once	Once	—
S MODE	Twice	—	—	—
MODE 3	—	—	—	—
MODE 4	Twice	—	Once	—
MODE 5	Twice	Once	—	—
MODE 6	—	Once	Once	—


How to change hazard and horn reminder mode

☑ With CONSULT-II

Hazard and horn reminder can be changed by CONSULT-II (EL-324).

☒ Without CONSULT-II

When LOCK and UNLOCK signals are sent from the keyfob for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



NOTE:

Reminder mode setting cannot be changed without CONSULT-II for MODES 3, 4, 5, and 6. However, C and S MODES can be changed without CONSULT-II.

Interior Lamp Operation

NAEL0392S0303

When the following input signals are both supplied:

- door switch CLOSED (when all the doors are closed);
- driver's door LOCKED;

REMOTE KEYLESS ENTRY SYSTEM

System Description (Cont'd)

remote keyless entry system turns on interior lamp and (for 30 seconds) with input of UNLOCK signal from keyfob. GI

For detailed description, refer to "INTERIOR, STEP, SPOT, VANITY MIRROR AND TRUNK ROOM LAMPS" (EL-98). MA

Panic Alarm Operation

When key switch is OFF (when ignition key is not inserted in key cylinder), remote keyless entry system turns horn and headlamp on and off intermittently with input of PANIC ALARM signal from keyfob. EM

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob. LC

For detailed description, refer to "VEHICLE SECURITY SYSTEM" (EL-347).

The panic alarm button's pressing time on keyfob can be changed with CONSULT-II (EL-324).

Power Window Opener Operation

The front power windows open when the unlock button on keyfob is activated and kept pressed for more than 3 seconds with the ignition key OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are carried out: FE

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated. CL
- When the unlock button is released.

The unlock button's pressing time can be changed with CONSULT-II (EL-324).

Door Lock/Unlock and front power window down signal is sent from smart entrance control unit to power window main switch with power window serial link communication link. Refer to "POWER WINDOW SERIAL LINK" (EL-274). Signals are supplied MT

- through smart entrance control unit terminal 33 AT
- to power window main switch terminal 14 and
- to front power window switch RH terminal 16. TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

REMOTE KEYLESS ENTRY SYSTEM

Schematic

Schematic

NAEL0393



REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS —



Wiring Diagram — KEYLESS —

NAEL0394

NAEL0394S01

FIG. 1

EL-KEYLES-01



REFER TO THE FOLLOWING.
 (E1) - SUPER MULTIPLE JUNCTION (SMJ)
 (M10), (E3) - FUSE BLOCK - JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)

NAEL0394S02

FIG. 2

EL-KEYLES-02



REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL031Q




REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)

FIG. 3

NAEL0394S03

EL-KEYLES-03



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)



MEL4130

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX









REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)


NAEL0394S05

FIG. 4

EL-KEYLES-04



MEL032Q




CONSULT-II Inspection Procedure

NAEL0395


“MULTI REMOTE ENT”

NAEL0395S01


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “MULTI REMOTE ENT”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

CONSULT-II Application Items

CONSULT-II Application Items

NAEL0457

NAEL0457S01

NAEL0457S0101

“MULTI REMOTE ENT” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.
PANIC BTN	Indicates [ON/OFF] condition of panic signal from keyfob.
UN BUTTON ON	Indicates [ON/OFF] condition of unlock switch form keyfob.
LK/UN BTN ON	Indicates [ON/OFF] condition of lock/unlock signal at the same time from keyfob.

NOTE:

Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

Active Test

NAEL0457S0102

Test Item	Description
INT/IGN ILLUM	This test is able to check interior lamp and ignition key hole illumination operation. The interior lamp and ignition key hole illumination are turned on when “ON” on CONSULT-II screen is touched.
HAZARD	This test is able to check hazard reminder operation. The hazard lamp turns on when “ON” on CONSULT-II screen is touched.
TRUNK OUTPUT	This test is able to check trunk lid opener actuator operation. The trunk is unlocked when “ON” on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after “ON” on CONSULT-II screen is touched.
HEAD LAMP	This test is able to check headlamps panic alarm operation. The headlamp illuminates for 0.5 seconds after “ON” on CONSULT-II screen is touched.
PW REMOTE DOWN SET	This test is able to check power window open operation. The front power windows activate for 10 seconds after “ON” on CONSULT-II screen is touched.

NOTE:

Even though TRUNK OUTPUT is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

Work Support

NAEL0457S0103

Test Item	Description
REMO CONT ID CONFIR	It can be checked whether keyfob ID code is registered or not in this mode.
REMO CONT ID REGIST	Keyfob ID code can be registered.
REMO CONT ID ERASUR	Keyfob ID code can be erased.

REMOTE KEYLESS ENTRY SYSTEM

CONSULT-II Application Items (Cont'd)

Test Item	Description
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed with this mode. Selects hazard and horn reminder mode among six steps (EL-316).
AUTO LOCK SET	Auto door lock mode can be selected among the following periods: <ul style="list-style-type: none"> ● MODE 1 (5 min.)/MODE 2 (OFF-Mode)/MODE 3 (1 min.)
PANIC ALARM SET	The panic alarm button's pressing time on keyfob can be selected among the following periods: <ul style="list-style-type: none"> ● MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)
TRUNK OPENER	The trunk lid opener button's pressing time on keyfob can be selected among the following periods: <ul style="list-style-type: none"> ● MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)
PW DOWN SET	The unlock button's pressing time on keyfob can be selected among the following periods: <ul style="list-style-type: none"> ● MODE 1 (3 sec.)/MODE 2 (OFF-Mode)/MODE 3 (5 sec.)

NOTE:

Even though TRUNK OPENER is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

Trouble Diagnoses

SYMPTOM CHART

NAEL0397

NOTE:

NAEL0397S01

- Always check keyfob battery before replacing keyfob.
- The panic alarm operation of remote keyless entry system does not activate with the ignition key inserted in the ignition key cylinder.

Symptom	Diagnoses/service procedure	Reference page (EL-)
All functions of remote keyless entry system do not operate.	1. Keyfob battery and function check	327
	2. Power supply and ground circuit for smart entrance control unit check	328
	3. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	340
The new ID of keyfob cannot be entered.	1. Keyfob battery and function check	327
	2. Key switch (insert) check	332
	3. Door switch check	330
	4. Door lock/unlock switch LH check	333
	5. Power supply and ground circuit for smart entrance control unit check	328
	6. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	340
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to EL-301)	1. Keyfob battery and function check	327
	2. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	340

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)


Symptom	Diagnoses/service procedure	Reference page (EL-)
Hazard and horn reminder does not activate properly when pressing lock or unlock button of keyfob.	1. Keyfob battery and function check	327
	2. Hazard reminder check	334
	3. Horn reminder check* *: Horn chirp can be activated or deactivated. First check the horn chirp setting. Refer to "System Description", EL-316.	335
	4. Door switch check	330
	5. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	340
Interior room lamp operation do not activate properly.	1. Interior room lamp operation check	337
	2. Door switch check	330
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Keyfob battery and function check	327
	2. Theft warning operation check. Refer to "PRELIMINARY CHECK" in "VEHICLE SECURITY SYSTEM".	358
	3. Key switch (insert) check	332
	4. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	340

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

REMOTE CONTROLLER BATTERY AND FUNCTION CHECK

-NAEL0397S02

1	CHECK REMOTE CONTROLLER BATTERY	
<p>Remove battery (refer to EL-342) and measure voltage across battery positive and negative terminals, (+) and (-).</p> <p>Voltage [V]: 2.5 - 3.0</p> <p>NOTE: Keyfob does not function if battery is not set correctly.</p>		
		
SEL237W		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Replace battery.

2	CHECK REMOTE CONTROLLER FUNCTION																						
<p> With CONSULT-II Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "PANIC BTN", "UN BUTTON ON" and "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II.</p>																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITOR</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td>LK BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>UN BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>TRUNK BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>PANIC BTN</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>UN BUTTON ON</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>LK/UN BTN ON</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		LK BUTTON/SIG	ON	UN BUTTON/SIG	ON	TRUNK BTN/SIG	ON	PANIC BTN	ON	UN BUTTON ON	ON	LK/UN BTN ON	ON					
DATA MONITOR																							
MONITOR																							
LK BUTTON/SIG	ON																						
UN BUTTON/SIG	ON																						
TRUNK BTN/SIG	ON																						
PANIC BTN	ON																						
UN BUTTON ON	ON																						
LK/UN BTN ON	ON																						
<p>When pushing each button of keyfob, the corresponding monitor item should be turned as follows.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th colspan="2" style="text-align: center;">Monitor item</th> </tr> </thead> <tbody> <tr> <td>Pushing LOCK</td> <td>LK BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing UNLOCK</td> <td>UN BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing TRUNK</td> <td>TRUNK BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing PANIC</td> <td>PANIC BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing UNLOCK</td> <td>UN BUTTON ON</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing LOCK and UNLOCK at the same time</td> <td>LK/UN BTN ON</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			Condition	Monitor item		Pushing LOCK	LK BUTTON/SIG	ON	Pushing UNLOCK	UN BUTTON/SIG	ON	Pushing TRUNK	TRUNK BTN/SIG	ON	Pushing PANIC	PANIC BTN/SIG	ON	Pushing UNLOCK	UN BUTTON ON	ON	Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON	ON
Condition	Monitor item																						
Pushing LOCK	LK BUTTON/SIG	ON																					
Pushing UNLOCK	UN BUTTON/SIG	ON																					
Pushing TRUNK	TRUNK BTN/SIG	ON																					
Pushing PANIC	PANIC BTN/SIG	ON																					
Pushing UNLOCK	UN BUTTON ON	ON																					
Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON	ON																					
SEL423Y																							
NOTE: Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.																							
OK or NG																							
OK	▶	Keyfob is OK. Further inspection is necessary. Refer to "SYMPTOM CHART", EL-325.																					
NG	▶	Replace keyfob. Refer to ID Code Entry Procedure.																					

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK


=NAEL0397S03

1	CHECK MAIN POWER SUPPLY CIRCUIT FOR SMART ENTRANCE CONTROL UNIT	
<p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M123 terminal 49 (G/R) or 51 (W/R) and ground.</p>		
SEL018Y		
Refer to wiring diagram in EL-319.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 40A fusible link (letter f, located in fuse and fusible link box) ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● M145 circuit breaker ● Harness for open or short between smart entrance control unit and fuse

2	CHECK IGNITION SWITCH “ACC” CIRCUIT	
<p>1. Disconnect smart entrance control unit harness connector. 2. Check voltage between smart entrance control unit harness connector M122 terminal 26 (G/W) and ground while ignition switch is “ACC”.</p>		
SEL019Y		
Refer to wiring diagram in EL-319.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 10, located in fuse block (J/B)] ● Harness for open or short between smart entrance control unit and fuse

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

3	CHECK GROUND CIRCUIT FOR SMART ENTRANCE CONTROL UNIT
<p>Check continuity between smart entrance control unit harness connector M122 terminal 43 (B) or M123 terminal 64 (B) and ground.</p>	
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> </div>	
<p>Refer to wiring diagram in EL-319.</p> <p style="text-align: right;">SEL020Y</p>	
<p>OK or NG</p>	
OK	▶ Power supply and ground circuits are OK.
NG	▶ Check ground harness.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

DOOR SWITCH CHECK

=NAEL0397S04

1 CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II

Check door switches ("DOOR SW-RR", "DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
DOOR SW-RR	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF


	Monitor item	Condition	Condition
DOOR SW-RR	Rear doors switch	Open	ON
		Closed	OFF
DOOR SW-DR	Door switch LH	Open	ON
		Closed	OFF
DOOR SW-AS	Door switch RH	Open	ON
		Closed	OFF

SEL024Y

Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.

Smart entrance control unit connector



	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front door switch LH	1	Ground	Open	0
			Closed	Approx. 12
Front door switch RH	2	Ground	Open	0
			Closed	Approx. 5
Rear and back door switches	3	Ground	Open	0
			Closed	Approx. 5

SEL021YD




Refer to wiring diagram in EL-320.

OK or NG

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

2	CHECK DOOR SWITCH																						
	<p>1. Disconnect door switch harness connector.</p> <p>2. Check the following.</p> <ul style="list-style-type: none"> ● Continuity between front door switch connector B9 (LH) or B68 (RH) terminals 1 and 2 ● Continuity between front door switch connector B9 (LH) or B68 (RH) terminal 3 and ground ● Continuity between back door switch connector D208 terminals 1 and 2 ● Continuity between rear door switch connector B18 (LH) or B71 (RH) terminal 1 and ground <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Front door switch connector</p>  </div> <div style="text-align: center;">  <p>Back door switch connector</p>  </div> <div style="text-align: center;">  <p>Rear door switch connector</p>  </div> </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switches</td> <td rowspan="2">1 - 2 3 - Ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Back door switch</td> <td rowspan="2">1 - 2</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Rear door switches</td> <td rowspan="2">1 - Ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table> <p style="text-align: right;">SEL287YA</p> <p style="text-align: center;">OK or NG</p>		Terminals	Condition	Continuity	Front door switches	1 - 2 3 - Ground	Closed	No	Open	Yes	Back door switch	1 - 2	Closed	No	Open	Yes	Rear door switches	1 - Ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity																				
Front door switches	1 - 2 3 - Ground	Closed	No																				
		Open	Yes																				
Back door switch	1 - 2	Closed	No																				
		Open	Yes																				
Rear door switches	1 - Ground	Closed	No																				
		Open	Yes																				
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● Door switch ground circuit (Front or back door) or door switch ground condition (Rear door) ● Harness for open or short between smart entrance control unit and door switch 																						
NG	<p>▶ Replace door switch.</p>																						


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK

=NAEL0397S05

1	CHECK KEY SWITCH INPUT SIGNAL	<p> With CONSULT-II Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;"></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> </div> <div style="margin-left: 20px;"> <p>When key is inserted to ignition key cylinder: KEY ON SW ON</p> <p>When key is removed from ignition key cylinder: KEY ON SW OFF</p> </div> </div>	DATA MONITOR		MONITOR		KEY ON SW	ON
DATA MONITOR								
MONITOR								
KEY ON SW	ON							
		SEL315W						
<p> Without CONSULT-II Check voltage between control unit harness connector M122 terminal 25 (W/R) and ground.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div> <p>Voltage [V]:</p> <p>Condition of key switch : Key is inserted. Approx. 12</p> <p>Condition of key switch : Key is removed. 0</p> </div> </div> <p style="margin-top: 20px;">Refer to wiring diagram in EL-319.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>								
OK		▶ Key switch is OK.						
NG		▶ GO TO 2.						

2	CHECK KEY SWITCH (INSERT)	<p>Check continuity between key switch connector terminals 1 and 2.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>Key switch connector (E5)</p>  </div> <div> <p>Continuity:</p> <p>Condition of key switch: Key is inserted. Yes</p> <p>Condition of key switch: Key is removed. No</p> </div> </div>
		SEL308X
OK or NG		
OK		▶ Check the following.
		<ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between smart entrance control unit and key switch
NG		▶ Replace key switch.

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH LH CHECK

=NAEL0397S06

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

LOCK SW DR/AS ON

When lock/unlock switch is turned to UNLOCK:

UNLK SW DR/AS ON


SEL341W

Without CONSULT-II


1. Remove key from ignition key cylinder.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with an oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals shown in the figure below can be detected during the first 10 sec. just after door lock/unlock switch is turned to "LOCK" or "UNLOCK".



Smart entrance control unit connector



Refer to wiring diagram in EL-319.



Voltage:

12V → 9V (10 sec.) measurement by analog circuit tester.

SEL699YA

OK or NG

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.


REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

HAZARD REMINDER CHECK

=NAEL0397S07

1	CHECK HAZARD INDICATOR	
Check if hazard indicator flashes with hazard switch.		
Does hazard indicator operate?		
Yes	▶	GO TO 2.
No	▶	Check "hazard indicator" circuit.

2	CHECK HAZARD REMINDER OPERATION WITH CONSULT-II	
<p> With CONSULT-II</p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "HAZARD" and touch "ON".</p>		
		
Hazard indicator should illuminate.		
SEL347W		
NOTE: If CONSULT-II is not available, skip this procedure and go to the next step.		
OK or NG		
OK	▶	Hazard reminder operation is OK.
NG	▶	Replace smart entrance control unit.

3	CHECK HAZARD REMINDER OPERATION WITHOUT CONSULT-II							
<p> Without CONSULT-II</p> <p>Apply ground to smart entrance control unit harness connector M122 terminal 47 (GY/L) and 48 (GY/R).</p>								
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Smart entrance control unit connector</p>  </div> <div style="flex: 1; margin-left: 20px;">  <p>CONNECT</p>   </div> <div style="flex: 2; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition of lock or unlock button</th> <th style="text-align: center;">Voltage (V)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Push.</td> <td style="text-align: center;">Approx. more than 0 - 12</td> </tr> <tr> <td style="text-align: center;">Do not push.</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> </div> </div>			Condition of lock or unlock button	Voltage (V)	Push.	Approx. more than 0 - 12	Do not push.	0
Condition of lock or unlock button	Voltage (V)							
Push.	Approx. more than 0 - 12							
Do not push.	0							
SEL027Y								
Refer to wiring diagram in EL-321.								
OK or NG								
OK	▶	System is OK.						
NG	▶	Replace smart entrance control unit.						

REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

HORN REMINDER CHECK

=NAEL0397S08

1	CHECK HORN	
Check if horn sounds with horn switch.		
Does horn operate?		
Yes	▶	GO TO 2.
No	▶	Check horn circuit.

2	CHECK HORN REMINDER OPERATION WITH CONSULT-II							
<p> With CONSULT-II</p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "HORN" and touch "ON".</p>								
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <p style="text-align: center; margin: 0;">ACTIVE TEST</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 2px;">HORN</td> <td style="width: 50%; padding: 2px;">OFF</td> </tr> <tr> <td style="height: 100px;"></td> <td style="height: 100px;"></td> </tr> <tr> <td style="text-align: center; padding: 2px;">ON</td> <td style="text-align: center; padding: 2px;"></td> </tr> </table> </div> <div style="text-align: center;"> <p>Horn should sound.</p> </div> </div>			HORN	OFF			ON	
HORN	OFF							
ON								
SEL451Y								
NOTE: If CONSULT-II is not available, skip this procedure and go to the next step.								
OK or NG								
OK	▶	Horn reminder operation is OK.						
NG	▶	GO TO 4.						

3	CHECK HORN REMINDER OPERATION WITHOUT CONSULT-II	
<p> Without CONSULT-II</p> <p>1. Disconnect smart entrance control unit harness connector. 2. Apply ground to smart entrance control unit harness connector M122 terminal 42 (LG/B).</p>		
		
Refer to wiring diagram in EL-321.		
Does horn sound?		
Yes	▶	Replace smart entrance control unit.
No	▶	GO TO 4.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC


EL


IDX

REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

4	CHECK HORN RELAY
Check horn relay.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace horn relay.

5	CHECK POWER SUPPLY FOR HORN RELAY
<ol style="list-style-type: none"> 1. Disconnect horn relay harness connector. 2. Check voltage between horn relay harness connector E118 terminal 1 (G/B) and ground. 	
	
Battery voltage should exist.	
SEL326XB	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 52, located in fuse block (J/B)] ● Harness for open or short between horn relay and fuse

6	CHECK HORN RELAY CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect horn relay harness connector. 2. Check voltage between horn relay harness connector E118 terminals 3 (G/B) and 5 (R). 3. Check voltage between horn relay harness connector E118 terminals 6 (LG) and 7 (G). 	
	
Battery voltage should exist.	
SEL327XB	
OK or NG	
OK	▶ Check harness for open or short between smart entrance control unit and horn relay.
NG	▶ Check the following. <ul style="list-style-type: none"> ● Harness for open or short between horn relay and fuse ● 7.5A fuse (No. 52, located in the fuse and fusible link box) ● 10A fuse (No. 54, located in the fuse and fusible link box)


REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

INTERIOR ROOM LAMP OPERATION CHECK

=NAEL0397S09

1	CHECK ROOM INTERIOR LAMP	
Check if the interior room lamp switch is in the "ON" position and the lamp illuminates.		
Does interior room lamp illuminate?		
Yes	▶	GO TO 2.
No	▶	Check the following. <ul style="list-style-type: none"> ● Harness for open or short between smart entrance control unit and interior room lamp ● Interior room lamp

2	CHECK INTERIOR ROOM LAMP OPERATION									
<p> With CONSULT-II</p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "INT/IGN ILLUM" and touch "ON".</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <table style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center; padding: 2px;">ACTIVE TEST</th></tr> <tr><td style="padding: 2px;">IN T/IGN ILLUM</td><td style="padding: 2px; text-align: right;">OFF</td></tr> <tr><td colspan="2" style="height: 100px;"></td></tr> <tr><td colspan="2" style="text-align: center; padding: 2px;">ON</td></tr> </table> </div> <div style="text-align: center;"> <p>Interior room lamp should illuminate.</p> </div> </div> <p style="text-align: right; margin-right: 20px;">SEL312Y</p>			ACTIVE TEST		IN T/IGN ILLUM	OFF			ON	
ACTIVE TEST										
IN T/IGN ILLUM	OFF									
ON										
<p> Without CONSULT-II</p> <p>Push unlock button of keyfob with all doors closed and driver's door locked, and check voltage between smart entrance control unit harness connector M122 terminal 31 (R/B) and ground.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-right: 20px;">    </div> <div> <p>Voltage [V]:</p> <p>Unlock button is pushed. 0 (For approx. 30 seconds.)</p> <p>Unlock button is not pushed. Battery voltage</p> </div> </div> <p style="text-align: right; margin-right: 20px;">SEL029Y</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>										
Refer to wiring diagram in EL-319.										
OK	▶	System is OK.								
NG	▶	Check harness for open or short between smart entrance control unit and interior room lamp.								

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM


ID Code Entry Procedure KEYFOB ID SET UP WITH CONSULT-II

=NAEL0398


NAEL0398S01

NOTE:


If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. When the ID code of a lost keyfob is not known, all keyfob ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.




1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "SMART ENTRANCE".
If "SMART ENTRANCE" is not indicated, go to GI-42, "CONSULT-II Data Link Connector (DLC) Circuit".




6. Touch "MULTI REMOTE ENT".

REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)



7. Touch "WORK SUPPORT".



8. The items are shown on the figure at left can be set up.

- "REMO CONT ID CONFIR"
Use this mode to confirm if a keyfob ID code is registered or not.
- "REMO CONT ID REGIST"
Use this mode to register a keyfob ID code.

NOTE:

Register the ID code when keyfob or smart entrance control unit is replaced, or when additional keyfob is required.

- "REMO CONT ID ERASUR"
Use this mode to erase a keyfob ID code.

Refer to the EL-324, "WORK SUPPORT" in "CONSULT-II Application Items" for the following items.

- "MULTI ANSWER BACK SET"
- "AUTO LOCK SET"
- "PANIC ALARM SET"
- "TRUNK OPENER"
- "PW DOWN SET"

NOTE:

Even though TRUNK OPENER is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)

KEYFOB ID SET UP WITHOUT CONSULT-II

NAEL0398S02



SEL170YA

REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)

NOTE:

- If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost keyfob is not known, all keyfob ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.
To erase all ID codes in memory, register one ID code (keyfob) four times. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.
- When registering an additional keyfob, the existing ID codes in memory may or may not be erased. If four ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than four ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new keyfob, repeat the procedure "Additional ID code entry" for each new keyfob.
- Entry of maximum four ID codes is allowed. When more than four ID codes are entered, the oldest ID code will be erased.
- Even if the same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REMOTE KEYLESS ENTRY SYSTEM





Keyfob Battery Replacement

Keyfob Battery Replacement

NAEL0399

NOTE:

- Be careful not to touch the circuit board or battery terminal.
- The keyfob is water-resistant. However, if it does get wet, immediately wipe it dry.





SEL485Y

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0400



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SEL677Y

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description

System Description


NAEL0401

NAEL0401S01

NAEL0401S0101

DESCRIPTION

1. Operation Flow



SEL334W

2. Setting The Vehicle Security System

NAEL0401S0102

Initial condition

- 1) Ignition switch is in OFF position.

Disarmed phase

When the vehicle security system is in the disarmed phase, the security indicator lamp blinks every 2.6 seconds.

Pre-armed phase and armed phase

When the following operation 1) or 2) is performed, the vehicle security system turns into the “pre-armed” phase. (The security indicator lamp illuminates.)

- 1) Smart entrance control unit receives LOCK signal from key cylinder switch or keyfob after hood, glass hatch and all doors are closed.
- 2) Hood, glass hatch and all doors are closed after front doors are locked by key, lock/unlock switch or multi-remote controller.

After about 30 seconds, the system automatically shifts into the “armed” phase (the system is set). (The security indicator lamp blinks every 2.6 seconds.)

3. Canceling The Set Vehicle Security System

NAEL0401S0103

When the following 1) or 2) operation is performed, the armed phase is canceled.

- 1) Unlock the doors with the key or keyfob.
- 2) Open the glass hatch with the key or keyfob.

4. Activating The Alarm Operation of The Vehicle Security System

NAEL0401S0104

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.6 seconds.)

When the following operation 1) or 2) is performed, the system sounds the horns and flashes the headlamps for about 50 seconds.

- 1) Engine hood, glass hatch or any door is opened during armed phase.
- 2) Disconnecting and connecting the battery connector before canceling armed phase.

POWER SUPPLY AND GROUND

NAEL0401S02

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to security indicator lamp terminal 1, and
- to smart entrance control unit terminal 49.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

GI

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

MA

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M4, M66, M111, M147 and M157.

EM

LC

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors, hood and glass hatch.

NAEL0401S03

EC

Pattern A

To activate the vehicle security system, the smart entrance control unit must receive signals indicating the doors, hood and glass hatch are closed.

NAEL0401S0301

FE

When a door is open, smart entrance control unit terminal 1, 2 or 3 receives a ground signal from each door switch.

CL

When the hood is open, smart entrance control unit terminal 6 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E13 and E41.

MT

When the glass hatch is open, smart entrance control unit terminal 13 receives a ground signal

- from terminal 1 of the glass hatch switch
- through body grounds B11, B22 and D210.

AT

When smart entrance control unit receives LOCK signal from key cylinder switch or keyfob and none of the described conditions exist, the vehicle security system will automatically shift to armed mode.

TF

Pattern B

To activate the vehicle security system, the smart entrance control unit must receive signal indicating any door (including hood and glass hatch) is opened.

NAEL0401S0302

PD

When the front doors are locked with key, lock/unlock switch or keyfob and then all doors are closed, the vehicle security system will automatically shift to armed mode.

AX

VEHICLE SECURITY SYSTEM ACTIVATION

Pattern A

With all doors (including hood and glass hatch) closed, if the key is used to lock doors, smart entrance control unit terminal 33 receives a signal from power window main switch terminal 14.

NAEL0401S04

SU

When key cylinder switch is in LOCK position, ground is supplied

- to power window main switch terminal 6
- from terminal 3 of the front door key cylinder switch LH
- through terminal 2 of front door key cylinder switch LH
- through body grounds M4, M66, M111, M147 and M157 or

BR

smart entrance control unit terminal 11 receives a ground signal

- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

ST

RS

If this signal, or lock signal from keyfob is received by the smart entrance control unit, the vehicle security system will activate automatically.

BT

HA

NOTE:

Vehicle security system can be set even though all doors are not locked.

SC

Pattern B

With any door (including hood and glass hatch) open, if lock/unlock switch is used to lock doors, smart entrance control unit terminal 33 receives a LOCK signal

NAEL0401S0402

- from terminal 14 of lock/unlock switch LH or
- from terminal 16 of lock/unlock switch RH, or

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

With any door (including hood and glass hatch) open if the key is used to lock doors, smart entrance control unit terminal 33 receives a LOCK signal from power window main front switch terminal 14. Refer to power window serial link (EL-274).

When key cylinder switch LOCK signal ground is supplied

- to power window main switch terminal 4
- from terminal 3 of the front door key cylinder switch LH
- through terminal 2 of front door key cylinder switch LH
- through body grounds M4, M66, M111, M147 and M157, or

smart entrance control unit terminal 11 receives a ground signal

- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

If these signals and lock signal from keyfob are received by the smart entrance control unit, ground signals of terminals 1, 2 and 3 are interrupted and all doors are closed, the vehicle security system will activate automatically.

NOTE:

Vehicle security system can be set even though the rear door is not locked.

Once the vehicle security system has been activated, smart entrance control unit terminal 38 supplies ground to terminal 2 of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blinks every 2.6 seconds.

Now the vehicle security system is in armed phase.

VEHICLE SECURITY SYSTEM ALARM OPERATION

NAEL0401S05

The vehicle security system is triggered by

- opening a door
- opening the hood or the glass hatch
- detection of battery disconnect and connect.

Once the vehicle security system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 1, 2, 3 (door switch), 13 (glass hatch switch) or 6 (hood switch), the vehicle security system will be triggered. The headlamps flash and the horn sounds intermittently.

Power is supplied at all times

- through 7.5A fuse (No. 52, located in fuse and fusible link box)
- to horn relay terminals 1 and 3.
- through 10A fuse (No. 54, located in fuse and fusible link box)
- to horn relay terminal 6.
- through 15A fuse (No. 60, located in fuse and fusible link box)
- to headlamp LH relay terminals 1 and 3,
- through 15A fuse (No. 59, located in fuse and fusible link box)
- to headlamp RH relay terminals 1 and 3.

When the vehicle security system is triggered, ground is supplied intermittently

- to headlamp (LH and RH) relay terminal 2 from smart entrance control unit terminals 21 and 59
- through smart entrance control unit terminals 43 and 64.

When headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

The headlamps flash intermittently.

When the vehicle security system is triggered, ground is supplied intermittently

- from smart entrance control unit terminal 42
- to horn relay terminal 2.

When horn relay are energized, then power is supplied to horn.

The horn sounds intermittently.

The alarm automatically turns off after 50 seconds but will reactivate if the vehicle is tampered with again.

VEHICLE SECURITY SYSTEM DEACTIVATION

NAEL0401S06

To deactivate the vehicle security system, a door or glass hatch must be unlocked with the key or keyfob.

When the key is used to unlock the door, smart entrance control unit terminal 33 receives an UNLOCK signal from power window main switch terminal 14. Refer to "POWER WINDOW SERIAL LINK" (EL-274).

When key cylinder switch is in UNLOCK position, the ground is supplied

VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

- to power window main switch terminal 6
- from the front door key cylinder switch LH terminal 1
- through front door key cylinder switch terminal 2,
- through body grounds M4, M66, M111, M147 and M157.

When the key is used to open the glass hatch, smart entrance control unit terminal 12 receives a ground signal from terminal 3 of the back door key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from keyfob, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required. NAEL0401S07

When the remote keyless entry system (panic alarm) is triggered, ground is supplied intermittently

- from smart entrance control unit terminals 21 and 59
- to headlamp (LH and RH) relay terminal 2, and
- from smart entrance control unit terminal 42
- to horn relay terminal 2.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic

Schematic


NAEL0402



MEL126S

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic (Cont'd)



Ⓢ : For U.S.A.

Ⓢ : For Canada

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

MEL437P

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC —



Wiring Diagram — VEHSEC —

NAEL0403


NAEL0403S01

FIG. 1

EL-VEHSEC-01



REFER TO THE FOLLOWING.
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M10) -FUSE BLOCK-JUNCTION BOX (J/B)








VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

FIG. 2

NAEL0403S02

EL-VEHSEC-02



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL034Q









VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

FIG. 3

NAEL0403S03


EL-VEHSEC-03



MEL035Q

VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II Inspection Procedure




CONSULT-II Inspection Procedure

=NAEL0404


NAEL0404S01

“THEFT WAR ALM”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” and “CONSULT-II CONVERTER” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START (NISSAN BASED VHCL)”.



5. Touch “SMART ENTRANCE”.
If “SMART ENTRANCE” is not indicated, go to GI-42, “CONSULT-II Data Link Connector (DLC) Circuit”.



6. Touch “THEFT WAR ALM”.



7. Select diagnosis mode.
“DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II Application Item

CONSULT-II Application Item

“THEFT WAR ALM” Data Monitor

NAEL0405

NAEL0405S01

NAEL0405S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.
TRNK OPNR SW	Indicates [ON/OFF] condition of back door switch.
KEY CYL LK SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
KEY CYL UN SW	Indicates [ON/OFF] condition of unlock signal from key cylinder switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
TRNK OPN MNTR	Indicates [ON/OFF] condition of back door switch.
TRUNK KEY SW	Indicates [ON/OFF] condition of back door key cylinder switch.
HOOD SWITCH	Indicates [ON/OFF] condition of hood switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from door lock/unlock LH and RH.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.

NOTE:

Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

Active Test

NAEL0405S0102

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when “ON” on CONSULT-II screen is touched.
HORN	This test is able to check vehicle security alarm operation. The alarm will be activated for 0.5 seconds after “ON” on CONSULT-II screen is touched.
HEAD LAMP	This test is able to check vehicle security alarm headlamp operation. The headlamp illuminates for 0.5 seconds after “ON” on CONSULT-II screen is touched.

Work Support

NAEL0405S0103

Test Item	Description
THEFT ALM TRG	The switch which triggered theft warning alarm is recorded. This mode is able to confirm and erase the record of theft warning alarm. The trigger data can be erased by touching “CLEAR” on CONSULT-II screen.
SECURITY ALARM SET	Theft warning alarm mode can be changed in this mode. Selects ON-OFF of theft warning alarm mode. ● MODE 1 (ON)/MODE 2 (OFF)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

NAEL0406S02

REFERENCE PAGE (EL-)	358	360	361	366	368	370	373	375	325
SYMPTOM	PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND GLASS HATCH SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	VEHICLE SECURITY HORN ALARM CHECK	VEHICLE SECURITY HEADLAMP ALARM CHECK	Check "MULTI-REMOTE CONTROL" system.
1	Vehicle security indicator does not illuminate for 30 seconds.	X	X	X	X				
	Vehicle security system cannot be set by ...								
	All items	X	X	X					
	Door outside key	X				X			
2	Back door key	X					X		
	Multi-remote control	X							X
	*1 Vehicle security system does not alarm when ...								
3	Any door is opened.	X		X					
	Any door is unlocked without using key or multi-remote controller	X							
4	Vehicle security alarm does not activate.								
	All function	X		X					
	Horn alarm	X					X		
5	Headlamp alarm	X						X	
	Vehicle security system cannot be canceled by ...								
	Door outside key	X				X			
6	Back door key	X					X		
	Multi-remote control	X							X

X : Applicable

*1: Make sure the system is in the armed phase.


Before starting trouble diagnoses above, perform preliminary check, EL-358.

Symptom numbers in the symptom chart correspond with those of preliminary check.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

NAEL0406S03


Power Supply Circuit Check

NAEL0406S0301

Terminals		Ignition switch position			
Connector	Terminal (Wire color)	(-)	(+)		
			OFF	ACC	ON
M123	49 (G/R)	Ground	Battery voltage	Battery voltage	Battery voltage
M122	26 (G/W)	Ground	0V	Battery voltage	Battery voltage
M122	27 (W/B)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 7.5A fuse [No. 11, located in fuse block (J/B)]
- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse.



Ground Circuit Check

NAEL0406S0302

Terminals		(-)	Continuity
Connector	Terminal (Wire color)		
		M122	43 (B)
M123	64 (B)		

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

DOOR, HOOD AND GLASS HATCH SWITCH CHECK


=NAEL0406S04

Door Switch Check

NAEL0406S0401

1	PRELIMINARY CHECK	
<p>1. Turn ignition switch OFF and remove key from ignition key cylinder. “SECURITY” indicator lamp should blink every 2.6 seconds.</p> <p>2. Close all doors, hood and glass hatch.</p> <p>3. Lock doors with multi-remote controller from inside the vehicle. “SECURITY” indicator lamp should turn on for 30 seconds.</p> <p>4. Unlock any door with the door lock knob and open the door within 30 seconds after door is locked. “SECURITY” indicator lamp should turn off.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Door switch is OK, and go to hood switch check.
NG	▶	GO TO 2.

2	CHECK DOOR SWITCH INPUT SIGNAL																																	
<p> With CONSULT-II Check door switches (“DOOR SW-RR”, “DOOR SW-DR” and “DOOR SW-AS”) in “DATA MONITOR” mode with CONSULT-II.</p>																																		
<table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>DOOR SW-RR</td> <td>OFF</td> </tr> <tr> <td>DOOR SW-DR</td> <td>OFF</td> </tr> <tr> <td>DOOR SW-AS</td> <td>OFF</td> </tr> </tbody> </table> <table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th></th> <th>Monitor item</th> <th>Condition</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">DOOR SW-RR</td> <td rowspan="2">Rear doors switch</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> <tr> <td rowspan="2">DOOR SW-DR</td> <td rowspan="2">Door switch LH</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> <tr> <td rowspan="2">DOOR SW-AS</td> <td rowspan="2">Door switch RH</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		DOOR SW-RR	OFF	DOOR SW-DR	OFF	DOOR SW-AS	OFF		Monitor item	Condition	Condition	DOOR SW-RR	Rear doors switch	Open	ON	Closed	OFF	DOOR SW-DR	Door switch LH	Open	ON	Closed	OFF	DOOR SW-AS	Door switch RH	Open	ON	Closed	OFF
DATA MONITOR																																		
MONITOR																																		
DOOR SW-RR	OFF																																	
DOOR SW-DR	OFF																																	
DOOR SW-AS	OFF																																	
	Monitor item	Condition	Condition																															
DOOR SW-RR	Rear doors switch	Open	ON																															
		Closed	OFF																															
DOOR SW-DR	Door switch LH	Open	ON																															
		Closed	OFF																															
DOOR SW-AS	Door switch RH	Open	ON																															
		Closed	OFF																															
SEL024Y																																		

<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.</p>																														
<p>Smart entrance control unit connector</p> 																														
<table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switch LH</td> <td rowspan="2">1</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">Front door switch RH</td> <td rowspan="2">2</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">Rear and back door switches</td> <td rowspan="2">3</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> </tbody> </table>				Terminals		Condition	Voltage [V]	(+)	(-)	Front door switch LH	1	Ground	Open	0	Closed	Approx. 5	Front door switch RH	2	Ground	Open	0	Closed	Approx. 5	Rear and back door switches	3	Ground	Open	0	Closed	Approx. 5
	Terminals			Condition	Voltage [V]																									
	(+)	(-)																												
Front door switch LH	1	Ground	Open	0																										
			Closed	Approx. 5																										
Front door switch RH	2	Ground	Open	0																										
			Closed	Approx. 5																										
Rear and back door switches	3	Ground	Open	0																										
			Closed	Approx. 5																										
SEL021YA																														
Refer to wiring diagram in EL-351.																														
OK or NG																														
OK	▶	Door switch is OK, and go to hood switch check.																												
NG	▶	GO TO 3.																												

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM


Trouble Diagnoses (Cont'd)

3 CHECK DOOR SWITCH


1. Disconnect door switch connector.
2. Check the following.
 - Continuity between front door switch connector B9 (LH) or B68 (RH) terminals 1 and 2
 - Continuity between front door switch connector B9 (LH) or B68 (RH) terminals 3 and ground
 - Continuity between back door switch connector D208 terminals 1 and 2
 - Continuity between rear door switch connector B18 (LH) or B71 (RH) terminal 1 and ground




Front door switch connector



Back door switch connector



Rear door switch connector



	Terminals	Condition	Continuity
Front door switches	1 - 2	Closed	No
		Open	Yes
Back door switch	1 - 2	Closed	No
		Open	Yes
Rear door switches	1 - Ground	Closed	No
		Open	Yes

SEL287YA

OK or NG

OK



Check the following.

- Door switch ground circuit (Front or back) or door switch ground condition
- Harness for open or short between smart entrance control unit and door switch

NG



Replace door switch.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


Hood Switch Check

=NAEL0406S0402

1	PRELIMINARY CHECK	
<p>1. Turn ignition switch OFF and remove key from ignition key cylinder. “SECURITY” indicator lamp should blink every 2.6 seconds.</p> <p>2. Close all doors, hood and trunk lid.</p> <p>3. Lock doors with multi-remote controller from inside the vehicle. “SECURITY” indicator lamp should turn on for 30 seconds.</p> <p>4. Unlock hood with hood opener within 30 seconds after door is locked. “SECURITY” indicator lamp should turn off.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Hood switch is OK, and go to trunk room lamp switch check.
NG	▶	GO TO 2.

2	CHECK HOOD SWITCH FITTING CONDITION	
OK or NG		
OK	▶	GO TO 3.
NG	▶	Adjust installation of hood switch or hood.

3	CHECK HOOD SWITCH INPUT SIGNAL							
<p> With CONSULT-II Check hood switch (“HOOD SWITCH”) in “DATA MONITOR” mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th></th></tr> <tr><td>HOOD SWITCH</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		HOOD SWITCH	OFF
DATA MONITOR								
MONITOR								
HOOD SWITCH	OFF							
<p>When hood is open: HOOD SWITCH ON</p> <p>When hood is closed: HOOD SWITCH OFF</p>								
SEL354W								

<p> Without CONSULT-II Check voltage between smart entrance control unit harness connector M121 terminal 6 (Y/B) and ground.</p>		
<p>Smart entrance control unit connector</p> 		
<p>Voltage [V]: Engine hood is open. 0 Engine hood is closed. Approx. 5</p>		
SEL035Y		
OK or NG		
OK	▶	Hood switch is OK, and go to glass hatch switch check.
NG	▶	GO TO 4.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


4	CHECK HOOD SWITCH	
	<p>1. Disconnect hood switch connector.</p> <p>2. Check continuity between hood switch connector terminals 1 and 2.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div data-bbox="467 268 747 598" style="text-align: center;"> <p>Hood switch connector (E3)</p> </div> <div data-bbox="971 346 1258 514" style="text-align: center;"> <p>Continuity: Condition: Pushed No Condition: Released Yes</p> </div> </div> <p style="text-align: right;">SEL338X</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Hood switch ground circuit ● Harness for open or short between smart entrance control unit and hood switch
NG	▶	<p>Replace hood switch.</p>


VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

Glass Hatch Switch Check

=NAEL0406S0403

1	CHECK GLASS HATCH SWITCH INPUT SIGNAL	
<p>Check voltage between smart entrance control unit harness connector M121 terminal 13 (L/W) and ground.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p>Smart entrance control unit connector</p>  </div> <div style="width: 20%; text-align: center;">    </div> <div style="width: 40%;"> <p>Voltage [V]: Glass hatch is open. Approx. 5 Glass hatch is closed. Approx. 0</p> </div> </div>		
SEL326YA		
OK or NG		
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 2.

2	CHECK GLASS HATCH SWITCH	
<p>1. Disconnect glass hatch switch connector. 2. Check continuity between glass hatch switch connector terminals 1 and 2.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p style="text-align: center;">  Glass hatch switch connector (D200) </p>  </div> <div style="width: 40%;"> <p>Continuity: Condition: Closed No Condition: Open Yes</p> </div> </div>		
SEL340X		
OK or NG		
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Glass hatch switch ground circuit ● Harness for open or short between smart entrance control unit and glass hatch switch
NG	▶	Replace glass hatch switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


SECURITY INDICATOR LAMP CHECK

=NAEL0406S05

1 CHECK INDICATOR LAMP OPERATION

With CONSULT-II

1. Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.
2. Select "THEFT IND" and touch "ON".




Security indicator lamp should illuminate.

SEL356W

Without CONSULT-II

1. Disconnect smart entrance control unit harness connector.
2. Check voltage between smart entrance control unit harness connector M122 terminal 38 (BR/Y) and ground.



Battery voltage should exist.

Refer to wiring diagram in EL-350.

SEL037Y


OK or NG

OK ► Security indicator lamp is OK.

NG ► GO TO 2.

2 CHECK SECURITY INDICATOR LAMP

1. Disconnect security indicator lamp connector.
2. Apply 12V direct current to security indicator lamp harness connector M20 terminals 1 and 2.



Security indicator lamp should illuminate.

SEL696Y


OK or NG

OK ► GO TO 3.

NG ► Replace security indicator lamp.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

3	CHECK POWER SUPPLY CIRCUIT FOR SECURITY INDICATOR LAMP	
<p>1. Disconnect security indicator lamp connector. 2. Check voltage between security indicator lamp harness connector M20 terminal 1 (R/G) and ground.</p>		
<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;"> <p>Security indicator lamp connector</p>  </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> <div style="text-align: right;"> <p>SEL697Y</p> </div> </div> <p style="text-align: center;">OK or NG</p>		
OK	▶	Check harness for open or short between security indicator lamp and smart entrance control unit.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between security indicator lamp and fuse

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

FRONT DOOR KEY CYLINDER SWITCH CHECK

=NAEL0406S06

1 CHECK FRONT DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front door key cylinder is turned to LOCK:

KEY CYL LK-SW ON



When key inserted in front door key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WF

Without CONSULT-II

1. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when key inserted in front key cylinder is turned "LOCK" or "UNLOCK".
2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Voltage:
12V → 9V (10 sec.)
measurement by analog
circuit tester.

SEL700YA

Refer to wiring diagram in EL-352.


OK or NG

OK ► Front door key cylinder switch LH is OK.

NG ► GO TO 2.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

2	CHECK FRONT DOOR KEY CYLINDER SWITCH														
	<p>1. Disconnect front door key cylinder switch LH connector. 2. Check continuity between front door key cylinder switch LH connector terminals.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  <p>Front door key cylinder switch LH connector (D9)</p>  </div> <div> <p>① : Door unlock switch terminal ② : Ground terminal ③ : Door lock switch terminal</p> <table border="1" data-bbox="795 409 1356 567"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LH: 3 - 2</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">LH: 1 - 2</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL313XB</p> <p style="text-align: center;">OK or NG</p>		Terminals	Key position	Continuity	LH: 3 - 2	Neutral/Unlock	No	Lock	Yes	LH: 1 - 2	Neutral/Lock	No	Unlock	Yes
Terminals	Key position	Continuity													
LH: 3 - 2	Neutral/Unlock	No													
	Lock	Yes													
LH: 1 - 2	Neutral/Lock	No													
	Unlock	Yes													
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Front door key cylinder switch LH ground circuit • Harness for open or short between power window main switch and front door key cylinder switch LH 													
NG	▶	Replace front door key cylinder switch LH.													

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

BACK DOOR KEY CYLINDER SWITCH CHECK

=NAEL0406S07

1 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back door key cylinder is turned to LOCK:

KEY CYL LK-SW ON


When key inserted in back door key cylinder is turned to UNLOCK:

KEY CYL UN-SW ON

SEL342WG

Without CONSULT-II

Check voltage between smart entrance control unit terminals 10 (LG), 11 (Y) or 12 (W/PU) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
Back door	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5
Glass hatch	12	Ground	Unlock	0
			Other positions	Approx. 5

SEL698Y

Refer to wiring diagram in EL-353.



OK or NG

OK ► Back door key cylinder switch is OK.

NG ► GO TO 2.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

2	CHECK BACK DOOR KEY CYLINDER SWITCH																									
1. Disconnect back door key cylinder switch connector. 2. Check continuity between back door key cylinder switch terminals.																										
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="margin-left: 20px;"> <table border="1" data-bbox="738 304 1442 546"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="4">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between lock (Back door) and unlock (glass hatch)</td> <td></td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-right: 50px;">SEL345X</p> <p style="text-align: center;">OK or NG</p>			Key position	Terminals				1	2	3	4	Between neutral and lock (Back door)	○			○	Between neutral and unlock (Back door)		○		○	Between lock (Back door) and unlock (glass hatch)			○	○
Key position	Terminals																									
	1	2	3	4																						
Between neutral and lock (Back door)	○			○																						
Between neutral and unlock (Back door)		○		○																						
Between lock (Back door) and unlock (glass hatch)			○	○																						
OK	▶	Check the following. <ul style="list-style-type: none"> ● Back door key cylinder switch ground circuit ● Harness for open or short between smart entrance control unit and back door key cylinder switch 																								
NG	▶	Replace back door key cylinder switch.																								

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH CHECK

=NAEL0406S08

1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

LOCK SW DR/AS ON

When lock/unlock switch is turned to UNLOCK:

UNLK SW DR/AS ON


SEL341W

Without CONSULT-II


1. Remove key from ignition key cylinder.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



Smart entrance control unit connector



Refer to wiring diagram in EL-352.



Voltage:

12V → 9V (10 sec.) measurement by analog circuit tester.

SEL699YA

OK or NG

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

VEHICLE SECURITY HORN ALARM CHECK

=NAEL0406S09

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

1 CHECK VEHICLE SECURITY HORN


- With CONSULT-II**
- Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.
 - Select "HORN" and touch "ON".



Vehicle security horn alarm should operate.

SEL041Y

- Without CONSULT-II**
- Disconnect smart entrance control unit harness connector.
 - Apply ground to smart entrance control unit harness connector M122 terminal 42 (LG/B).



Vehicle security horn alarm should operate.

SEL043YC

Refer to wiring diagram in EL-353.

OK or NG

OK	▶	Horn alarm is OK.
NG	▶	GO TO 2.

2 CHECK HORN RELAY


Check horn relay.


OK or NG

OK	▶	GO TO 3.
NG	▶	Replace horn relay.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

3		CHECK POWER SUPPLY FOR HORN RELAY
<ol style="list-style-type: none"> 1. Disconnect horn relay connector. 2. Check voltage between horn relay harness connector E118 terminal 1 (G/B) and ground. 		
<div style="display: flex; align-items: center; justify-content: space-between;"> <div style="text-align: center;">  <p>Horn relay connector</p> </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> </div>		
SEL326XB		
OK or NG		
OK	▶	GO TO 4.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse (No. 52, located in the fuse and fusible link box) ● Harness for open or short between horn relay and fuse

4		CHECK HORN RELAY CIRCUIT
<ol style="list-style-type: none"> 1. Disconnect horn relay connector. 2. Check voltage between horn relay harness connector E118 terminals 3 (G/B) and 5 (R). 3. Check voltage between horn relay harness connector E118 terminals 6 (LG) and 7 (G). 		
<div style="display: flex; align-items: center; justify-content: space-between;"> <div style="text-align: center;">  <p>Horn relay connector</p> </div> <div style="text-align: center;"> <p>Battery voltage should exist.</p> </div> </div>		
SEL327XB		
OK or NG		
OK	▶	Check harness for open or short between horn relay and smart entrance control unit.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between horn relay and fuse ● 7.5A fuse (No. 52, located in the fuse and fusible link box) ● 10A fuse (No. 54, located in the fuse and fusible link box)

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


VEHICLE SECURITY HEADLAMP ALARM CHECK

=NAEL0406S10

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1 CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION


- With CONSULT-II**
1. Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.
 2. Select "HEADLAMP" and touch "ON".



Vehicle security headlamp alarm should operate.

SEL042Y

- Without CONSULT-II**
1. Disconnect smart entrance control unit connector.
 2. Apply ground to smart entrance control unit harness connector M121, M123 terminals 21 (PU/R) and 59 (PU/W).



Vehicle security headlamp alarm should operate.

SEL198Y

Refer to wiring diagram in EL-354.

OK or NG

OK	▶	Headlamp is OK.
NG	▶	GO TO 2.

2 CHECK HEADLAMP OPERATION

Does headlamp come on when turning lighting switch "ON"?

Yes	▶	Check harness for open or short between headlamp relay and smart entrance control unit.
No	▶	Check headlamp system. Refer to "HEADLAMP".

SMART ENTRANCE CONTROL UNIT

Description

Description

NAEL0407

NAEL0407S01

OUTLINE

The smart entrance control unit totally controls the following body electrical system operations.

- Headlamp auto light control system
- Warning chime
- Rear defogger and door mirror defogger timer
- Power door lock
- Remote keyless entry system
- Vehicle security system
- Interior lamp

In addition, the following timer operations are controlled by the smart entrance control unit.

- Battery saver control
- Retained power control

BATTERY SAVER CONTROL

NAEL0407S02

Headlamps/Parking Lamps/License Lamps/Tail Lamps/Fog Lamps/Illumination Lamps

NAEL0407S0201

While the headlamps (including parking, license, tail, fog and illumination lamps) are turned ON by "1ST" or "2ND" of lighting switch, the exterior lamp battery saver control is activated when the ignition switch signal changes from ON (or ACC) to OFF, and either one of LH or RH front door switch ON signal is received. The headlamps (including parking, license, tail, fog and illumination lamps) are turned off after 5 minutes.

While the headlamps are turned ON by "AUTO" operation, the exterior lamp battery saver control is activated when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch ON signal is input.

The smart entrance control unit controls timer activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.

The "45" second timer's duration can be changed with the function setting mode of CONSULT-II.

Interior Lamp/Luggage Room Lamp/Spot Lamp/Vanity Mirror Illumination

NAEL0407S0202

The lamps turn off automatically when the interior lamp, spot lamp or/and vanity mirror illumination are illuminated with the ignition key in the OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in the ON position for more than 30 minutes.

After lamps are turned off by the battery saver system, the lamps illuminate again when:

- Door is locked or unlocked with keyfob or door lock/unlock switch or door key cylinder.
- Ignition switch ON.
- Door is opened or closed,
- Key is inserted or removed into ignition key cylinder.

Rear Window Defogger/Door Mirror Defogger

NAEL0407S0203

Rear window defogger and door mirror defogger are turned off in approximately 15 minutes after the rear window defogger switch is turned on.

RETAINED POWER CONTROL

NAEL0407S03

When the ignition switch is turned to OFF (or ACC) position from ON or START position, the following systems can be operated for 45 seconds by the RAP signal from the smart entrance control unit terminal 46.

- Electric sunroof
- Power window

The retained power operation is canceled when the driver or passenger side door is opened.

SMART ENTRANCE CONTROL UNIT

Description (Cont'd)

INPUT/OUTPUT

NAEL0407S04

System	Input	Output
Power door lock	Door lock and unlock switch LH and RH Key switch (Insert) Door switches Door key cylinder switches	Door lock actuator
Remote keyless entry	Key switch (Insert) Ignition switch (ACC) Door switches Keyfob signal Door lock/unlock switch LH	Horn relay Headlamp relay (LH and RH) Hazard warning lamp Interior lamp Power window main switch Door lock actuator Opener actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch (driver's seat) Front door switch LH	Warning chime (located in smart entrance control unit)
Rear window defogger and door mirror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Vehicle security	Ignition switch (ACC, ON) Door switches Hood switch Back door switch Glass hatch switch Door lock/unlock switches Door key cylinder switches (lock/unlock)	Horn relay Headlamp relay Security indicator
Interior lamp	Door switches Keyfob signal (lock/unlock) Door lock/unlock switches (lock/unlock) Door key cylinder switch (lock/unlock) Ignition switch (ON) Key switch (Insert)	Interior lamp Step lamp Door indicator
Battery saver control for headlamps/parking lamps/licence lamps/tail lamps/fog lamps/illumination lamps	Ignition switch (ON) Lighting switches	Headlamps Parking lamps Licence lamps Tail lamps Fog lamps Illumination lamps
Battery saver control for interior lamp/spot lamp/vanity mirror illumination	Ignition switch (ON) Front door switches Lamp switches	Interior lamp Step lamp Spot lamp Vanity mirror illumination
Battery saver control for rear window defogger and door mirror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Retained power control for electric sunroof	Ignition switch (ON) Front door switches	Sunroof motor
Retained power control for power window	Ignition switch (ON) Front door switches	Power window relay
Headlamp auto light control	Auto light sensor Lighting switches	Headlamp relay Tail lamp relay

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SMART ENTRANCE CONTROL UNIT

CONSULT-II

CONSULT-II DIAGNOSTIC ITEMS APPLICATION

NAEL0408

NAEL0408S01

Item (CONSULT-II screen terms)	Diagnosed system	DATA MONITOR	ACTIVE TEST	WORK SUPPORT
DOOR LOCK	Power door lock	X	X	X
REAR DEFOGGER	Rear window defogger	X	X	
KEY WARN ALM	Warning chime	X	X	
LIGHT WARN ALM	Warning chime	X	X	
SEAT BELT ALM	Warning chime	X	X	
INT LAMP	Interior lamps	X	X	X
BATTERY SAVER	Battery saver control for interior lamp	X	X	X
THEFT WAR ALM	Vehicle security system	X	X	X
RETAINED PWR	Retained power control	X	X	X
MULTI REMOTE ENT	Remote keyless entry system	X	X	X
HEAD LAMP	Headlamp	X	X	X


X: Applicable

For diagnostic item in each control system, refer to the relevant pages for each system.

DIAGNOSTIC ITEM DESCRIPTION

NAEL0408S02


MODE	Description
DATA MONITOR	Input/output data in the smart entrance control unit can be read.
ACTIVE TEST	Diagnostic Test Mode in which CONSULT-II drives some systems apart from the smart entrance control unit.
WORK SUPPORT for DOOR LOCK	<ul style="list-style-type: none"> ● Select unlock mode ON-OFF setting can be changed. ● Key reminder door mode ON-OFF setting can be changed.
WORK SUPPORT for INT LAMP	Interior lamp timer mode ON-OFF setting can be changed.
WORK SUPPORT for BATTERY SAVER	Interior lamp battery saver period can be changed.
WORK SUPPORT for THEFT WAR ALM	<ul style="list-style-type: none"> ● The recorded trigger signal when vehicle security system was activated can be checked. ● Security alarm ON-OFF setting can be changed.
WORK SUPPORT for RETAINED PWR SET	RAP signal's power supply period can be changed.
WORK SUPPORT for MULTI REMOTE ENT	<ul style="list-style-type: none"> ● ID code of keyfob can be registered and erased. ● Keyless answer back mode can be changed. ● Pressing time of panic alarm, trunk lid opener and door unlock (for power window down operation) buttons on keyfob can be changed. ● Auto lock operation starting time can be changed.
WORK SUPPORT for HEADLAMP	<ul style="list-style-type: none"> ● Auto light sensitivity can be changed. ● Exterior lamp battery saver control ON-OFF setting can be changed. ● Auto light delay off time can be changed.




CONSULT-II INSPECTION PROCEDURE

NAEL0408S03


1. Turn the ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "SMART ENTRANCE".
If "SMART ENTRANCE" is not indicated, go to GI-42, "CONSULT-II Data Link Connector (DLC) Circuit".



6. Perform each diagnostic item according to "DIAGNOSTIC ITEMS APPLICATION". Refer to EL-378.


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SMART ENTRANCE CONTROL UNIT

Schematic

NAEL0409

Schematic




MEL957R

SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

Smart Entrance Control Unit Inspection Table

NAEL0410

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)	
1	G/OR	Driver door switch	OFF (Closed) → ON (Open)		12V → 0V	
2	Y	Passenger door switch	OFF (Closed) → ON (Open)		5V → 0V	
3	R/L	Rear door switch	OFF (Closed) → ON (Open)		5V → 0V	
6	Y/B	Hood switch	ON (Open) → OFF (Closed)		0V → 12V	
7	W/G	Auto light sensor (Signal)	Ignition switch ON position	Light is applied to auto light sensor.	1 to 5V	
				Light is not applied to auto light sensor.	Less than 1V	
8	L/R	Auto light sensor (GND)	Ignition switch ON position		0V	
9	GY	Auto light sensor (Power)	Ignition switch (OFF → ON)		0V → 5V	
10	LG	Back door key cylinder unlock switch	OFF (Neutral) → ON (Unlocked)		5V → 0V	
11	Y	Back door key cylinder lock switch	OFF (Neutral) → ON (Locked)		5V → 0V	
12	W/PU	Back door key cylinder switch	OFF (Neutral) → ON (Unlock)		5V → 0V	
13	L/W	Glass hatch switch	ON (Open) → OFF (Closed)		5V → 0V	
14	OR	Rear window defogger switch	OFF → ON (Only when pushed)		5V → 0V	
19	R/G	Tail lamp relay (Output)	Ignition switch (with lighting switch 1ST or 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position		0V
				Headlamps illuminate by auto light control. (Operate → Not operate)		Less than 1V → 12V
20	G	Tail lamp switch	Light switch (OFF or AUTO → 1ST or 2ND position)		12V → 0V	
21	PU/R	Headlamp LH relay	Ignition switch (with lighting switch 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position		0V
				Headlamps illuminate by auto light control. (Operate → Not operate)		Less than 1V → 12V

SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table (Cont'd)

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)
22	SB	Headlamp switch	Lighting switch	Except PASS or 2ND position	12V
				PASS or 2ND position	0V
			Headlamps illuminate by auto light control. (Operate → Not operate)	10V → 12V	
23	L/Y	Headlamp switch	Ignition switch "ON" position	Lighting switch (Except AUTO → AUTO position)	12V → 0V
25	W/R	Ignition key switch (Insert)	Key inserted → Key removed from IGN key cylinder		12V → 0V
26	G/W	Ignition switch (ACC)	"ACC" position		Battery voltage
27	W/B	Ignition switch (ON)	Ignition key is in "ON" position		Battery voltage
28	B/Y	Seat belt buckle switch	Unfastened → Fastened (Ignition key is in "ON" position)		0V → 12V
31	R/B	Interior lamp	When doors are locked using keyfob (Lamp switch in "DOOR" position)		0V → 12V
33	BR	Communication interface	Door lock and unlock switches (Neutral → Lock/unlock)		Refer to EL-384.
			Front door key cylinder switch LH (Neutral → Lock/unlock)		
37	G/B	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)		12V → 0V
38	BR/Y	Security indicator	Goes off → Illuminates		12V → 0V
42	LG/B	Horn relay	When panic alarm is operated using keyfob (ON → OFF)		12V → 0V
43	B	Ground	Ignition switch ON position		0V
46	R/Y	Power window relay	Retained power operation is operated (ON → OFF)		12V → 0V
47	GY/L	LH turn signal lamp	When door lock or unlock is operated using keyfob (ON → OFF)		12V → 0V
48	GY/R	RH turn signal lamp	When door lock or unlock is operated using keyfob (ON → OFF)		12V → 0V
49	G/R	Power source (Fuse)	—		Battery voltage
50	R/W	Battery saver (Interior lamp)	Battery saver operates → Does not operate (ON → OFF)		12V → 0V
51	W/R	Power source (PTC)	—		Battery voltage
54	L	Door lock actuators	Door lock & unlock switch (Free → Lock)		0V → 12V
55	W/PU	Driver door lock actuator	Door lock & unlock switch (Free → Unlock)		0V → 12V
56	Y/B	Passenger, rear and back doors lock actuator	Door lock & unlock switch (Free → Unlock)		0V → 12V

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table (Cont'd)

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)
57	R	Tail lamp relay	Ignition switch (with lighting switch 1ST or 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position 12V
					Within 5 minutes after ignition switch is turned to OFF position 0V
				ON or START position	0V
			Headlamps illuminate by auto light control. (Operate → Not operate)		
58	G/W	Tail lamp switch	Lighting switch OFF or AUTO → 1ST or 2ND		12V → 0V
59	PU/W	Headlamp RH relay	Ignition switch (with lighting switch OFF or 1ST)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position 12V
					Within 5 minutes after ignition switch is turned to OFF position 0V
				ON or START position	0V
			Headlamps illuminate by auto light control. (Operate → Not operate)		
60	L	Headlamp switch	Lighting switch	Except PASS or 2ND position	12V
				PASS or 2ND position	0V
			Headlamps illuminate by auto light control. (Operate → Not operate)		
64	B	Ground	Ignition switch ON position		0V



COMMUNICATION INTERFACE SIGNAL

NAEL0410S02

Voltage:

12 V → 9V (10 sec.) measurement by analog circuit tester.



HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram — TRNSCV —

Wiring Diagram — TRNSCV —

NAEL0411

EL-TRNSCV-01



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MEL040Q

HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses


Trouble Diagnoses DIAGNOSTIC PROCEDURE

NAEL0412


NAEL0412S01

SYMPTOM: Homelink universal transceiver does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is malfunctioning. Condition is not vehicle related.


1	PRELIMINARY CHECK	
<p>1. Turn ignition switch "OFF". 2. Does red light (LED) of homelink universal transceiver illuminate when any button is pressed?</p>		
		
SEL442UA		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK HOMELINK UNIVERSAL TRANSCEIVER FUNCTION	
<p>Check homelink universal transceiver with Tool. For details, refer to Technical Service Bulletin.</p>		
OK or NG		
OK	▶	Receiver or hand-held transmitter is malfunctioning. Condition is not vehicle related.
NG	▶	Replace homelink universal transceiver with sun visor assembly.


3	CHECK POWER SUPPLY	
<p>1. Disconnect homelink universal transceiver connector. 2. Turn ignition switch "OFF". 3. Check voltage between homelink universal transceiver harness connector R5 terminal 1 (R/G) and ground.</p>		
		
Battery voltage should exist.		
SEL358X		
OK or NG		
OK	▶	GO TO 4.
NG	▶	GO TO 5.

HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses (Cont'd)

4	CHECK GROUND CIRCUIT	
<p>Check continuity between homelink universal transceiver harness connector R5 terminal 2 (B) and ground.</p>		
		
Continuity should exist.		
SEL359X		
OK or NG		
OK	▶	Replace homelink universal transceiver with sun visor assembly.
NG	▶	Repair harness.

GI
MA
EM
LC
EC
FE
CL

5	CHECK MAIN POWER SUPPLY FOR SMART ENTRANCE CONTROL UNIT	
<p>1. Disconnect smart entrance control unit. 2. Check voltage between smart entrance control unit harness connector M123 terminal 49 (G/R) and ground.</p>		
		
Battery voltage should exist.		
SEL284Y		
OK or NG		
OK	▶	GO TO 6.
NG	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse No. 24, located in fuse block (J/B)

MT
AT
TF
PD
AX
SU
BR


ST
RS
BT
HA
SC

EL

IDX

HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses (Cont'd)


6	CHECK GROUND CIRCUIT FOR SMART ENTRANCE CONTROL UNIT
<p data-bbox="154 199 1429 252">Check continuity between smart entrance control unit harness connector M122 terminal 43 (B) or M123 terminal 64 (B) and ground.</p> <div data-bbox="224 283 1266 567"><p data-bbox="341 283 568 325">Smart entrance control unit connector</p><p data-bbox="974 409 1266 451">Continuity should exist.</p></div> <p data-bbox="747 619 876 651" style="text-align: center;">OK or NG</p> <p data-bbox="1380 577 1477 609" style="text-align: right;">SEL285Y</p>	
OK	▶ Power supply and ground circuits are OK.
NG	▶ Check ground harness.

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0413



NOTE:

If customer reports a “No Start” condition, request ALL KEYS to be brought to the Dealer in case of an NVIS (NATS) malfunction.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

System Description

System Description

=NAEL0414

NATS (Nissan Anti-Theft System) has the following immobilizer functions:


- Since only NVIS (NATS) ignition keys, whose ID nos. have been registered into the ECM and IMMU of NVIS (NATS), allow the engine to run, operation of a stolen vehicle without an NVIS (NATS) registered key is prevented by NVIS (NATS).
That is to say, NVIS (NATS) will immobilise the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs (except for card plate key) have been NVIS (NATS) registered.
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, NVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the “ON” position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. When NVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically NVIS (NATS) registered. Then, if necessary, additional registration of other NVIS (NATS) ignition key IDs can be carried out.
Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.
- **When servicing a malfunction of the NVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another NVIS (NATS) ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

System Composition

NAEL0415

The immobiliser function of the NVIS (NATS) consists of the following:

- NVIS (NATS) ignition key
- NVIS (NATS) immobilizer control unit (IMMU) located in the ignition key cylinder
- Engine control module (ECM)
- Security indicator




NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Wiring Diagram — NATS —

Wiring Diagram — NATS —



NAEL0416

EL-NATS-01




Refer to EL-POWER.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




REFER TO THE FOLLOWING.
 (E1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M10), (E3) -FUSE BLOCK-JUNCTION BOX (J/B)



NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

CONSULT-II



CONSULT-II


CONSULT-II INSPECTION PROCEDURE

NAEL0417
NAEL0417S01


1. Turn ignition switch OFF.
2. Insert NVIS (NATS) program card into CONSULT-II.

Program card NATS (AEN02B)

3. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector.
4. Turn ignition switch ON.
5. Touch "START".




6. Select "NATS V.5.0".



7. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual, IVIS/NVIS.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

NAEL0417S02

CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following three components, C/U initialization and re-registration of all NVIS (NATS) ignition keys are necessary. [NVIS (NATS) ignition key/IMMU/ECM]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart EL-393.

NOTE:

- When any initialization is performed, all ID previously registered will be erased and all NVIS (NATS) ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show “DIFFERENCE OF KEY” or “LOCK MODE” as a self-diagnostic result on the CONSULT-II screen.
- In rare case, “CHAIN OF ECM-IMMU” might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.

HOW TO READ SELF-DIAGNOSTIC RESULTS

NAEL0417S03

Result display screen (When no malfunction is detected)

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
PRINT	

Result display screen (When malfunction is detected)

SELF DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU	0
DIFFERENCE OF KEY	1
Scroll down	
ERASE	PRINT

Detected items →

If “Scroll Down” is indicated, there are four or more malfunctions.

When touched, the results stored in the engine control module (ECM) are erased.

← Time data

This indicates how many times the vehicle was driven after the last detection of a malfunction. If the malfunction is detected currently, the time data will be “0”.

← When touched, the results are printed out.

SEL364X

NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART

NAEL0417S04

Detected items (NATS program card screen terms)	P No. Code (Self-diagnostic result of “ENGINE”)	Malfunction is detected when	Reference page
ECM INT CIRC-IMMU	NATS MAL-FUNCTION P1613	The malfunction of ECM internal circuit of IMMU communication line is detected.	EL-397
CHAIN OF ECM-IMMU	NATS MAL-FUNCTION P1612	Communication impossible between ECM and IMMU (In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.)	EL-398
DIFFERENCE OF KEY	NATS MAL-FUNCTION P1615	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-402
CHAIN OF IMMU-KEY	NATS MAL-FUNCTION P1614	IMMU cannot receive the key ID signal.	EL-403
ID DISCORD, IMM-ECM	NATS MAL-FUNCTION P1611	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-404

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

CONSULT-II (Cont'd)


Detected items (NATS program card screen terms)	P No. Code (Self-diagnostic result of "ENGINE")	Malfunction is detected when	Reference page
LOCK MODE	NATS MALFUNCTION P1610	When the starting operation is carried out five or more times consecutively under the following conditions, NVIS (NATS) will shift the mode to one which prevents the engine from being started. <ul style="list-style-type: none">● Unregistered ignition key is used.● IMMU or ECM's malfunctioning.	EL-407
DON'T ERASE BEFORE CHECKING ENG DIAG	—	All engine trouble codes except NVIS (NATS) trouble code has been detected in ECM.	EL-395

Trouble Diagnoses WORK FLOW

NAEL0418

NAEL0418S01

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



SEL004XA

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

NAEL0418S02

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine cannot be started. 	ECM INT CIRC-IMMU	PROCEDURE 1 (EL-397)	ECM	B
	CHAIN OF ECM-IMMU	PROCEDURE 2 (EL-398)	In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			ECM	B
			IMMU	A
	DIFFERENCE OF KEY	PROCEDURE 3 (EL-402)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 4 (EL-403)	Malfunction of key ID chip	E
			IMMU	A
	ID DISCORD, IMM-ECM	PROCEDURE 5 (EL-404)	System initialization has not yet been completed.	F
ECM			F	
LOCK MODE	PROCEDURE 7 (EL-407)	LOCK MODE	D	
<ul style="list-style-type: none"> ● MIL staying ON ● Security indicator lighting up* 	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-395)	Engine trouble data and NVIS (NATS) trouble data have been detected in ECM	—

*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

NAEL0418S03

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)
Security ind. does not light up.	PROCEDURE 6 (EL-405)	Security ind.
		Open circuit between Fuse and IMMU
		Continuation of initialization mode
		IMMU

DIAGNOSTIC SYSTEM DIAGRAM

NAEL0418S04



SEL761Y

SELF DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL365X

DIAGNOSTIC PROCEDURE 1

NAEL0418S05

Self-diagnostic results:
“ECM INT CIRC-IMMU” displayed on CONSULT-II screen

1. Confirm SELF-DIAGNOSTIC RESULTS “ECM INT CIRC-IMMU” displayed on CONSULT-II screen. Ref. part No. B.
2. Replace ECM.
3. Perform initialization with CONSULT-II.
 For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

=NAEL0418S06

Self-diagnostic results:

“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
<p>Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF ECM-IMMU” displayed on CONSULT-II screen.</p> <p>NOTE: In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.</p>												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>CHAIN OF ECM-IMMU</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF ECM-IMMU	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF ECM-IMMU	0											
SEL366X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	CHECK POWER SUPPLY CIRCUIT FOR IMMU	
<p>1. Disconnect IMMU connector.</p> <p>2. Check voltage between IMMU harness connector terminal 8 and ground with CONSULT-II or tester.</p>		
		
Battery voltage should exist.		
SEL302WD		
OK or NG		
OK	▶	GO TO 3.
NG	▶	<p>Check the following</p> <ul style="list-style-type: none"> ● 7.5A fuse (No. 62, located in the fuse and fusible link box) ● Harness for open or short between fuse and IMMU connector <p>Ref. Part No. C1</p>

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


3	CHECK IGN SW. ON SIGNAL		GI
<ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Check voltage between IMMU harness connector terminal 7 and ground with CONSULT-II or tester. 		MA	
<p style="text-align: center;">Battery voltage should exist.</p>		EM	
OK or NG		LC	
		EC	
		FE	
		CL	
OK	▶	GO TO 4.	MT
NG	▶	Check the following <ul style="list-style-type: none"> • 10A fuse [No. 16, located in the fuse block (J/B)] • Harness for open or short between fuse and IMMU connector Ref. part No. C2	AT


4	CHECK GROUND CIRCUIT FOR IMMU		TF
<ol style="list-style-type: none"> 1. Turn ignition OFF. 2. Check harness continuity between IMMU harness connector E113 terminal 4 (B) and ECM harness connector F203 terminal 67 (B/P). 		PD	
<p style="text-align: center;">Continuity should exist.</p>		AX	
OK or NG		SU	
		BR	
		ST	
OK	▶	GO TO 5.	RS
NG	▶	Repair harness. Ref. part No. C3	BT

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

5	CHECK COMMUNICATION LINE OPEN CIRCUIT	
<p>1. Disconnect ECM connector. 2. Check harness continuity between ECM harness connector terminal 88 and IMMU harness connector terminal 1.</p>		
		
Continuity should exist.		
SEL740Y		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair harness or connector. Ref. part No. C4

6	CHECK COMMUNICATION LINE BATTERY SHORT CIRCUIT	
<p>1. Turn ignition ON. 2. Check voltage between ECM harness connector terminal 88 or IMMU harness connector terminal 1 and ground.</p>		
		
Voltage: 0V		
SEL741Y		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Communication line is short-circuited with battery voltage line or ignition switch ON line. Repair harness or connectors. Ref. part No. C4

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

7	CHECK COMMUNICATION LINE GROUND SHORT CIRCUIT	
<p>1. Turn ignition switch OFF. 2. Check continuity between ECM harness connector terminal 88 or IMMU harness connector terminal 1 and ground.</p>		
SEL742Y		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Communication line is short-circuited with ground line. Repair harness or connectors. Ref. part No. C4

8	SIGNAL FROM ECM TO IMMU CHECK	
<p>1. Check the signal between ECM harness connector F203 terminal 88 (G) and ground with CONSULT-II or oscilloscope when ignition switch is turned "ON". 2. Make sure signals which are shown in the figure below can be detected during 750 msec. just after ignition switch is turned "ON".</p>		
SEL730W		
OK or NG		
OK	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
NG	▶	ECM is malfunctioning. Replace ECM. Ref. part No. B Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

=NAEL0418S07

Self-diagnostic results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS “DIFFERENCE OF KEY” displayed on CONSULT-II screen.												
<table border="1"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>DIFFERENCE OF KEY</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	DIFFERENCE OF KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
DIFFERENCE OF KEY	0											
SEL367X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	PERFORM INITIALIZATION WITH CONSULT-II				
Perform initialization with CONSULT-II. Re-register all NVIS (NATS) ignition key IDs. For initialization and registration of NVIS (NATS) ignition key IDs, refer to “CONSULT-II operation manual NVIS/NVIS”.					
<table border="1"> <thead> <tr> <th>IMMU INITIALIZATION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">INITIALIZATION FAIL</td> </tr> <tr> <td>THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </tbody> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
NOTE:					
If the initialization is not completed or fails, CONSULT-II shows above message on the screen.					
Can the system be initialized and can the engine be started with re-registered NVIS (NATS) ignition key?					
Yes	▶	Ignition key ID was unregistered. Ref. part No. D			
No	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.			

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

=NAEL0418S08

Self-diagnostic results:
"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen.												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>CHAIN OF IMMU-KEY</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF IMMU-KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF IMMU-KEY	0											
SEL368X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	CHECK NVIS (NATS) IGNITION KEY ID CHIP	
Start engine with another registered NVIS (NATS) ignition key.		
Does the engine start?		
Yes	▶	Ignition key ID chip is malfunctioning. Replace the ignition key. Ref. part No. E Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
No	▶	GO TO 3.

3	CHECK IMMU INSTALLATION	
Check IMMU installation. Refer to "How to Replace IMMU" in EL-408.		
OK or NG		
OK	▶	IMMU is malfunctioning. Replace IMMU. Ref. part No. A Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
NG	▶	Reinstall IMMU correctly.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

=NAEL0418S09

Self-diagnostic results:

“ID DISCORD, IMM-ECM” displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS “ID DISCORD, IMM-ECM” displayed on CONSULT-II screen.												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>ID DISCORD, IMM-ECM</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	ID DISCORD, IMM-ECM	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
ID DISCORD, IMM-ECM	0											
SEL369X												
<p>NOTE: “ID DISCORD IMM-ECM”: Registered ID of IMMU is in discord with that of ECM.</p>												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	PERFORM INITIALIZATION WITH CONSULT-II				
Perform initialization with CONSULT-II. Re-register all NVIS (NATS) ignition key IDs. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.					
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>IMMU INITIALIZATION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 10px;">INITIALIZATION FAIL</td> </tr> <tr> <td style="text-align: center; padding: 5px;">THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </tbody> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
<p>NOTE: If the initialization is not completed or fails, CONSULT-II shows above message on the screen.</p>					
Can the system be initialized?					
Yes	▶	Start engine. (END) (System initialization had not been completed. Ref. part No. F)			
No	▶	ECM is malfunctioning. Replace ECM. Ref. part No. F Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.			

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 6

“SECURITY INDICATOR LAMP DOES NOT LIGHT UP”

=NAEL0418S10

1	CHECK FUSE	
Check 10A fuse [No. 12, located in the fuse block (J/B)].		
Is 10A fuse OK?		
Yes	▶	GO TO 2.
No	▶	Replace fuse.

2	CHECK SECURITY INDICATOR LAMP	
<ol style="list-style-type: none"> 1. Install 10A fuse. 2. Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II Operation Manual IVIS/NVIS”. 3. Turn ignition switch OFF. 4. Start engine and turn ignition switch OFF. 5. Check the security indicator lamp lighting. <p>Security indicator lamp should be blinking.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 3.

3	CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT	
<ol style="list-style-type: none"> 1. Disconnect security indicator lamp connector. 2. Check voltage between security indicator lamp harness connector terminal 1 and ground. 		
		
SEL370XA		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Check harness for open or short between fuse and security indicator lamp.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

4		CHECK SECURITY INDICATOR LAMP
<ol style="list-style-type: none"> 1. Disconnect security indicator lamp connector. 2. Apply 12V direct current to security indicator lamp harness connector M20 terminals 1 and 2. 		
SEL696Y		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Replace security indicator lamp.

5		CHECK IMMU FUNCTION
<ol style="list-style-type: none"> 1. Connect IMMU connector. 2. Disconnect security indicator lamp connector. 3. Check continuity between IMMU harness connector terminal 5 and ground. 		
SEL300WC		
OK or NG		
OK	▶	Check harness for open or short between security indicator lamp and IMMU.
NG	▶	IMMU is malfunctioning. Replace IMMU. Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

=NAEL0418S11

Self-diagnostic results:
"LOCK MODE" displayed on CONSULT-II screen

1	CONFIRM SELF-DIAGNOSTIC RESULTS											
Confirm SELF-DIAGNOSTIC RESULTS "LOCK MODE" is displayed on CONSULT-II screen.												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">LOCK MODE</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	LOCK MODE	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
LOCK MODE	0											
SEL371X												
Is CONSULT-II screen displayed as above?												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

2	ESCAPE FROM LOCK MODE	
<ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds. 3. Return the key to OFF position. 4. Repeat steps 2 and 3 twice (total of three cycles). 5. Start the engine. 		
Does engine start?		
Yes	▶	System is OK. (Now system is escaped from "LOCK MODE".)
No	▶	GO TO 3.


3	CHECK IMMU ILLUSTRATION	
Check IMMU installation. Refer to "How to Replace IMMU" in EL-408.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Reinstall IMMU correctly.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

4	PERFORM INITIALIZATION WITH CONSULT-II				
<p>Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".</p>					
<table border="1" style="margin: auto;"> <tr> <td style="text-align: center;">IMMU INITIALIZATION</td> </tr> <tr> <td style="text-align: center;">INITIALIZATION FAIL</td> </tr> <tr> <td style="text-align: center;">THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
<p>NOTE: If the initialization is not completed or fails, CONSULT-II shows the above message on the screen.</p>					
Can the system be initialized?					
Yes	▶	System is OK.			
No	▶	GO TO DIAGNOSTIC PROCEDURE 4 to check "CHAIN OF IMMU-KEY", refer to EL-403.			



How to Replace NVIS (NATS) IMMU

NAEL0419

NOTE:

- If NVIS (NATS) IMMU is not installed correctly, NVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE".

System Description

NAEL0462

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

NAEL0463

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Wide/Wagon						
Engine	VQ35DE						
Transmission	A/T						M/T
Brake control	VDC			ABS			
Axle	4WD (All-mode)	4WD (Part time)	2WD	4WD (All-mode)	4WD (Part time)	2WD	4WD (Part time)
CAN system type	1	2		3			4
CAN system trouble diagnosis	EL-414	EL-438		EL-460			EL-473

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


CAN COMMUNICATION

CAN Communication Unit (Cont'd)

TYPE 1 System Diagram

=NAEL0463S01

NAEL0463S0101



SEL683Y

Input/Output Signal Chart

NAEL0463S0102

T: Transmit R: Receive

Signals	ECM	TCM	Transfer control unit	Steering angle sensor	ABS actuator and electric unit (control unit)	Combination meter
Engine speed signal	T		R		R	R
Accelerator pedal position signal	T		R		R	
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
VDC operation signal			R		T	
TCS operation signal			R		T	
ABS operation signal			R		T	
Output shaft revolution signal	R	T	R			
During shifting signal		T	R		R	
Steering wheel angle sensor signal				T	R	
Wheel speed sensor signal			R		T	
Stop lamp switch signal		R				T
Malfunction indicator lamp signal	T					R
Engine coolant temperature signal	T					R
Vehicle speed signal					T	R
	R					T
Neutral range switch signal		R				T
Parking range switch signal		R				T
Overdrive control switch signal		R				T
A/C compressor feedback signal	T					R
Fuel level sensor signal	R					T
A/T position indicator signal		T				R
O/D OFF indicator signal		T				R


CAN COMMUNICATION

CAN Communication Unit (Cont'd)

TYPE 2 System Diagram

=NAEL0463S02

NAEL0463S0201



SEL682Y

Input/Output Signal Chart

NAEL0463S0202

T: Transmit R: Receive

Signals	ECM	TCM	Steering angle sensor	ABS actuator and electric unit (control unit)	Combination meter
Engine speed signal	T			R	R
Accelerator pedal position signal	T			R	
Closed throttle position signal	T	R			
Wide open throttle position signal	T	R			
Steering wheel angle sensor signal			T	R	
Malfunction indicator lamp signal	T				R
Engine coolant temperature signal	T				R
Vehicle speed signal				T	R
	R				T
Stop lamp switch signal		R			T
Neutral range switch signal		R			T
Parking range switch signal		R			T
Overdrive control switch signal		R			T
A/C compressor feedback signal	T				R
Fuel level sensor signal	R				T
A/T position indicator signal		T			R
O/D OFF indicator signal		T			R

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN COMMUNICATION

CAN Communication Unit (Cont'd)

TYPE 3 System Diagram

=NAEL0463S03

NAEL0463S0301



SEL684Y

Input/Output Signal Chart

NAEL0463S0302

T: Transmit R: Receive

Signals	ECM	TCM	Combination meter
Engine speed signal	T		R
Closed throttle position signal	T	R	
Wide open throttle position signal	T	R	
Stop lamp switch signal		R	T
Neutral range switch signal		R	T
Parking range switch signal		R	T
Overdrive control switch signal		R	T
Malfunction indicator lamp signal	T		R
Engine coolant temperature signal	T		R
Vehicle speed signal	R		T
A/C compressor feedback signal	T		R
Fuel level sensor signal	R		T
A/T position indicator signal		T	R
O/D OFF indicator signal		T	R


CAN COMMUNICATION

CAN Communication Unit (Cont'd)

TYPE 4 System Diagram

=NAEL0463S04

NAEL0463S0401



SEL681Y

Input/Output Signal Chart

NAEL0463S0402

T: Transmit R: Receive

Signals	ECM	Combination meter
Engine speed signal	T	R
Malfunction indicator lamp signal	T	R
Engine coolant temperature signal	T	R
Vehicle speed signal	R	T
A/C compressor feedback signal	T	R
Fuel level sensor signal	R	T

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

CAN SYSTEM (TYPE 1)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0464



System Description

NAEL0465

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN SYSTEM (TYPE 1)






Wiring Diagram — CAN —

Wiring Diagram — CAN —

NAEL0466

EL-CAN-01

— — — — — : DATA LINE



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



MEL578Q

CAN SYSTEM (TYPE 1)

Wiring Diagram — CAN — (Cont'd)

EL-CAN-02

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL579Q

Trouble Diagnoses

NAEL0467

NAEL0467S01

WORK FLOW

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ALL MODE AWD/4WD" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]	0
F.F.DATA	
ERASE	PRINT
MODE	BACK
LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ALL MODE AWD/4WD" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

➔

CAN DIAG SUPPORT MNTR	
ENGINE	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	OK
IPDM E/R	OK
AWD/4WD/e4WD	UNKWN
PRINT	Scroll Down
MODE	BACK
LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-418).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-418).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-419).

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

CHECK SHEET

=NAEL0467S02

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					VDC/TCS/ABS	METER/M&A
			ECM	TCM	AWD/4WD	STRG			
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN	
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-	
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	

Symptoms:

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
---	--	---	--

Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
---	--	---	--

PKIA8707E

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

CHECK SHEET RESULTS (EXAMPLE)

=NAEL0467S03

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.


Case 1

NAEL0467S0301

Check harness between TCM and transfer control unit. Refer to "CIRCUIT CHECK BETWEEN TCM AND TRANSFER CONTROL UNIT" (EL-424).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8711E




Case 2

NAEL0467S0302

Check harness between transfer control unit and steering angle sensor. Refer to "CIRCUIT CHECK BETWEEN TRANSFER CONTROL UNIT AND STEERING ANGLE SENSOR" (EL-425).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8712E



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)


Case 3

NAEL0467S0303

Check harness between steering angle sensor and ABS actuator and electric unit (control unit). Refer to "CIRCUIT CHECK BETWEEN STEERING ANGLE SENSOR AND ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)" (EL-426).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8713E




Case 4

NAEL0467S0304

Check ECM circuit. Refer to "ECM CIRCUIT CHECK" (EL-427).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8714E



CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)


Case 5

Check TCM circuit. Refer to "TCM CIRCUIT CHECK" (EL-428).

=NAEL0467S0305

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8715E



PKIA8738E


Case 6

Check transfer control unit circuit. Refer to "TRANSFER CONTROL UNIT CIRCUIT CHECK" (EL-429).

NAEL0467S0306

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8716E



PKIA8739E

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)


Trouble Diagnoses (Cont'd)

Case 7

Check steering angle sensor circuit. Refer to "STEERING ANGLE SENSOR CIRCUIT CHECK" (EL-430). =NAEL0467S0307

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8717E




Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) CIRCUIT CHECK" (EL-431). =NAEL0467S0308

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8718E



CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)


Case 9

Check combination meter circuit. Refer to "COMBINATION METER CIRCUIT CHECK" (EL-432).

=NAEL0467S0309

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8719E



PKIA8742E

Case 10

Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-433).

NAEL0467S0310

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	AWD/4WD	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	-
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8720E

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)


Trouble Diagnoses (Cont'd)

CIRCUIT CHECK BETWEEN TCM AND TRANSFER CONTROL UNIT

NAEL0467S05

1 CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector, transfer control unit connector and combination meter connector.
2. Check continuity between TCM harness connector M119 terminals 5 (L), 6 (R) and transfer control unit harness connector M142 terminals 7 (L), 8 (R).



SEL707Y

OK or NG

OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-417).
NG	▶	Repair harness.

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

CIRCUIT CHECK BETWEEN TRANSFER CONTROL UNIT AND STEERING ANGLE SENSOR

=NAEL0467S06

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).</p> <ul style="list-style-type: none"> ● Harness connector M1 ● Harness connector E1 <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect transfer control unit connector and harness connector M1.</p> <p>2. Check continuity between transfer control unit harness connector M142 terminals 7 (L), 8 (R) and harness connector M1 terminals 4m (L), 11r (R).</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness.

3	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect steering angle sensor connector.</p> <p>2. Check continuity between harness connector E1 terminals 4m (L), 11r (R) and steering angle sensor harness connector E136 terminals 3 (L), 4 (R).</p>		
OK or NG		
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-417).
NG	▶	Repair harness.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

CIRCUIT CHECK BETWEEN STEERING ANGLE SENSOR AND ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

=NAEL0467S07


1	CHECK HARNESS FOR OPEN CIRCUIT
<p>1. Disconnect steering angle sensor connector, ABS actuator and electric unit (control unit) connector and combination meter connector.</p> <p>2. Check continuity between steering angle sensor harness connector E136 terminals 3 (L), 4 (R) and ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L), 15 (R).</p>	
<p>Continuity should exist.</p>	
<p>OK or NG</p>	
OK	▶ Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-417).
NG	▶ Repair harness.

SEL710Y

=NAEL0467S08

ECM CIRCUIT CHECK

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check following terminals and connector for damage, bend and loose connection (control module side and harness side). <ul style="list-style-type: none"> ● ECM ● Harness connector F23 ● Harness connector M32 		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect ECM connector. 2. Check resistance between ECM harness connector F203 terminals 94 (L) and 86 (R).		
		
Approx. 108 - 132 Ω		
OK or NG		
OK	▶	Replace ECM.
NG	▶	Repair harness between ECM and TCM.

SEL711Y

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

TCM CIRCUIT CHECK

=NAEL0467S09

1	CHECK CONNECTOR
1. Turn ignition switch OFF. 2. Check the terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT
1. Disconnect TCM connector. 2. Check resistance between TCM harness connector M119 terminals 5 (L) and 6 (R).	
	
SEL712Y	
OK or NG	
OK	▶ Replace ECM.
NG	▶ Repair harness between TCM and transfer control unit.

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

TRANSFER CONTROL UNIT CIRCUIT CHECK

=NAEL0467S10

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect transfer control unit connector. 2. Check resistance between transfer control unit harness connector M142 terminals 7 (L) and 8 (R).		
<p style="text-align: center;">Transfer control unit connector</p> <p style="text-align: center;">Approx. 54 - 66 Ω</p>		
OK or NG		
OK	▶	Replace transfer control unit.
NG	▶	Repair harness between transfer control unit and harness connector M1.

SEL713Y

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

STEERING ANGLE SENSOR CIRCUIT CHECK

=NAEL0467S11

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect steering angle sensor connector. 2. Check resistance between steering angle sensor harness connector E136 terminals 3 (L) and 4 (R).		
 <p style="text-align: center;">Steering angle sensor connector</p> <p style="text-align: right;">Approx. 54 - 66 Ω</p>		
OK or NG		
OK	▶	Replace steering angle sensor.
NG	▶	Repair harness between steering angle sensor and ABS actuator and electric unit (control unit).

SEL714Y


CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) CIRCUIT CHECK

=NAEL0467S12

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect ABS actuator and electric unit (control unit) connector. 2. Check resistance between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L) and 15 (R).		
 <p>ABS actuator and electric unit (control unit) connector</p>  <p style="text-align: right;">Approx. 54 - 66 Ω</p>		
SEL715Y		
OK or NG		
OK	▶	Replace ABS actuator and electric unit (control unit).
NG	▶	Repair harness between ABS actuator and electric unit (control unit) and harness connector E1.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

COMBINATION METER CIRCUIT CHECK

=NAEL0467S13

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF. 2. Check following terminals and connector for damage, bend and loose connection (meter side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter. ● Harness connector M1. ● Harness connector E1. <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.


2	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect combination meter connector. 2. Check resistance between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p> <div style="text-align: center;">  <p style="text-align: right;">Approx. 108 - 132 Ω</p> </div> <p style="text-align: center;">OK or NG</p>		
OK	▶	Replace combination meter.
NG	▶	Repair harness between combination meter and ABS actuator and electric unit (control unit).


SEL716Y

CAN COMMUNICATION CIRCUIT CHECK

=NAEL0467S14

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (meter side, control unit side, sensor side, control module side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter ● ABS actuator and electric unit (control unit) ● Steering angle sensor ● Transfer control unit ● TCM ● ECM ● Between combination meter and ECM 		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect ECM connector and harness connector F23.</p> <p>2. Check continuity between ECM harness connector F203 terminals 94 (L) and 86 (R).</p>		
		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness between ECM and harness connector F23.

3	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ECM harness connector F203 terminals 94 (L), 86 (R) and ground.</p>		
		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair harness between ECM and harness connector F23.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

4	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect TCM connector, transfer control unit connector and harness connector M1. 2. Check continuity between TCM harness connector M119 terminals 5 (L) and 6 (R).</p>		
<p style="text-align: center;">TCM connector</p> <p style="text-align: center;">Continuity should not exist.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32. ● Repair harness between TCM and transfer control unit.

SEL440Y

5	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between TCM harness connector M119 terminals 5 (L), 6 (R) and ground.</p>		
<p style="text-align: center;">TCM connector</p> <p style="text-align: center;">Continuity should not exist.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32. ● Repair harness between TCM and transfer control unit.

SEL441Y

CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)


6	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect steering angle sensor connector and ABS actuator and electric unit (control unit) connector.</p> <p>2. Check continuity between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L) and 15 (R).</p>		
<p>ABS actuator and electric unit (control unit) connector</p>		
		Continuity should not exist.
		SEL719Y
OK or NG		
OK	▶	GO TO 7.
NG	▶	<ul style="list-style-type: none"> Repair harness between ABS actuator and electric unit (control unit) and harness connector E1. Repair harness between ABS actuator and electric unit (control unit) and steering angle sensor.


7	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L), 15 (R) and ground.</p>		
<p>ABS actuator and electric unit (control unit) connector</p>		
		Continuity should not exist.
		SEL720Y
OK or NG		
OK	▶	GO TO 8.
NG	▶	<ul style="list-style-type: none"> Repair harness between ABS actuator and electric unit (control unit) and harness connector E1. Repair harness between ABS actuator and electric unit (control unit) and steering angle sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 1)

Trouble Diagnoses (Cont'd)

8	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect combination meter connector. 2. Check continuity between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p>		
		
SEL721Y		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Repair harness between combination meter and harness connector M1.

9	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between combination meter harness connector M25 terminals 34 (Y), 35 (L) and ground.</p>		
		
SEL722Y		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Repair harness between combination meter and harness connector M1.

10	ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION	
<p>Check components inspection. Refer to "ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION" (EL-437).</p>		
OK or NG		
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-417).
NG	▶	Replace ECM and/or combination meter.



Component Inspection ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION

=NAEL0468

NAEL0468S01

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 34 and 35.

Unit	Terminal	Resistance value (Ω)
ECM	94 - 86	Approx. 108 - 132
Combination meter	34 - 35	

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

CAN SYSTEM (TYPE 2)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0469



System Description

NAEL0470

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN SYSTEM (TYPE 2)





Wiring Diagram — CAN —

Wiring Diagram — CAN —

NAEL0471

EL-CAN-03

— : DATA LINE



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



MEL576Q

CAN SYSTEM (TYPE 2)

Wiring Diagram — CAN — (Cont'd)

EL-CAN-04

▬ : DATA LINE



REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL577Q

Trouble Diagnoses

NAEL0472

WORK FLOW

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
		Scroll Down	
BACK	LIGHT	COPY	

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]	0
F.F.DATA	
ERASE PRINT	
MODE	BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T" and "ABS" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
		Scroll Down	
BACK	LIGHT	COPY	

CAN DIAG SUPPORT MNTR	
ENGINE	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	OK
IPDM E/R	OK
AWD/4WD/e4WD	UNKWN
PRINT	
MODE	BACK LIGHT COPY
	Scroll Down

PKIA8343E

- Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-442).
- Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-442).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

- According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-443).

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

CHECK SHEET

=NAEL0472S02

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

Symptoms:

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT MNTR

Attach copy of
A/T
CAN DIAG SUPPORT MNTR

Attach copy of
ABS
CAN DIAG SUPPORT MNTR

PKIA8708E

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

CHECK SHEET RESULTS (EXAMPLE)

=NAEL0472S03

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.


Case 1

NAEL0472S0301

Check harness between TCM and steering angle sensor. Refer to "CIRCUIT CHECK BETWEEN TCM AND STEERING ANGLE SENSOR" (EL-448).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8721E



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)


Case 2

=NAEL0472S0302

Check harness between steering angle sensor and ABS actuator and electric unit (control unit). Refer to "CIRCUIT CHECK BETWEEN STEERING ANGLE SENSOR AND ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)" (EL-449).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8722E



PKIA8744E


Case 3

NAEL0472S0303

Check ECM circuit. Refer to "ECM CIRCUIT CHECK" (EL-450).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8723E



PKIA8745E

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)


Case 4

Check TCM circuit. Refer to "TCM CIRCUIT CHECK" (EL-451).

=NAEL0472S0304

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8724E



PKIA8746E


Case 5

Check steering angle sensor circuit. Refer to "STEERING ANGLE SENSOR CIRCUIT CHECK" (EL-452).

NAEL0472S0305

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8725E



PKIA8747E

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 2)


Trouble Diagnoses (Cont'd)

Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) CIRCUIT CHECK" (EL-453). =NAEL0472S0306

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8726E




PKIA8748E

Case 7

Check combination meter circuit. Refer to "COMBINATION METER CIRCUIT CHECK" (EL-454). =NAEL0472S0307

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ABS	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN

PKIA8727E



PKIA8749E

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

Case 8

Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-455).

=NAEL0472S0308

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	STRG	VDC/TCS/ ABS	METER/ M&A
ENGINE	NG	UN KN WN	-	UN KN WN	-	UN KN WN	UN KN WN
A/T	NG	UN KN WN	UN KN WN	-	-	UN KN WN	UN KN WN
ABS	NG	UN KN WN	UN KN WN	UN KN WN	UN KN WN	-	UN KN WN

PKIA8728E

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

CIRCUIT CHECK BETWEEN TCM AND STEERING ANGLE SENSOR

=NAEL0472S06

1	CHECK CONNECTOR	<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (connector side and harness side).</p> <ul style="list-style-type: none"> ● Harness connector M1 ● Harness connector E1 <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	<p>1. Disconnect TCM connector and harness connector M1.</p> <p>2. Check continuity between TCM harness connector M119 terminals 5 (L), 6 (R) and harness connector M1 terminals 4m (L), 11r (R).</p> <div style="text-align: center;"> <p style="text-align: center;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p> </div> <p style="text-align: right;">SEL728Y</p>
OK	▶	GO TO 3.
NG	▶	Repair harness.

3	CHECK HARNESS FOR OPEN CIRCUIT	<p>1. Disconnect steering angle sensor connector.</p> <p>2. Check continuity between harness connector E1 terminals 4m (L), 11r (R) and steering angle sensor harness connector E136 terminals 3 (L), 4 (R).</p> <div style="text-align: center;"> <p style="text-align: center;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p> </div> <p style="text-align: right;">SEL709Y</p>
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-441).
NG	▶	Repair harness.

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

CIRCUIT CHECK BETWEEN STEERING ANGLE SENSOR AND ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

=NAEL0472S07

1	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect steering angle sensor connector, ABS actuator and electric unit (control unit) connector and combination meter connector.</p> <p>2. Check continuity between steering angle sensor harness connector E136 terminals 3 (L), 4 (R) and ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L), 15 (R).</p>		
		Continuity should exist.
OK or NG		
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-441).
NG	▶	Repair harness.

SEL710Y

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

=NAEL0472S08

ECM CIRCUIT CHECK


1	CHECK CONNECTOR	
		<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (control module side and harness side).</p> <ul style="list-style-type: none"> ● ECM ● Harness connector F23 ● Harness connector M32 <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
		<p>1. Disconnect ECM connector.</p> <p>2. Check resistance between ECM harness connector F203 terminals 94 (L) and 86 (R).</p> <div style="text-align: center;">  <p style="text-align: center;">Approx. 108 - 132 Ω</p> </div> <p style="text-align: right;">SEL711Y</p> <p style="text-align: center;">OK or NG</p>
OK	▶	Replace ECM.
NG	▶	Repair harness between ECM and TCM.

TCM CIRCUIT CHECK

=NAEL0472S09

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect TCM connector. 2. Check resistance between TCM harness connector M119 terminals 5 (L) and 6 (R).		
		
Approx. 54 - 66 Ω		
OK or NG		
SEL712Y		
OK	▶	Replace TCM.
NG	▶	Repair harness between TCM and harness connector M1.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

STEERING ANGLE SENSOR CIRCUIT CHECK

=NAEL0472S11

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect steering angle sensor connector. 2. Check resistance between steering angle sensor harness connector E136 terminals 3 (L) and 4 (R).		
 <p style="text-align: center;">Steering angle sensor connector</p>		
Approx. 54 - 66 Ω		
OK or NG		
OK	▶	Replace steering angle sensor.
NG	▶	Repair harness between steering angle sensor and ABS actuator and electric unit (control unit).

SEL714Y

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) CIRCUIT CHECK

=NAEL0472S12

1	CHECK CONNECTOR	
	1. Turn ignition switch OFF. 2. Check the terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).	
	OK or NG	
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
	1. Disconnect ABS actuator and electric unit (control unit) connector. 2. Check resistance between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L) and 15 (R).	
	ABS actuator and electric unit (control unit) connector	
		Approx. 54 - 66 Ω
		SEL715Y
	OK or NG	
OK	▶	Replace ABS actuator and electric unit (control unit).
NG	▶	Repair harness between ABS actuator and electric unit (control unit) and harness connector E1.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

COMBINATION METER CIRCUIT CHECK

=NAEL0472S13

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF. 2. Check following terminals and connector for damage, bend and loose connection (meter side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter. ● Harness connector M1. ● Harness connector E1. <p style="text-align: right;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect combination meter connector. 2. Check resistance between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p> <div style="text-align: center;">  <p>Approx. 108 - 132 Ω</p> </div> <p style="text-align: right;">SEL716Y</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Replace combination meter.
NG	▶	Repair harness between combination meter and ABS actuator and electric unit (control unit).

=NAEL0472S14

CAN COMMUNICATION CIRCUIT CHECK

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (meter side, control unit side, sensor side, control module side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter ● ABS actuator and electric unit (control unit) ● Steering angle sensor ● TCM ● ECM ● Between combination meter and ECM <p style="text-align: right;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect ECM connector and harness connector F23.</p> <p>2. Check continuity between ECM harness connector F203 terminals 94 (L) and 86 (R).</p> <div style="text-align: center;"> </div>		
OK	▶	GO TO 3.
NG	▶	Repair harness between ECM and harness connector F23.

3	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ECM harness connector F203 terminals 94 (L), 86 (R) and ground.</p> <div style="text-align: center;"> </div>		
OK	▶	GO TO 4.
NG	▶	Repair harness between ECM and harness connector F23.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

4	CHECK HARNESS FOR SHORT CIRCUIT		
<p>1. Disconnect TCM connector and harness connector M1. 2. Check continuity between TCM harness connector M119 terminals 5 (L) and 6 (R).</p>			
<p style="text-align: center;">TCM connector</p>			
		Continuity should not exist.	
		SEL440Y	
OK or NG			
OK	▶	GO TO 5.	
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32. 	

5	CHECK HARNESS FOR SHORT CIRCUIT		
Check continuity between TCM harness connector M119 terminals 5 (L), 6 (R) and ground.			
<p style="text-align: center;">TCM connector</p>			
		Continuity should not exist.	
		SEL441Y	
OK or NG			
OK	▶	GO TO 6.	
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32. 	

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)

6	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect steering angle sensor connector and ABS actuator and electric unit (control unit) connector.</p> <p>2. Check continuity between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L) and 15 (R).</p>		
<p>ABS actuator and electric unit (control unit) connector</p> <div style="display: flex; justify-content: center; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">C/UNIT</div> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">○</div> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">CONNECTOR</div> </div> <div style="display: flex; justify-content: center; align-items: center; margin-top: 10px;"> <div style="text-align: center; margin-right: 20px;">11</div> <div style="text-align: center; margin-right: 20px;">Ω</div> <div style="text-align: center;">15</div> </div>		
Continuity should not exist.		
SEL719Y		
OK or NG		
OK	▶	GO TO 7.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between ABS actuator and electric unit (control unit) and harness connector E1. ● Repair harness between ABS actuator and electric unit (control unit) and steering angle sensor.

7	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ABS actuator and electric unit (control unit) harness connector E142 terminals 11 (L), 15 (R) and ground.</p>		
<p>ABS actuator and electric unit (control unit) connector</p> <div style="display: flex; justify-content: center; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">C/UNIT</div> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">○</div> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">CONNECTOR</div> </div> <div style="display: flex; justify-content: center; align-items: center; margin-top: 10px;"> <div style="text-align: center; margin-right: 20px;">11, 15</div> <div style="text-align: center; margin-right: 20px;">Ω</div> <div style="text-align: center;"> </div> </div>		
Continuity should not exist.		
SEL720Y		
OK or NG		
OK	▶	GO TO 8.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between ABS actuator and electric unit (control unit) and harness connector E1. ● Repair harness between ABS actuator and electric unit (control unit) and steering angle sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 2)

Trouble Diagnoses (Cont'd)


8	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect combination meter connector. 2. Check continuity between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p>		
<p style="text-align: center;">Continuity should not exist.</p>		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Repair harness between combination meter and harness connector M1.

SEL721Y

9	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between combination meter harness connector M25 terminals 34 (Y), 35 (L) and ground.</p>		
<p style="text-align: center;">Continuity should not exist.</p>		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Repair harness between combination meter and harness connector M1.

SEL722Y

10	ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION	
<p>Check components inspection. Refer to "ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION" (EL-459).</p>		
OK or NG		
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-441).
NG	▶	Replace ECM and/or combination meter.



Component Inspection

ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION

=NAEL0473

NAEL0473S01

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 34 and 35.

Unit	Terminal	Resistance value (Ω)
ECM	94 - 86	Approx. 108 - 132
Combination meter	34 - 35	

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

CAN SYSTEM (TYPE 3)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NAEL0474



System Description

NAEL0475

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN SYSTEM (TYPE 3)






Wiring Diagram — CAN —

Wiring Diagram — CAN —

NAEL0476

EL-CAN-05

— — — — — : DATA LINE



REFER TO THE FOLLOWING.
 (E1) - SUPER MULTIPLE
 JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

MEL580Q

CAN SYSTEM (TYPE 3)

Trouble Diagnoses

WORK FLOW

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE" and "A/T" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]	0
F.F.DATA	
ERASE	PRINT
MODE	BACK
LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE" and "A/T" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	

CAN DIAG SUPPORT MNTR	
ENGINE	
	PRSNT
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	OK
METER/M&A	OK
ICC	UNKWN
BCM/SEC	OK
IPDM E/R	OK
AWD/4WD/e4WD	UNKWN
PRINT	Scroll Down
MODE	BACK
LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-463).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-463).

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

5. According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-464).

CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

CHECK SHEET

=NAEL0477S02

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis		
			ECM	TCM	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	UNKWN
A/T	NG	UNKWN	UNKWN	-	UNKWN

Symptoms:

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT MNTR

Attach copy of
A/T
CAN DIAG SUPPORT MNTR

PKIA8709E

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

CHECK SHEET RESULTS (EXAMPLE)

=NAEL0477S03

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.


Case 1

NAEL0477S0301

Check ECM circuit. Refer to "ECM CIRCUIT CHECK" (EL-466).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis		
			ECM	TCM	METER/M&A
ENGINE	NG	UNKWN ✓	-	UNKWN ✓	UNKWN ✓
A/T	NG	UNKWN	UNKWN ✓	-	UNKWN

PKIA8729E



PKIA8750E


Case 2

NAEL0477S0302

Check TCM circuit. Refer to "TCM CIRCUIT CHECK" (EL-467).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis		
			ECM	TCM	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN ✓	UNKWN
A/T	NG	UNKWN ✓	UNKWN ✓	-	UNKWN ✓

PKIA8730E



PKIA8751E

CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)


Case 3

Check combination meter circuit. Refer to "COMBINATION METER CIRCUIT CHECK" (EL-468).

NAEL0477S0303

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis		
			ECM	TCM	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN	UNKWN ✓
A/T	NG	UNKWN	UNKWN	-	UNKWN ✓

PKIA8731E



PKIA8752E

Case 4

Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-469).

NAEL0477S0304

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR				
	Initial diagnosis	Transmit diagnosis	Receive diagnosis		
			ECM	TCM	METER/M&A
ENGINE	NG	UNKWN ✓	-	UNKWN ✓	UNKWN ✓
A/T	NG	UNKWN ✓	UNKWN ✓	-	UNKWN ✓

PKIA8732E

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

ECM CIRCUIT CHECK

=NAEL0477S07

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (control module side and harness side).</p> <ul style="list-style-type: none"> ● ECM ● Harness connector F23 ● Harness connector M32 		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.


2	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect ECM connector.</p> <p>2. Check resistance between ECM harness connector F203 terminals 94 (L) and 86 (R).</p>		
		
OK or NG		
OK	▶	Replace ECM.
NG	▶	Repair harness between ECM and TCM.

SEL711Y

TCM CIRCUIT CHECK

=NAEL0477S08

1	CHECK CONNECTOR	
1. Turn ignition switch OFF. 2. Check the terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
1. Disconnect TCM connector. 2. Check resistance between TCM harness connector M119 terminals 5 (L) and 6 (R).		
		
OK or NG		
OK	▶	Replace TCM.
NG	▶	Repair harness between TCM and harness connector M1.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

COMBINATION METER CIRCUIT CHECK

=NAEL0477S11

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (meter side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter ● Harness connector M1 ● Harness connector E1 <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR OPEN CIRCUIT	
<p>1. Disconnect combination meter connector.</p> <p>2. Check resistance between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Approx. 108 - 132 Ω</p> </div> <p style="text-align: right; margin-right: 50px;">SEL716Y</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Replace combination meter.
NG	▶	Repair harness between combination meter and TCM.

CAN COMMUNICATION CIRCUIT CHECK

=NAEL0477S12

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (meter side, control module side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter ● TCM ● ECM ● Between combination meter and ECM <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.


2	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect ECM connector and harness connector F23.</p> <p>2. Check continuity between ECM harness connector F203 terminals 94 (L) and 86 (R).</p>		
SEL717Y		
OK	▶	GO TO 3.
NG	▶	Repair harness between ECM and harness connector F23.

3	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ECM harness connector F203 terminals 94 (L), 86 (R) and ground.</p>		
SEL718Y		
OK	▶	GO TO 4.
NG	▶	Repair harness between ECM and harness connector F23.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

4	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect TCM connector and harness connector M1. 2. Check continuity between TCM harness connector M119 terminals 5 (L) and 6 (R).</p>		
		
Continuity should not exist.		
OK or NG		
OK	▶	GO TO 5.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32.


SEL440Y

5	CHECK HARNESS FOR SHORT CIRCUIT	
Check continuity between TCM harness connector M119 terminals 5 (L), 6 (R) and ground.		
		
Continuity should not exist.		
OK or NG		
OK	▶	GO TO 6.
NG	▶	<ul style="list-style-type: none"> ● Repair harness between TCM and harness connector M1. ● Repair harness between TCM and harness connector M32.


SEL441Y

CAN SYSTEM (TYPE 3)


Trouble Diagnoses (Cont'd)

6	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between harness connector E1 terminals 6m (L) and 12m (R).</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>SMJ harness connector</p>  </div> <div style="text-align: center;"> <p>Continuity should not exist.</p> </div> </div> <p style="text-align: right;">SEL732Y</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 7.
NG	▶	Repair harness between harness connector E1 and harness connector E1.

GI
MA
EM
LC
EC
FE
CL

7	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between harness connector E1 terminals 6m (L), 12m (R) and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>SMJ harness connector</p>  </div> <div style="text-align: center;"> <p>Continuity should not exist.</p> </div> </div> <p style="text-align: right;">SEL733Y</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 8.
NG	▶	Repair harness between harness connector E1 and harness connector E1.


MT
AT
TF
PD
AX
SU
BR

8	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect combination meter connector. 2. Check continuity between combination meter harness connector M25 terminals 34 (Y) and 35 (L).</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Combination meter connector</p>  </div> <div style="text-align: center;"> <p>Continuity should not exist.</p> </div> </div> <p style="text-align: right;">SEL721Y</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 9.
NG	▶	Repair harness between combination meter and harness connector M1.

ST
RS
BT
HA
SC
EL
IDX


CAN SYSTEM (TYPE 3)

Trouble Diagnoses (Cont'd)

9	CHECK HARNESS FOR SHORT CIRCUIT
<p>Check continuity between combination meter harness connector M25 terminals 34 (Y), 35 (L) and ground.</p> <div style="text-align: center;">  <p>Continuity should not exist.</p> <p>OK or NG</p> </div>	
OK	▶ GO TO 10.
NG	▶ Repair harness between combination meter and harness connector M1.

SEL722Y

10	ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION
<p>Check components inspection. Refer to "ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION" (EL-472).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-462).
NG	▶ Replace ECM and/or combination meter.



Component Inspection

ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION

NAEL0478


NAEL0478S01

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 34 and 35.

Unit	Terminal	Resistance value (Ω)
ECM	94 - 86	Approx. 108 - 132
Combination meter	34 - 35	

CAN SYSTEM (TYPE 4)

Component Parts and Harness Connector Location



Component Parts and Harness Connector Location

NAEL0479

System Description

NAEL0480

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CAN SYSTEM (TYPE 4)


Wiring Diagram — CAN —

Wiring Diagram — CAN —

NAEL0481

EL-CAN-06

▬ : DATA LINE




25	26	27	28	29	30	31	32	33		
34	35	36	37	38	39	40	41	42	43	44

(M25) BR

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(M32) BR

REFER TO THE FOLLOWING.
 (E1) - SUPER MULTIPLE JUNCTION (SMJ)



MEL581Q

Trouble Diagnoses

NAEL0482

NAEL0482S01

WORK FLOW

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
		Scroll Down	
BACK	LIGHT	COPY	

➔

SELF-DIAG RESULTS			
DTC RESULTS	TIME		
CAN COMM CIRCUIT [U1000]	0		
F.F.DATA			
ERASE	PRINT		
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
		Scroll Down	
BACK	LIGHT	COPY	

➔

CAN DIAG SUPPORT MNTR			
ENGINE			
	PRSNT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
TCM	OK		
VDC/TCS/ABS	OK		
METER/M&A	OK		
ICC	UNKWN		
BCM/SEC	OK		
IPDM E/R	OK		
AWD/4WD/e4WD	UNKWN		
PRINT	Scroll Down		
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to "CHECK SHEET" (EL-476).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put "v" marks onto the items with "UNKWN" or "NG" in the check sheet table. Refer to "CHECK SHEET" (EL-476).

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
5. According to the check sheet results (example), start inspection. Refer to "CHECK SHEET RESULTS (EXAMPLE)" (EL-476).

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 4)

Trouble Diagnoses (Cont'd)

CHECK SHEET

=NAEL0482S02

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis	
			ECM	METER/M&A
ENGINE	NG	UNKWN	-	UNKWN

Symptoms:

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT MNTR

PKIA8710E

CHECK SHEET RESULTS (EXAMPLE)

NAEL0482S03

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Case 1

NAEL0482S0301

Check CAN communication circuit. Refer to "CAN COMMUNICATION CIRCUIT CHECK" (EL-477).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR			
	Initial diagnosis	Transmit diagnosis	Receive diagnosis	
			ECM	METER/M&A
ENGINE	NG	UNKWN ✓	-	UNKWN ✓

PKIA8733E

CAN SYSTEM (TYPE 4)

Trouble Diagnoses (Cont'd)

CAN COMMUNICATION CIRCUIT CHECK

NAEL0482S08

1	CHECK CONNECTOR	
<p>1. Turn ignition switch OFF.</p> <p>2. Check following terminals and connector for damage, bend and loose connection (meter side, control module side and harness side).</p> <ul style="list-style-type: none"> ● Combination meter ● ECM ● Between combination meter and ECM <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair terminal or connector.

2	CHECK HARNESS FOR SHORT CIRCUIT	
<p>1. Disconnect ECM connector and combination meter connector.</p> <p>2. Check continuity between ECM harness connector F203 terminals 94 (L) and 86 (R).</p>		
SEL717Y		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness between ECM and combination meter.

3	CHECK HARNESS FOR SHORT CIRCUIT	
<p>Check continuity between ECM harness connector F203 terminals 94 (L), 86 (R) and ground.</p>		
SEL718Y		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair harness between ECM and combination meter.


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CAN SYSTEM (TYPE 4)

Trouble Diagnoses (Cont'd)

4	CHECK HARNESS FOR OPEN CIRCUIT	
<p>Check continuity between ECM harness connector F203 terminals 94 (L), 86 (R) and combination meter harness connector M25 terminals 34 (Y), 35 (L).</p>		
OK	▶	GO TO 5.
NG	▶	Repair harness.

5	ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION	
<p>Check components inspection. Refer to "ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION" (EL-478).</p>		
OK or NG		
OK	▶	Connect all the connectors and diagnose again. Refer to "Work Flow" (EL-475).
NG	▶	Replace ECM and/or combination meter.



Component Inspection

ECM/COMBINATION METER INTERNAL CIRCUIT INSPECTION

NAEL0483

NAEL0483S01

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 34 and 35.

Unit	Terminal	Resistance value (Ω)
ECM	94 - 86	Approx. 108 - 132
Combination meter	34 - 35	



ELECTRICAL UNITS LOCATION

Engine Compartment

Engine Compartment

NAEL0431

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




MEL063Q

ELECTRICAL UNITS LOCATION


Passenger Compartment

Passenger Compartment

NAEL0432




A Instrument panel LH side




MEL113S

ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)



J Behind the luggage room trim LH side



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC

EL

MEL114S


IDX

HARNESS LAYOUT

How to Read Harness Layout

How to Read Harness Layout

NAEL0433



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

TO USE THE GRID REFERENCE

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

NAEL0433S01

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

NAEL0433S02


Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> • Ground terminal etc. 	—			

HARNESS LAYOUT

Outline

Outline

NAEL0434



MEL072M

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

HARNESS LAYOUT

Main Harness

Main Harness

NAEL0435



★: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

Body ground





Body ground

MEL100S

HARNESS LAYOUT

Main Harness (Cont'd)

B4★ (M1)	SMJ : To (E1)	E1★ (M47)	W/20 : To (Z1)	F4★ (M99)	W/12 : To (B77)
B4★ (M2)	SMJ : To (B1)	D4 (M48)	W/10 : Audio unit	F4★ (M100)	GY/20 : To (B88)
A3	— : Body ground	G3 (M49)	W/6 : Audio unit	G2 (M101)	BR/6 : To (D41)
B4 (M5)	BR/16 : To (D3)	D1 (M51)	W/8 : Combination meter (With all-mode 4-wheel drive and normal meter)	F2 (M102)	GY/16 : A/C auto amp. (With auto A/C)
A3 (M6)	W/10 : To (D4)	E4 (M52)	L/4 : Heated seat switch LH (With heated seat, without woody instrument finisher)	D1 (M103)	GY/20 : A/C auto amp.
A3 (M7)	B/2 : Diode (For Canada)	F4 (M53)	W/4 : Heated seat switch RH (With heated seat, without woody instrument finisher)	D4 (M107)	W/2 : Intake sensor
A2 (M8)	BR/2 : Tweeter LH	D4 (M55)	W/3 : Air mix door motor (With auto A/C)	A3 (M111)	— : Body ground
C4 (M9)	W/16 : Data link connector	F4 (M56)	B/2 : Cigarette lighter socket	A4 (M112)	GY/12 : To (D13)
B2★ (M10)	SMJ : Fuse block (J/B)	F4 (M57)	W/2 : Cigarette lighter illumination (For Canada)	A3★ (M114)	W/18 : To (E116)
B4 (M12)	GY/3 : Diode	E1 (M58)	B/2 : Sunload sensor (With auto A/C)	B4★ (M119)	W/24 : TCM (Transmission control module)
C4★ (M14)	L/2 : ASCD clutch switch (With M/T)	G2 (M59)	W/8 : Intake door motor (With auto A/C)	B4★ (M120)	GY/24 : TCM (With A/T)
B3 (M15)	B/3 : Combination flasher unit	G2 (M60)	W/4 : Fan control amp. (With auto A/C)	C2 (M121)	W/24 : Smart entrance control unit
C4 (M17)	GY/6 : Memory seat cancel switch	G1 (M61)	BR/4 : Fan resistor (With manual A/C)	C2 (M122)	GY/24 : Smart entrance control unit
C4 (M19)	W/3 : Illumination control switch	F1 (M62)	W/6 : To (R1)	C2 (M123)	GY/16 : Smart entrance control unit
C3 (M20)	W/2 : Security indicator lamp	F1 (M63)	W/6 : To (R2)	A3 (M132)	B/2 : Diode
B2 (M23)	L/4 : Power window relay	G2 (M64)	BR/2 : Tweeter RH	F3 (M139)	W/16 : Audio unit (With steering receiver control)
C1★ (M24)	W/24 : Combination meter	G2 (M66)	— : Body ground	C3 (M140)	W/10 : Door mirror remote control switch
D1★ (M25)	BR/20 : Combination meter	F2 (M67)	BR/16 : To (D33)	E4★ (M141)	W/8 : 4WD shift switch
D1★ (M26)	BR/24 : Combination meter	G2 (M68)	W/6 : To (D34)	E4★ (M142)	L/24 : Transfer control unit (With all-mode 4-wheel drive)
C3★ (M28)	L/2 : Clutch interlock switch (With M/T)	F3 (M69)	W/3 : Power antenna	E4★ (M143)	G/24 : Transfer control unit
E3 (M30)	W/2 : ASCD brake switch	F3★ (M70)	W/20 : To (B50)	B2 (M144)	W/4 : Power socket relay
C3★ (M31)	B/2 : Stop lamp switch (With M/T)	F3★ (M71)	W/24 : To (B51)	B2 (M145)	W/2 : Circuit breaker
D3★ (M32)	BR/24 : To (F23)	F3★ (M72)	W/16 : To (B52)	G2 (M147)	— : Body ground
D3★ (M33)	GY/16 : To (F22)	G3 (M73)	W/2 : Blower motor	E4 (M148)	W/4 : Rear TV switch (With rear TV, without woody instrument finisher)
D3 (M34)	W/2 : In-vehicle sensor (With auto A/C)	E1 (M75)	W/3 : Auto light sensor	G3 (M150)	W/4 : Intake door motor (With manual A/C)
E2 (M35)	W/8 : Hazard switch	A3 (M81)	B/2 : Fuse block (J/B)	C4 (M151)	L/6 : VDC off switch (With VDC)
D3 (M36)	W/6 : Rear window defogger switch (With auto A/C and normal meter, with manual A/C)	D1 (M89)	B/2 : Diode (With manual A/C)	C3 (M152)	W/2 : Tire pressure warning check switch (With low tire pressure warning system)
C2 (M37)	B/2 : Diode	B3★ (M91)	W/12 : Fuse block (J/B)	C3★ (M154)	W/4 : Stop lamp switch (With A/T)
E4 (M38)	W/3 : Mode door motor (With auto A/C)	D3 (M92)	B/2 : CD player (Without BOSE system)	F4 (M155)	W/2 : Ashtray illumination (With woody instrument finisher)
D2 (M40)	W/4 : Clock	D3 (M93)	W/4 : CD player (Without BOSE system)	G1 (M156)	W/16 : Low tire pressure warning control unit (With low tire pressure warning system)
D4 (M41)	W/8 : Steering wheel receiver control switch	D3★ (M94)	W/18 : To (F27)	A3 (M157)	— : Body ground
E2 (M42)	W/4 : Recirculation switch (With manual A/C)	B3★ (M98)	GY/6 : Joint connector	A4★ (M158)	— : Body ground
F1 (M43)	W/6 : Fan switch (With manual A/C)	★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.		D1 (M159)	W/6 : Combination meter (With all-mode 4-wheel drive and fine vision meter)
F2 (M44)	W/3 : A/C switch (With manual A/C)	Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.			
E1 (M45)	W/3 : A/C switch illumination (With manual A/C)				



MEL101S


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Engine Room Harness

Engine Room Harness

NAEL0436



* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.


MEL102S

HARNESS LAYOUT


Engine Room Harness (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.



★ E1	SMJ	: To	M1	★ E116	W/18	: To	M114
E2	B/2	: Fuse block (J/B)		E117	BR/6	: Rear window defogger relay (Relay box-1)	
E3	W/16	: Fuse block (J/B)		E118	BR/6	: Horn relay (Relay box-1)	
E4	W/4	: Fuse block (J/B)		E120	B/1	: Horn (High)	
E5	BR/2	: Key switch		E121	W/2	: Diode	
★ E6	W/6	: Ignition switch		★ E123	SB/2	: Swirl control valve control vacuum check switch	
E7	BR/4	: Combination switch (Lighting switch)		B3	E125	B/3	: Refrigerant pressure sensor
E8	W/8	: Combination switch (Lighting and turn signal switch)		A2	E127	GY/4	: Daytime light control unit (For Canada)
E9	GY/8	: Combination switch (Front wiper switch)		C2	★ E135	GY/8	: To E132
E4	E12	GY/3	: Front turn signal and parking lamp LH	E2	E137	—/3	: VDC pressure sensor (With VDC)
E3	★ E13	—	: Body ground	B1	★ E138	L/4	: Throttle control motor relay (Relay box-2)
F4	E14	BR/2	: Front wheel sensor LH	D2	E140	GY/6	: Front wiper motor relay (Relay box-2)
D1	E16	L/4	: Front fog lamp relay (Relay box-1)	D2	E142	SMJ	: ABS actuator and electric unit (With VDC)
D1	E24	B/5	: ATP relay (With A/T and part-time 4-wheel drive) (Relay box-1)	A1	E148	L/4	: Park/Neutral position relay (With A/T) (Relay box-2)
F1	E26	L/4	: A/C relay (Relay box-1)	E149	W/2	: To E170	(With trailer)
E2	E28	GY/2	: Brake fluid level switch				
D4	E29	B/3	: Headlamp LH				
C3	E32	B/2	: Ambient sensor (With auto A/C)				
C4	E33	B/2	: Ambient air temperature sensor (For thermometer)				
B3	E36	B/1	: Horn (Low)				
A3	E38	B/3	: Headlamp RH				
A3	E40	GY/3	: Front turn signal and parking lamp RH				
A2	★ E41	—	: Body ground				
B4	E42	BR/2	: Washer level switch (For Canada)				
B4	E43	GY/2	: Rear washer motor				
A4	E44	GY/2	: Front washer motor				
A2	E45	GY/8	: Daytime light control unit (For Canada)				
A2	E46	GY/6	: Daytime light control unit (For Canada)				
A2	★ E47	GY/2	: A/T dropping resistor (With A/T)				
B1	★ E48	GY/4	: To E102				
C2	E49	GY/1	: To E104				
C3	E51	GY/2	: Front wheel sensor RH				
D2	E52	B/1	: Battery				
C2	E53	B/1	: Battery				
A1	E55	L/4	: Clutch interlock relay (With M/T) (Relay box-2)				
B1	★ E57	BR/6	: ECM relay (Relay box-2)				
C1	★ E60	—	: Fuse and fusible link box				
D5	E61	L/2	: Front fog lamp LH				
A4	E62	L/2	: Front fog lamp RH				
	E63	W/3	: Combination switch (Front fog lamp switch)				
B2	★ E81	GY/2	: Transfer dropping resistor (With all-mode 4-wheel drive)				
F2	★ E92	W/1	: Transfer motor relay (With all-mode 4-wheel drive)				
F2	★ E93	W/1	: Transfer motor relay (With all-mode 4-wheel drive)				
G2	★ E94	GY/2	: Transfer motor relay (With all-mode 4-wheel drive)				
D1	★ E95	B/5	: Transfer shift Hi relay (With all-mode 4-wheel drive) (Relay box-1)				
D1	E97	L/4	: Headlamp RH relay (Relay box-1)				
E1	E98	L/4	: Headlamp LH relay (Relay box-1)				
F1	★ E99	B/5	: Transfer shift Low relay (With all-mode 4-wheel drive) (Relay box-1)				
D2	★ E111	SMJ	: ABS actuator and electric unit (Without VDC)				
D3	E112	—	: Body ground				
	E113	W/8	: NATS IMMU				
	E114	W/4	: Combination switch (Rear wiper switch)				
F1	E115	L/4	: Tail lamp relay (Relay box-1)				




MEL103S

HARNESS LAYOUT

Engine Control Harness

Engine Control Harness

NAEL0437



* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.

Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

MEL104S

HARNESS LAYOUT

Engine Control Harness (Cont'd)

E5	(F5)	L/8	:	To (F100)	F5★	(F116)	SB/2	:	To (F19)
G5★	(F10)	B/6	:	Mass air flow sensor	C4	(F118)	GY/3	:	Ignition coil No. 2
E5★	(F19)	SB/2	:	To (F116)	F1	(F119)	GY/3	:	Ignition coil No. 4
D5	(F20)	—	:	Engine ground	G3	(F120)	GY/3	:	Ignition coil No. 6
G1★	(F22)	GY/16	:	To (M33)	D5	(F202)	B/1	:	Compressor (Air conditioner)
G1★	(F23)	BR/24	:	To (M32)	F2★	(F203)	SMJ	:	ECM
D5	(F25)	—	:	Engine ground	F3★	(F204)	P/20	:	Joint connector
G2★	(F27)	W/18	:	To (M94)	F3★	(F205)	GY/6	:	Accelerator pedal position sensor
D1★	(F28)	SB/3	:	To (F112)	D1★	(F206)	L/4	:	Heated oxygen sensor 2 (BANK 1)
C3	(F29)	W/2	:	Condenser	C1★	(F207)	G/4	:	Heated oxygen sensor 1 (BANK 1)
B2	(F30)	GY/3	:	Ignition coil No. 1	E5★	(F208)	L/4	:	Heated oxygen sensor 2 (BANK 2)
C2	(F31)	GY/3	:	Ignition coil No. 3	F5★	(F209)	G/4	:	Heated oxygen sensor 1 (BANK 2)
C2	(F32)	GY/3	:	Ignition coil No. 5	G3★	(F210)	G/6	:	Electric throttle control actuator
C4★	(F37)	B/3	:	Camshaft position sensor (PHASE) (BANK 2)	E5	(F211)	G/6	:	To (F221)
B3★	(F38)	B/3	:	Camshaft position sensor (PHASE) (BANK 1)	G5	(F221)	G/6	:	To (F211)
G2★	(F39)	G/2	:	Intake valve timing control solenoid valve (BANK 2)					
B2★	(F40)	SB/2	:	Intake valve timing control solenoid valve (BANK 1)					
C4★	(F41)	G/2	:	Swirl control valve control solenoid valve					
C3	(F42)	BR/2	:	VIAS control solenoid valve (With A/T)					
G4	(F100)	L/8	:	To (F5)					
E2★	(F102)	L/2	:	Knock sensor					
B3★	(F103)	GY/2	:	Injector No. 1					
C4★	(F104)	GY/2	:	Injector No. 2					
B3★	(F105)	GY/2	:	Injector No. 3					
C4★	(F106)	GY/2	:	Injector No. 4					
E2★	(F107)	GY/2	:	Injector No. 5					
E1★	(F108)	GY/2	:	Injector No. 6					
D1★	(F112)	SB/3	:	To (F28)					
G4★	(F113)	L/2	:	EVAP canister purge volume control solenoid valve					
E1★	(F114)	GY/2	:	Engine coolant temperature sensor					

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC

MEL105S

EL


IDX

HARNES LAYOUT


Body Harness LH

Body Harness LH

NAEL0438



Body Harness RH



- (B162) W/10 : To (B167) (With heated seat, with woody instrument finisher)
- (B163) B/6 : YAW RATE/SIDE/DECEL G sensor (With VDC)
- (B164) Y/2 : To (B165)
- (B165) Y/2 : To (B164)
- (B166) Y/2 : RH side curtain air bag module (With side air bag)
- (B167) W/10 : To (B162)
- (B168) W/4 : Heated seat switch RH (With heated seat, with woody instrument finisher)
- (B169) L/4 : Heated seat switch LH
- (B300) GY/2 : To (B72)
- (B301) B/3 : Tire carrier switch

- (B50) W/20 : To (M70)
- (B51) W/24 : To (M71)
- (B52) W/16 : To (M72)
- (B55) - : Body ground
- (B56) GY/3 : Heated seat RH (With heated seat) (Via sub-harness)
- (B57) W/2 : Power seat RH
- (B58) GY/5 : G sensor (For 4-wheel drive model with ABS)
- (B59) GY/8 : A/T device (With A/T) (Via sub-harness)
- (B61) B/6 : To (B200) (With M/T)
- (B62) B/4 : To (B201) (With A/T and part-time 4-wheel drive)
- (B64) BR/8 : Terminal cord assembly
- (B65) GY/8 : Park/neutral position switch (With A/T)
- (B66) GY/2 : Park/neutral position switch (With A/T)
- (B67) GY/3 : Rear revolution sensor
- (B68) B/3 : Front door switch RH
- (B69) BR/2 : Rear wheel sensor RH
- (B70) W/10 : To (D70)
- (B71) BR/1 : Rear door switch RH
- (B72) GY/2 : To (B300)
- (B74) W/6 : Rear combination lamp RH
- (B75) - : Body ground
- (B76) W/3 : Ashtray illumination (Without woody instrument finisher)
- (B77) W/12 : To (M99)
- (B78) GY/8 : To (B206)
- (B79) B/4 : To (B208)
- (B80) B/8 : To (B207)
- (B82) GY/6 : To (B251) (With all-mode 4-wheel drive)
- (B83) Y/2 : Seat belt pretensioner RH
- (B87) BR/4 : Turbine revolution sensor (With A/T)
- (B88) GY/20 : To (M100)
- (B89) W/2 : Diode (With all-mode 4-wheel drive)
- (B126) Y/2 : Side air bag module RH (With side air bag)
- (B128) Y/2 : Satellite sensor RH (With side air bag)
- (B129) Y/12 : Air bag diagnosis sensor unit
- (B131) B/2 : Rear power socket
- (B160) - : Body ground (With side air bag)
- (B161) W/4 : Rear TV switch (With rear TV, with woody instrument finisher)


GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT


Back Door Harness

Back Door Harness

NAEL0440




- (D100) W/12 : To (B23)
- (D101) W/6 : To (B24)
- (D102) BR/6 : To (B25)
- (D103) W/3 : Luggage room lamp
- (D105) W/16 : To (D205)
- (D106) W/4 : To (D206)
- (D107) W/2 : To (D300)
- (D108) W/1 : To (D301)
- (D109) W/2 : Diode
- (D110) Y/2 : To (B158)
- (D111) OR/2 : LH side curtain air bag module (with side air bag)
- (D201) W/6 : Back door key cylinder switch
- (D202) BR/2 : License plate lamp (Without spare tire carrier)
- (D203) BR/2 : License plate lamp (With spare tire carrier)
- (D205) W/16 : To (D105)
- (D206) W/4 : To (D106)
- (D207) W/4 : Back door lock actuator
- (D208) W/2 : Back door switch
- (D209) W/2 : Glass hatch switch
- (D210) — : Body ground
- (D212) W/8 : Rear wiper motor
- (D213) W/4 : Back window opener actuator
- (D300) W/2 : To (D107)
- (D301) W/1 : License plate lamp
- (D302) W/3 : License plate lamp
- (D303) B/1 : Rear window defogger
- (D304) B/1 : Rear window defogger
- (D305) — : Body ground
- (Diode) Diode (D109)
- (W/1) : To (D109)
- (W/3) : High-mounted stop lamp
- (B/1) : Rear window defogger
- (B/1) : Rear window defogger
- (—) : Body ground



MEL108S

Engine and Transmission Harness

NAEL0441




GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Room Lamp Harness

Room Lamp Harness

NAEL0442




MEL061Q

HARNES LAYOUT

Air Bag Harness

Air Bag Harness

NAEL0443



GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT


Front Door Harness

Front Door Harness

NAEL0444


LH side

- (D1) W/8 : Door mirror LH
- (D3) BR/16 : To (M5)
- (D4) W/10 : To (M6)
- (D5) GY/6 : Front power window motor LH
- (D6) W/16 : Power window main switch
- (D7) GY/4 : Front door lock actuator LH
- (D9) BR/3 : Front door key cylinder switch LH
- (D10) BR/2 : Front door speaker LH
(Without BOSE system)
- (D12) W/6 : Front door speaker LH
(With BOSE system)
- (D13) GY/12 : To (M112)
- (D15) W/3 : Power window main switch
- (D16) W/8 : Seat memory switch
(With seat memory)
- (D17) W/4 : Trunk and fuel lid opener switch



RH side

- (D31) W/8 : Door mirror RH
- (D33) BR/16 : To (M67)
- (D34) W/6 : To (M68)
- (D35) GY/6 : Front power window motor RH
- (D37) GY/4 : Front door lock actuator RH
- (D40) BR/2 : Front door speaker RH (Without BOSE system)
- (D41) BR/6 : To (M101) (With BOSE system)
- (D42) W/6 : Front door speaker RH (With BOSE system)
- (D44) W/16 : Front power window switch RH



MEL111S


HARNESS LAYOUT

Rear Door Harness

Rear Door Harness


NAEL0445

LH side



- D50** W/10 : To **B10**
- D51** B/2 : Rear power window motor LH
- D52** W/8 : Rear power window switch LH
- D53** BR/2 : Rear door speaker LH
- D54** GY/4 : Rear door lock actuator LH

RH side



- D70** W/10 : To **B70**
- D71** B/2 : Rear power window motor RH
- D72** W/8 : Rear power window switch RH
- D73** BR/2 : Rear door speaker RH
- D74** GY/4 : Rear door lock actuator RH

MEL112S

GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

BULB SPECIFICATIONS*Headlamp***Headlamp**

NAEL0446S01

Item	Wattage W
High/Low (Semi-sealed beam)	60/55 (HB2)

Exterior Lamp

NAEL0446S02

Item	Wattage W	
Front fog lamp	55	
Front turn signal lamp	21	
Parking lamp	5	
Rear combination lamp	Turn signal lamp	27
	Stop/Tail lamp	21/5
	Back-up lamp	18
License plate lamp	5	
High-mounted stop lamp	5	

Interior Lamp

NAEL0446S03

Item	Wattage W
Interior lamp	10
Vanity mirror lamp	1.4
Spot lamp	8
Luggage room lamp	10

WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C, A	HA	Auto Air Conditioner
A/C, M	HA	Manual Air Conditioner
ABS	BR	Anti-lock Brake System
APPS1	EC	Accelerator Pedal Position Sensor 1
APPS2	EC	Accelerator Pedal Position Sensor 2
APPS	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	Automatic Speed Control Device Brake Switch
ASC/SW	EC	Automatic Speed Control Device Steering Switch
ASCIND	EC	Automatic Speed Control Device Indicator
ASCBOF	EC	Automatic Speed Control Device Brake Switch (Off)
AUDIO	EL	Audio
AUT/DP	EL	Automatic Drive Positioner
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	EL	Back-up Lamp
BRK/SW	EC	Brake Switch
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	EL	CAN System
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CLOCK	EL	Clock
COMPAS	EL	Compass and Thermometer
D/LOCK	EL	Power Door Lock
DEF	EL	Rear Window Defogger

Code	Section	Wiring Diagram Name
DTRL	EL	Headlamp — With Daytime Light System —
ECM/PW	EC	ECM Power supply (Back-up)
ECTS	EC	Engine Coolant Temperature Sensor
ENGSS	AT	Engine Speed Signal
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Electric Throttle Control Motor Relay
ETC3	EC	Electric Throttle Control Motor
F/FOG	EL	Front Fog Lamp
F/PUMP	EC	Fuel Pump Control
FTS	AT	A/T Fluid Temperature Sensor
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/LAMP	EL	Headlamp
HEATER	HA	Heater
HORN	EL	Horn
HSEAT	EL	Heated Seat
IATS	EC	Intake Air Temperature Sensor
IGNSYS	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Interior, Spot, Vanity Mirror, and Luggage Room Lamps
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
KEYLES	EL	Remote Keyless Entry System
KS	EC	Knock Sensor
LOAD	EC	Electrical Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
METER	EL	Speedometer, Tachometer, Temp., and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Door Mirror
NATS	EL	NVIS (NISSAN Vehicle Immobilizer System)
NONDTC	AT	Non-detectable Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater (Bank 1)
O2H1B2	EC	Heated Oxygen Sensor 1 Heater (Bank 2)
O2H2B1	EC	Heated Oxygen Sensor 2 Heater (Bank 1)
O2H2B2	EC	Heated Oxygen Sensor 2 Heater (Bank 2)
O2S1B1	EC	Heated Oxygen Sensor 1 (Bank 1)
O2S1B2	EC	Heated Oxygen Sensor 1 (Bank 2)
O2S2B1	EC	Heated Oxygen Sensor 2 (Bank 1)
O2S2B2	EC	Heated Oxygen Sensor 2 (Bank 2)
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PHSB1	EC	Camshaft Position Sensor (PHASE) Bank 1
PHSB2	EC	Camshaft Position Sensor (PHASE) Bank 2
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PNP/SW	EC	Park/Neutral Position PNP Switch
PNP/SW	AT	Park/Neutral Position PNP Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PS/SEN	EC	Power Steering Pressure Sensor
REMOTE	EL	Audio (Remote Control Switch)
RP/SEN	EC	Refrigerant Pressure Sensor
S/VCSW	EC	Swirl Control Valve Control Vacuum Check Switch
SEAT	EL	Power Seat

Code	Section	Wiring Diagram Name
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop Lamp
SWL/V	EC	Swirl Control Valve Control Solenoid Valve
T&FLID	EL	Trunk Lid and Fuel Lid Opener
T/F	TF	Transfer
T/WARN	SU	Low Tire Pressure Warning
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock up)
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS	AT	Throttle Position Sensor
TPS1	EC	Electric Throttle Control Actuator (Throttle Position Sensor 1)
TPS2	EC	Electric Throttle Control Actuator (Throttle Position Sensor 2)
TPS3	EC	Electric Throttle Control Actuator (Throttle Position Sensor)
TRNSCV	EL	Homelink Universal Transceiver
TRSA/T	AT	Turbine Revolution Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VDC	BR	Vehicle Dynamics Control System
VEHSEC	EL	Vehicle Security System
VENT/V	EC	EVAP Canister Vent Control Valve
VIAS/V	EC	Variable Induction Air Control System
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIP/R	EL	Rear Wiper and Washer
WIPER	EL	Front Wiper and Washer