

Rear Shock Absorber

Base Part Number: 18080

Special Tool(s) / General Equipment**Vehicle/Axle Stands****Removal**

⚠ WARNING: Do not apply heat or flame to the shock absorber or strut tube. The shock absorber and strut tube are gas pressurized and could explode if heated. Failure to follow this instruction may result in serious personal injury.


⚠ WARNING: Keep all body parts clear of shock absorbers or strut rods. Shock absorbers or struts can be found unassisted. Failure to follow this instruction may result in serious personal injury.

NOTICE: Suspension fasteners are critical parts that affect the performance of vital components and systems. Failure of these fasteners may result in major service expense. Use the same or equivalent parts if replacement is necessary. Do not use a replacement part of lesser quality or substitute design. Tighten fasteners as specified.

NOTE: Removal steps in this procedure may contain installation details.


1. With the vehicle in NEUTRAL, position it on a hoist.
Refer to: [Jacking and Lifting](#) (100-02 Jacking and Lifting, Description and Operation).
2. Support the rear axle assembly.
Use the General Equipment: Vehicle/Axle Stands





3.

1. Remove and discard the rear shock absorber upper and lower bolts and nuts.
Torque: 52 lb.ft (70 Nm)
2. Remove the rear shock absorber.



Installation

1. To install, reverse the removal procedure.

Copyright © 2019 Ford Motor Company
