

205-02 Rear Drive Axle/Differential - Vehicles With: Dana M220  
Removal and Installation

2019 Ranger  
Procedure revision date: 11/27/2018

---

### Drive Pinion Front Bearing

#### Removal and Installation

**NOTE:** *The outer differential bearing cup needs to be replaced when replacing the outer differential bearing.*

1. Replace the outer pinion bearing cup.

Refer to: [Drive Pinion](#) (205-02 Rear Drive Axle/Differential - Vehicles With: Dana M220, Removal and Installation).

---

Copyright © 2019 Ford Motor Company