


Variable Camshaft Timing (VCT) Oil Control Solenoid

Base Part Number: 6B297/6M280

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the valve cover.
Refer to: [Valve Cover](#) (303-01 Engine - 2.3L EcoBoost (201kW/273PS), Removal and Installation).
2. Remove the bolts and the VCT oil control solenoids.
Torque: 97 lb.in (11 Nm)



Installation

1. To install, reverse the removal procedure.

Copyright © 2019 Ford Motor Company

