


Horn

Base Part Number: 13801

Removal


NOTE: Removal steps in this procedure may contain installation details.

1. Remove the LH front wheel and tire assembly.
Refer to: [Wheel and Tire](#) (204-04A Wheels and Tires, Removal and Installation).
2. Remove the push-pins and position the fender liner aside.



3. Remove the horn assembly.
 1. Disconnect the electrical connector.
 2. Remove the nut.
Torque: 97 lb.in (11 Nm)
 3. Separate the wire harness retainer.





Installation

1. To install, reverse the removal procedure.

