


Front Door Tweeter Speaker

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: Battery Disconnect and Connect (414-01) .
- 2.



Installation

1. To install, reverse the removal procedure.

