

417-01 Exterior Lighting
Removal and Installation

2019 Ranger
Procedure revision date: 01/4/2019


Rear Lamp Assembly

Base Part Number: 13404


Removal

NOTE: LH side shown, RH side similar.

1. Remove the screws and the rear lamp assembly.



2. Disconnect the electrical connector.
 - Remove the harness retainer.



Installation

1. To install, reverse the removal procedure.

Copyright © 2019 Ford Motor Company

