

Center Interior Lamp

Special Tool(s) / General Equipment

Flat-Bladed Screwdriver


Removal

NOTE: Removal steps in this procedure may contain installation details.


1. **NOTICE:** Take extra care when handling the component.

NOTICE: Take extra care not to scratch the Interior lamp lens.


Use the General Equipment: Flat-Bladed Screwdriver



2. Use the General Equipment: Flat-Bladed Screwdriver



3.



Installation

1. To install, reverse the removal procedure.

