


Cowl Panel Grille

Removal

NOTE: Removal steps in this procedure may contain installation details.

NOTE: RHD shown, LHD similar.

1. Remove the windshield wiper pivot arm.
Refer to: Windshield Wiper Pivot Arm - Vehicles Built From: 17-08-2015 (501-16 Wipers and Washers) .
2.
 1. If equipped.
Remove the push pins.
 2. Remove the cowl panel extensions.
 3. Remove the push pins.
 4. Remove the cowl panel grille.



Installation

1. To install, reverse the removal procedure.

