

Fender Splash Shield

Base Part Number: 16054

Removal


NOTE: Removal steps in this procedure may contain installation details.

Both sides

1. Remove the wheel and tire.
Refer to: [Wheel and Tire](#) (204-04A Wheels and Tires, Removal and Installation).
2. Remove the fender moulding.
Refer to: [Front Fender Moulding](#) (501-08 Exterior Trim and Ornamentation, Removal and Installation).

LH Side


3. Remove the pin-type retainers and the fender splash shield.




RH Side

4. Remove the pin-type retainers.





5. Remove the pin-type retainers and the fender splash shield.



Installation

1. To install, reverse the removal procedure.

