


Fuel Filler Door

Special Tool(s) / General Equipment

Flat-Bladed Screwdriver

Removal

1. Using a screwdriver, pry the retaining tab back and slide the fuel filler door from the fuel filler door hinge.
Use the General Equipment: Flat-Bladed Screwdriver



Installation

1. To install, reverse the removal procedure.

