

Handles, Locks, Latches and Entry Systems - Overview

Overview

The power lock/unlock feature locks or unlocks the doors upon a customer request from a door lock control switch, the passive entry system (if equipped) or a RKE transmitter. Driver door can also be locked manually using the mechanical access opening just above the door latch.

If equipped, the passive entry feature automatically locks or unlocks the doors and the tailgate latch.