


Interior Rear Door Handle - Crew Cab


Removal


NOTE: *RH side shown, LH side similar.*

1. Remove the rear door trim panel.
Refer to: [Rear Door Trim Panel - SuperCab](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2.
Remove the interior rear door handle pin.
 1. Release the spring.
 2. Remove the interior rear door handle pivot pin and discard.





3. Remove the interior rear door handle.





Installation


1. Install the interior rear door handle.




2. **NOTE:** Make sure that a new pivot pin is installed.

Install the interior rear door handle pivot pin.

1. Position the interior rear door handle.
2. Install the spring.
3. Install the interior rear door handle pivot pin.





3. Install the rear door trim panel.
Refer to: [Rear Door Trim Panel - SuperCab](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

