

Roller Shutter Lock Cylinder

Removal

NOTE: The roller shutter lock cylinder is serviced as an assembly with the roller shutter rear bar assembly.

NOTE: Repair individual lock cylinders by discarding the inoperative lock cylinder and building a new lock cylinder using the appropriate lock repair service kit. The lock repair service kit includes a detailed instruction sheet to build the new lock to match the key cut pattern for the vehicle, thus allowing for single point replacement without needing to replace or reprogram other locks or keys.

1. Remove the roller shutter rear bar assembly.
Refer to: Roller Shutter Rear Bar Assembly (501-04 Pickup Bed and Platform Body) .

Installation

1. To install, reverse the removal procedure.
2. Rotate the key to check for correct operation.